vhbw VHBW4065705332333

vhbw Dual USB Charger for Olympus Stylus 1, 1s Camera - Instruction Manual

Model: VHBW4065705332333

Introduction

This manual provides instructions for the safe and efficient use of your vhbw Dual USB Charger. This charger is designed to simultaneously charge up to two batteries for Olympus Stylus 1 and 1s cameras. It features an LED indicator to display the charging status and includes a Micro USB charging cable for convenient power supply from any USB port.

Package Contents

- 1 x vhbw Dual USB Charger
- 1 x USB to Micro USB Charging Cable

Safety Information

WARNING:

- To prevent fire or moisture exposure, keep the charger in a dry location.
- To reduce the risk of electronic shock, do not remove the cover or back plate.
- There are no user-serviceable parts inside. Refer all servicing to qualified service personnel.

Caution: Dry location use only.



Image: Bottom view of the vhbw dual USB charger, displaying the model number, input/output specifications, and important safety warnings regarding moisture, electronic shock, and servicing. The text 'Made in China' is also visible.

Setup

1. Connect the supplied USB to Micro USB cable to the Micro USB port on the charger.
2. Plug the standard USB-A end of the cable into any compatible USB power source, such as a computer USB port, a USB wall adapter (not included), or a power bank.
3. Ensure the power source provides sufficient current (AC 5V/2.1A recommended).



Image: The vhbw dual USB charger shown with its included USB to Micro USB cable. The Micro USB end is connected to the charger, and the standard USB-A end is visible, ready to be plugged into a power source.

Operating Instructions

1. With the charger powered on, insert one or two compatible camera batteries into the designated charging slots (CH1 and CH2). Ensure the battery contacts align correctly with the charger's pins.
2. The LED indicator for each channel will illuminate to show the charging status. Typically, a red light indicates charging in progress, and a green light indicates a full charge.
3. The charger automatically switches to trickle charge mode once the batteries are fully charged to prevent overcharging.
4. Once charging is complete, remove the batteries from the charger.



Image: Top view of the vhbw dual USB charger, highlighting the two battery charging slots labeled 'CH1' and 'CH2'. Each slot is designed for BLS-5 type batteries and includes LED indicators to show charging status.

Maintenance

- Keep the charger clean and dry. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners.
- Store the charger in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- Avoid dropping the charger or subjecting it to strong impacts.

Troubleshooting

Charger not powering on:

- Ensure the USB cable is securely connected to both the charger and the power source.
- Verify that the USB power source is active and providing power. Try a different USB port or power adapter.

Batteries not charging:

- Check that the batteries are correctly inserted into the charging slots with proper contact alignment.
- Ensure the batteries are compatible with the charger (Olympus Stylus 1, 1s).
- If the LED indicator remains off or shows an error, the battery might be faulty or deeply discharged. Try a different battery if available.

Specifications

Feature	Specification
Brand	vhbw

Model Number	VHBW4065705332333
Input Voltage	AC 5 V / 2.1 A
Charger Output Voltage	DC 8.4 V
Output Current	DC 2 x 0.5 A / 1 x 0.7 A
Number of Battery Slots	2
Color	Black
Item Weight	61 Grams
Compliant Specifications	CE

Warranty and Support

This vhbw product is covered by a standard manufacturer's warranty. For specific warranty terms, conditions, or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for warranty claims.

© 2023 vhbw. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question