## TechniSat DIGITRADIO CD 2GO BT

# TechniSat DIGITRADIO CD 2GO BT Portable DAB+ Radio and CD Player User Manual

Model: DIGITRADIO CD 2GO BT (0000/3970)

| | | | | | |
|---|---|---|---|---|---|
| **Introduction** | **Safety Information** | **Package Contents** | **Product Overview** | **Setup** | **Operation** |
| | **Maintenance** | **Troubleshooting** | **Specifications** | | |

## 1. INTRODUCTION

Thank you for choosing the TechniSat DIGITRADIO CD 2GO BT. This portable device combines a CD player with DAB+ and FM radio reception, along with Bluetooth connectivity, offering versatile audio entertainment. This manual provides essential information for the safe and efficient use of your device, including setup, operation, and maintenance.
Please read this manual thoroughly before using the device and retain it for future reference.

## 2. SAFETY INFORMATION

Observe the following safety precautions to prevent damage to the device or injury to yourself:

- Do not expose the device to rain, moisture, or extreme temperatures.
- Avoid placing the device near heat sources or in direct sunlight.
- Do not open the device casing. Refer all servicing to qualified personnel.
- Use only the specified power adapter and batteries.
- Ensure proper ventilation around the device during operation.
- Avoid listening at excessively high volumes for prolonged periods to prevent hearing damage.

## 3. PACKAGE CONTENTS

Please check that all items are present in the package:

- TechniSat DIGITRADIO CD 2GO BT unit

- Headphones

- 2 x BL5C rechargeable batteries

- External power cable (AC adapter)

- User Manual (this document)

## 4. PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your DIGITRADIO CD 2GO BT.



**Figure 4.1:** Front view of the TechniSat DIGITRADIO CD 2GO BT, showing the display, navigation buttons (ON/OFF OK, SKIP UP, SKIP DOWN), playback controls (PLAY/PAUSE, STOP/SEARCH), and function buttons (MENU, EQ/BT, MODE).

# CD-Player mit MP3-Funktion

Spielt die Lieblings-CDs rauf und runter.

**Figure 4.2:** Top view of the device with the CD compartment open, revealing the CD spindle and loading area. This is where audio CDs, MP3 CDs, CD-R, and CD-RW discs are inserted.

## Kopfhöreranschluss

Flexibilität ist mit dem DIGITRADIO CD 2GO BT auch geboten. Denn Sie genießen Ihre Lieblingsmusik mit klassischen, kabelgebundenen oder auch kabellosen Kopfhörern - dank Bluetooth-Funktion.

**Figure 4.3:** Side view illustrating the 3.5mm headphone jack, which also serves as the antenna for FM and DAB+ radio reception when headphones are connected.

### Controls:

- **ON/OFF OK:** Power on/off, confirm selection.
- **PLAY/PAUSE:** Start or pause playback.
- **STOP/SEARCH:** Stop playback, initiate station search in radio mode.
- **SKIP UP / SKIP DOWN:** Skip tracks on CD, navigate menus, tune radio stations.
- **MENU:** Access menu options.
- **EQ/BT:** Access equalizer settings, activate Bluetooth pairing.
- **MODE:** Switch between CD, DAB+, FM, and Bluetooth modes.

## 5. SETUP

### 5.1. Battery Installation

The DIGITRADIO CD 2GO BT operates on two BL5C rechargeable batteries. To install:

1. Locate the battery compartment on the underside of the device.
2. Open the battery compartment cover.

3. Insert the two BL5C batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

## 5.2. Powering the Device

You can power the device using the included AC adapter or the installed rechargeable batteries.

- **AC Power:** Connect the external power cable to the DC IN port on the device and plug the adapter into a wall outlet.
- **Battery Power:** Ensure the batteries are charged. The device will automatically switch to battery power when disconnected from AC.

## 5.3. Initial Power On

Press and hold the **ON/OFF OK** button to power on the device. The display will illuminate. If this is the first time powering on, the device may prompt you for initial setup options such as language or perform an automatic DAB+ station scan.

# 6. OPERATING INSTRUCTIONS

## 6.1. CD Playback

The DIGITRADIO CD 2GO BT supports audio CDs, MP3 CDs, CD-R, and CD-RW formats.



# DIGITRADIO CD 2GO BT

Tragbarer CD-Spieler

**Figure 6.1:** The portable design of the DIGITRADIO CD 2GO BT makes it suitable for on-the-go use.

1. Open the CD compartment cover.
2. Place a CD onto the spindle with the label side facing up.
3. Close the CD compartment cover firmly until it clicks.
4. Press the **MODE** button until "CD" mode is selected.
5. Press the **PLAY/PAUSE** button to start playback.
6. Use **SKIP UP** and **SKIP DOWN** to navigate between tracks.
7. Press **PLAY/PAUSE** to pause, and **STOP/SEARCH** to stop playback.

**Resume Function:** The player will automatically resume playback from the last listened position after being turned off and on again, ideal for audiobooks.

**Anti-Shock Protection (ASP):** This feature helps prevent playback interruptions during movement, ensuring a smooth listening experience.



## Mit ASP-Funktion

Kein Aussetzen der Wiedergabe bei Bewegungen

**Figure 6.2:** The Anti-Shock Protection (ASP) feature ensures uninterrupted audio playback even during activities like cycling or walking.

## 6.2. DAB+ Radio

DAB+ (Digital Audio Broadcasting Plus) offers high-quality digital radio reception.

**Figure 6.3:** Enjoy a wide variety of digital radio programs with DAB+ reception.

1. Connect the included headphones to the 3.5mm jack; they act as the antenna.
2. Press the **MODE** button until "DAB+" mode is selected.
3. If this is the first time in DAB+ mode, the device will perform an automatic scan for available stations.
4. Use **SKIP UP** and **SKIP DOWN** to browse through available DAB+ stations.
5. To save a favorite station, press and hold the **MENU** button, navigate to "Preset Store", select a preset number (1-10), and press **ON/OFF OK** to confirm.
6. To recall a favorite station, press the **MENU** button, navigate to "Preset Recall", select the desired preset, and press **ON/OFF OK**.

### 6.3. FM Radio

For traditional analog radio reception.

1. Connect the included headphones to the 3.5mm jack; they act as the antenna.
2. Press the **MODE** button until "FM" mode is selected.
3. Press **STOP/SEARCH** to automatically scan for the next available FM station.
4. Alternatively, use **SKIP UP** and **SKIP DOWN** for manual tuning.
5. To save a favorite station, press and hold the **MENU** button, navigate to "Preset Store", select a preset number (1-10), and press **ON/OFF OK** to confirm.
6. To recall a favorite station, press the **MENU** button, navigate to "Preset Recall", select the desired

preset, and press **ON/OFF OK**.

## 6.4. Bluetooth Connection

Connect your DIGITRADIO CD 2GO BT to Bluetooth headphones or speakers.

1. Press the **MODE** button until "Bluetooth" mode is selected. The device will enter pairing mode, indicated by a flashing Bluetooth icon on the display.
2. Activate Bluetooth on your external audio device (e.g., headphones, speaker) and set it to pairing mode.
3. On the DIGITRADIO CD 2GO BT, press and hold the **EQ/BT** button to initiate a search for nearby Bluetooth devices.
4. Select your desired device from the list on the DIGITRADIO CD 2GO BT's display using **SKIP UP**/**DOWN** and confirm with **ON/OFF OK**.
5. Once connected, the Bluetooth icon will become solid. Audio will now be streamed to the connected device.

## 6.5. Volume Control

Adjust the volume using the dedicated volume buttons (often integrated with SKIP UP/DOWN or separate buttons, refer to your device's specific button layout if different from general description). Note that due to European standards, a default volume limitation is active. To deactivate this and increase the maximum volume, press and hold the **MENU** button for a few seconds. Navigate through the menu options to find the "Volume Limit" setting and adjust it as desired. Refer to page 17 of the original printed manual for precise instructions on this setting.

## 6.6. Equalizer Settings

Customize your audio experience with the built-in equalizer.

1. Press the **EQ/BT** button (short press) to cycle through preset equalizer modes (e.g., Pop, Rock, Jazz, Classic, Flat).
2. Some models may offer a custom equalizer setting, allowing manual adjustment of bass and treble. Consult the device display for available options.

# 7. MAINTENANCE

## 7.1. Cleaning

To maintain the appearance and functionality of your device:

- Wipe the exterior with a soft, dry cloth.
- For stubborn marks, use a slightly damp cloth with mild detergent, then wipe dry.
- Do not use abrasive cleaners, solvents, or alcohol, as these can damage the surface.
- Periodically clean the CD lens with a specialized CD lens cleaner disc.

## 7.2. Battery Care

To prolong battery life:

- Fully charge the batteries before first use.
- If the device will not be used for an extended period, remove the batteries to prevent leakage.
- Dispose of used batteries according to local regulations.

# 8. TROUBLESHOOTING

If you encounter issues with your DIGITRADIO CD 2GO BT, refer to the following table:

| Problem | Possible Cause | Solution |
|---|---|---|
| Device does not power on. | Batteries are depleted or incorrectly inserted. AC adapter not connected or faulty. | Check battery charge and polarity. Ensure AC adapter is securely connected and functional. |
| No sound from headphones. | Headphones not properly connected. Volume too low. Volume limit active. | Ensure headphones are fully plugged in. Increase volume. Deactivate volume limit (see Section 6.5). |
| CD skips or does not play. | CD is dirty, scratched, or inserted incorrectly. CD compartment not closed. | Clean the CD. Ensure it is inserted correctly. Close the CD compartment firmly. |
| Poor radio reception (DAB+/FM). | Headphones not connected or poorly positioned. Weak signal in current location. | Ensure headphones are connected and fully extended. Try repositioning the device or moving to a different location. |
| Bluetooth pairing fails. | Device not in pairing mode. External device too far or not in pairing mode. | Ensure both devices are in pairing mode and within range. Try restarting both devices. |

# 9. SPECIFICATIONS

| Feature | Detail |
|---|---|
| Model Name | DIGITRADIO CD 2GO BT |
| Model Number | 0000/3970 |
| Brand | TechniSat |
| Connectivity Technology | Bluetooth |
| Special Features | Replaceable Battery, Anti-Shock Function, Resume Function |
| Compatible Devices | Headphones |
| Supported Audio Formats | MP3, WMA, AAC |
| Number of Discs | 1 |
| Connector Type | 3.5 mm Jack |
| Power Source | 2 x Lithium-ion batteries (included), AC adapter |
| Battery Rechargeable | Yes |
| Usage | Indoor and Outdoor |
| Dimensions (W x H x D) | 14 x 2.50 x 14 cm (approximate, from feature bullets) |

## 10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official TechniSat website. Keep your proof of purchase for any warranty claims.

Please note that spare parts availability is currently listed as "unavailable" according to product specifications. Software updates are also listed as "information not available".

## Related Documents - DIGITRADIO CD 2GO BT

| | |
|---|---|
| | [TechniSat DIGITRADIO 140 Instruction Manual](#)<br>Comprehensive instruction manual for the TechniSat DIGITRADIO 140, covering setup, operation, features like Internet Radio, DAB+, FM, Bluetooth, CD/MP3 playback, and troubleshooting. |
| | [TechniSat DIGITRADIO 601 & 631: Bedienungsanleitung für Internetradio mit DAB+/UKW und Bluetooth](#)<br>Umfassende Bedienungsanleitung für das TechniSat DIGITRADIO 601 und DIGITRADIO 631. Erfahren Sie mehr über die Funktionen, Einrichtung und Bedienung Ihres Internet-Radios mit DAB+/UKW-Tuner und Bluetooth-Streaming. |
| | [DIGITRADIO 217: Instrukcja obsługi radia DAB+/FM z Bluetooth i budzikiem](#)<br>Przewodnik użytkownika dla TechniSat DIGITRADIO 217, szczegółowo opisujący funkcje radia DAB+/FM, strumieniowe przesyłanie dźwięku Bluetooth, ustawienia budzika i obsługę. |
| | [TechniSat DIGITRADIO 143 CD Instruction Manual](#)<br>Comprehensive instruction manual for the TechniSat DIGITRADIO 143 CD, covering setup, operation, features like internet radio, DAB+, FM, Bluetooth, and CD playback, along with troubleshooting and technical data. |
| | [TechniSat DIGITRADIO 380 CD IR User Manual: Internet Radio, DAB+, FM, Bluetooth, CD Player](#)<br>Comprehensive user manual for the TechniSat DIGITRADIO 380 CD IR. Learn how to set up, operate, and troubleshoot your internet radio, DAB+/FM tuner, Bluetooth streamer, and CD player. |
| | [TechniSat DigitRadio 210 IR User Manual - DAB/FM Radio Guide](#)<br>Comprehensive user manual for the TechniSat DigitRadio 210 IR, covering setup, operation, DAB/FM features, safety, and technical specifications. Learn how to use your digital radio. |