Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KitchenAid 5KFCB519EER

KitchenAid 5KFCB519EER Wireless Electric Chopper

USER MANUAL

Introduction

Thank you for choosing the KitchenAid 5KFCB519EER Wireless Electric Chopper. This versatile appliance is designed to simplify your food preparation tasks, offering efficient chopping and mixing capabilities without the need for a power cord during operation. Its rechargeable lithium-ion battery provides maximum flexibility and performance. Please read this manual thoroughly before first use to ensure safe and optimal operation of your new chopper.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the chopper.
- To protect against risk of electrical shock, do not immerse the motor base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by KitchenAid may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter.
- Do not let cord contact hot surfaces.
- Be extremely careful when handling the sharp processing blades. Always handle the blade assembly by the plastic hub.
- Always ensure the lid is securely locked in place before operating the appliance.
- Do not attempt to defeat the lid interlock mechanism.
- Do not fill the work bowl above the maximum fill line to prevent overflow.

Product Overview and Components





Figure 1: The KitchenAid Wireless Electric Chopper fully assembled, showcasing its compact design and vibrant red base.



Figure 2: All components of the chopper laid out, including the motor base, 1.19L work bowl, lid, multi-purpose blade, whisk accessory, and charging adapter.

The KitchenAid Wireless Electric Chopper consists of several key components designed for ease of use and versatility:

- **Motor Base:** Contains the rechargeable battery and motor, with a control dial for speed selection and pulse function.
- **1.19L BPA-Free Work Bowl:** Transparent bowl with a handle and spout for easy pouring.
- **Lid:** Features a liquid drizzle basin and locks securely onto the work bowl.
- **Multi-Purpose Blade:** Stainless steel blade for chopping, mincing, and pureeing.
- **Whisk Accessory:** For whisking, stirring, and emulsifying.
- **Charging Adapter:** For recharging the internal lithium-ion battery.

Setup and Charging

Unpacking and Initial Cleaning

1. Carefully unpack all parts from the carton.
2. Wash the work bowl, lid, multi-purpose blade, and whisk accessory in warm, soapy water or in the dishwasher (top rack only).

3. Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
4. Dry all parts thoroughly before assembly.

Charging the Battery

The chopper is powered by a rechargeable lithium-ion battery. For optimal performance, fully charge the battery before first use.

1. Ensure the chopper is turned off (control dial set to '0').
2. Locate the charging port on the back of the motor base.
3. Connect the charging adapter to the charging port and plug the adapter into a standard electrical outlet.
4. The battery indicator lights on the front of the motor base will illuminate to show charging progress. All lights will be solid when fully charged.
5. A full charge typically takes approximately 2 hours.





Figure 3: Side view of the chopper, highlighting the location of the charging port on the motor base.

Operating Instructions

Assembly for Use

1. Place the motor base on a clean, dry, flat surface.
2. Carefully place the multi-purpose blade or whisk accessory onto the drive pin inside the work bowl.
3. Add ingredients to the work bowl. Do not exceed the maximum fill line.
4. Place the lid onto the work bowl and twist clockwise until it locks securely into place. Ensure the lid handle aligns with the work bowl handle.
5. Place the assembled work bowl and lid onto the motor base, aligning the tabs and twisting clockwise until it locks.

Chopping and Mixing

1. With the chopper fully assembled and ingredients loaded, select your desired speed using the control dial:
    - **Speed 1:** For slower chopping, mixing, and pureeing.
    - **Speed 2:** For faster chopping and processing.
2. For continuous operation, turn the dial to '1' or '2'.
3. For pulse operation, turn the dial to 'P' and hold. Release to stop. This is ideal for coarse chopping or to prevent over-processing.
4. Process ingredients until desired consistency is achieved.
5. When finished, turn the control dial to '0' and wait for the blade to stop completely before disassembling.



Figure 4: The KitchenAid chopper actively processing ingredients in a kitchen environment, demonstrating its practical application.

Tips for Best Results

- Cut large ingredients into 2.5 cm (1 inch) pieces for even processing.
- Do not overload the work bowl. Process in batches if necessary.
- For liquids, use the liquid drizzle basin on the lid to slowly add oil or other liquids while processing.
- Use the pulse function for precise control over consistency, especially for delicate ingredients or when you want a coarse chop.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your KitchenAid chopper.

Disassembly for Cleaning

1. Ensure the control dial is set to '0' and the blade has stopped rotating.

2. Twist the work bowl counter-clockwise to unlock it from the motor base and lift it off.
3. Twist the lid counter-clockwise to unlock it from the work bowl and remove.
4. Carefully remove the multi-purpose blade or whisk accessory by grasping the plastic hub.

Cleaning Instructions

- **Work Bowl, Lid, Multi-Purpose Blade, Whisk Accessory:** These parts are dishwasher-safe (top rack only). Alternatively, wash in warm, soapy water, rinse thoroughly, and dry.
- **Motor Base:** Wipe clean with a damp cloth. Do not immerse in water or other liquids.
- For stubborn food residue, soak parts in warm, soapy water before cleaning.

Storage

Store the chopper assembled or disassembled in a clean, dry place. Ensure the blade is stored safely to prevent accidental injury. The blade can be stored inside the work bowl with the lid on for compact storage.

Troubleshooting

If you experience issues with your KitchenAid Wireless Electric Chopper, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chopper does not turn on.	Battery is depleted. Work bowl or lid not properly assembled/locked.	Charge the battery fully. Ensure the work bowl is locked onto the motor base and the lid is locked onto the work bowl.
Motor runs, but blade does not spin.	Blade not properly seated on drive pin. Work bowl overloaded.	Ensure the blade is fully pushed down onto the drive pin. Reduce the amount of ingredients in the work bowl.
Chopper stops during operation.	Overload protection activated. Battery low.	Turn off, remove some ingredients, and wait a few minutes before restarting. Recharge the battery.
Ingredients are unevenly chopped.	Ingredients too large or too many. Insufficient pulsing.	Cut ingredients into smaller, uniform pieces. Process in smaller batches. Use the pulse function for better control and to redistribute ingredients.

If the problem persists after trying these solutions, please contact KitchenAid Customer Service for assistance.

Specifications

Brand	KitchenAid
Model Number	5KFCB519EER
Colour	Imperial Red
Capacity	1.19 Liters (Work Bowl)

Power / Wattage	24 Watts
Voltage	12 Volts (Internal Battery) / 220-240V (Charger Input)
Frequency	50/60 Hz (Charger)
Material	Plastic (BPA-free work bowl)
Number of Speeds	2 + Pulse
Item Weight	1.27 Kilograms
Product Dimensions (H x W x D)	264 x 140 x 168 mm (approx.)
Care Instructions	Hand Wash (Motor Base), Dishwasher Safe (Work Bowl, Lid, Blades - Top Rack)

Warranty and Customer Support

KitchenAid products are manufactured to the highest quality standards. For information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official KitchenAid website for details specific to your region.

Should you require assistance, have questions, or need to order replacement parts, please contact KitchenAid Customer Service. Contact information can typically be found on the KitchenAid website or in your product's packaging.

Online Support: Visit www.kitchenaid.com/service-and-support.html (or your regional KitchenAid website) for FAQs, troubleshooting guides, and contact options.

© 2023 KitchenAid. All rights reserved. Model: 5KFCB519EER.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09K6DQH33

More documents and user manuals: **https://manuals.plus/**