Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Haier HP2590DEL-ZWA

Haier HP2590DEL-ZWA 25 Liter Digital Microwave Oven User Manual

Model: HP2590DEL-ZWA

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should be followed, including the following:

- Read all instructions before using the appliance.
- Do not operate the oven when empty.
- Do not attempt to tamper with, or make any adjustments or repairs to the door, control panel, safety interlock switches, or any other part of the oven.
- Do not heat liquids or other foods in sealed containers since they are liable to explode.
- Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
- Ensure proper ventilation around the microwave. Do not block air vents.
- Do not use corrosive chemicals or vapors in this appliance.
- Do not use metal utensils or containers in the microwave, as this can cause arcing.
- Always use oven mitts when removing items from the microwave as they can be very hot.

2. Product Overview

The Haier HP2590DEL-ZWA is a 25-liter digital microwave oven designed for convenient and efficient cooking. It features a sleek silver design with an electronic control panel and LED display.



Front view of the Haier HP2590DEL-ZWA 25 Liter Digital Microwave Oven, showing the closed door and control panel.

Key Features:

- **Capacity:** 25 Liters
- **Output Power:** 900 Watts
- **Power Levels:** 6 cooking power levels
- **Display:** LED display
- **Controls:** Electronic with one-touch settings
- **Defrost Function:** Automatic defrost
- **Safety:** Child lock feature
- **Door:** Left-hinged, tempered glass outer screen
- **Interior:** Glass material for easy cleaning
- **Color:** Silver

Control Panel:





A detailed view of the microwave's control panel, showing buttons for Power Level, Weight Adjust, Speed Defrost, Auto Defrost, Preset, Clock, Menu, Time, Pause/Cancel, and Start/Quick Start.

The control panel includes buttons and a rotary knob for various functions:

- **Power Level:** Adjust microwave power.
- **Weight Adjust:** For weight-based defrosting or cooking.

- **Speed Defrost:** Quick defrost function.
- **Auto Defrost:** Automatic defrost based on food type.
- **Preset:** Pre-programmed cooking settings.
- **Clock:** Set the current time.
- **Menu:** Access various cooking menus.
- **Time (Rotary Knob):** Adjust cooking time or settings.
- **Pause/Cancel:** Stop or clear current operation.
- **Start/Quick Start:** Begin cooking or start quick cooking.

3. Setup

Unpacking:

- Remove all packaging materials from inside and outside the microwave oven.
- Check the oven for any damage, such as dents or a misaligned door. Do not operate the oven if it is damaged.
- Ensure the glass turntable and turntable ring are present and correctly placed inside the oven.



Interior view of the microwave, showing the glass turntable and roller ring in place.

Placement:

- Place the microwave on a flat, stable surface that can support its weight and the heaviest food item likely to be cooked in it.
- Ensure there is adequate space for ventilation: at least 20 cm (8 inches) of space above the oven, 10 cm (4 inches) at the rear, and 5 cm (2 inches) on each side.
- Do not place the microwave near heat sources or in a damp environment.

Power Connection:

- Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the microwave.

4. Operating Instructions

Setting the Clock:

1. Press the **Clock** button.
2. Rotate the **Time** knob to set the hour.
3. Press the **Clock** button again.
4. Rotate the **Time** knob to set the minutes.
5. Press the **Clock** button one more time to confirm.

Basic Microwave Cooking:

1. Place food in a microwave-safe container on the turntable.
2. Close the door securely.
3. Press the **Power Level** button repeatedly to select the desired power level (e.g., P100 for full power, P80 for 80% power). There are 6 power levels available.
4. Rotate the **Time** knob to set the cooking time.
5. Press the **Start/Quick Start** button to begin cooking.

Quick Start Cooking:

- Press the **Start/Quick Start** button repeatedly to cook at full power for 30-second intervals. Each press adds 30 seconds.

Automatic Defrost:

1. Place the frozen food on the turntable.
2. Press the **Auto Defrost** button.
3. Rotate the **Weight Adjust** knob to select the food weight.
4. Press the **Start/Quick Start** button to begin defrosting.

Child Lock Function:

- **To activate:** Press and hold the **Pause/Cancel** button for 3 seconds. An indicator will appear on the display.
- **To deactivate:** Press and hold the **Pause/Cancel** button for 3 seconds again. The indicator will disappear.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your microwave oven.

- **Exterior:** Wipe the exterior with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Interior:** Clean the interior cavity after each use. For stubborn food splatters, place a bowl of water with lemon slices inside and microwave for 2-3 minutes. The steam will loosen the residue, making it easier to wipe clean.

- **Turntable and Roller Ring:** The glass turntable and roller ring can be removed and washed in warm soapy water or in a dishwasher. Ensure they are completely dry before placing them back in the oven.
- **Door Seals:** Keep the door seals clean to ensure a proper seal during operation.
- **Ventilation Openings:** Ensure the ventilation openings are clear of dust and debris.

Caution: Always unplug the microwave oven before cleaning.

6. Troubleshooting

If you encounter any issues with your microwave, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven will not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure power cord is securely plugged in; Close the door firmly; Check household fuse or reset circuit breaker.
Food not heating	Door not closed properly; Cooking time not set; Power level too low.	Ensure door is fully closed; Set appropriate cooking time; Increase power level.
Turntable not rotating	Turntable not properly placed; Roller ring dirty or damaged; Food too large or heavy.	Ensure turntable and roller ring are correctly positioned; Clean roller ring and oven floor; Use smaller dishes or lighter food items.
Unusual noise during operation	Turntable or roller ring misaligned; Foreign object inside.	Check and adjust turntable and roller ring; Remove any foreign objects.

If the problem persists after trying these solutions, please contact customer service.

7. Specifications

Feature	Specification
Brand	Haier
Model Information	HP2590DEL-ZWA
Product Dimensions (W x H x D)	48.3 x 28.1 x 42.2 cm
Capacity	25 Liters
Installation Type	Freestanding
Part Number	6925777888207
Special Features	LED Display, 6 Power Levels, Automatic Defrost, One-Touch Settings, Child Lock
Oven Cooking Mode	Microwave

Feature	Specification
Color	Silver
Power Output	900 Watts
Defrost Function	Yes
Door Hinges	Left
Material Type (Exterior)	Glass
Interior Material Type	Glass
Item Weight	15.4 Kilograms
Control Type	Switch

8. Warranty and Support

For installation services, warranty information, or technical support, please contact Haier customer service at the following numbers:

- **Riyadh:** +966-11-4094006 Ext – 113
- **Jeddah:** +966-12-6577714
- **Dammam:** +966-13-8343691
- **Qassim:** +966 581044198
- **Abha:** +966 593322785

Please have your model number (HP2590DEL-ZWA) and purchase date available when contacting support.

© 2023 Haier. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09KBMR9C9

More documents and user manuals: **https://manuals.plus/**