OXO 11262700

OXO Good Grips Glass Salad Spinner Instruction Manual

Brand: OXO | Model: 11262700

1. Introduction

Thank you for choosing the OXO Good Grips Glass Salad Spinner. This manual provides detailed instructions for the proper assembly, operation, maintenance, and troubleshooting of your new salad spinner. Designed for efficiency and durability, this product features an elegant borosilicate glass bowl that doubles as a serving dish, a convenient one-hand pump mechanism, and a patented brake button for immediate stopping. Please read this manual thoroughly before first use to ensure optimal performance and longevity of your product.

2. Product Overview

The OXO Good Grips Glass Salad Spinner is comprised of three main components: the glass bowl, the colander basket, and the lid with the pump mechanism.



Figure 2.1: Assembled OXO Good Grips Glass Salad Spinner.



Figure 2.2: Components of the salad spinner: glass bowl, removable colander basket, and lid with pump.



Figure 2.3: Product dimensions: approximately 15.2 cm (6.0 in) high and 27.1 cm (10.7 in) in diameter.



Figure 2.4: Key features include a patented brake button, a non-slip base for stability during use, and an integrated storage lock to keep the pump flush with the lid for compact storage.

3. Setup

1. **Unpack Components:** Carefully remove all parts from the packaging: the glass bowl, the colander basket, and the lid.
2. **Initial Cleaning:** Before first use, wash all components with warm, soapy water. Rinse thoroughly and dry. All parts are dishwasher safe (top rack recommended for the lid).
3. **Assembly:** Place the colander basket inside the glass bowl. Position the lid securely on top of the bowl, ensuring it is properly aligned. The pump mechanism on the lid should be in the unlocked (up) position.

4. Operating Instructions

4.1. Preparing Greens

1. Place your washed salad greens or herbs into the colander basket. The basket can also be used as a standalone colander for rinsing.
2. Ensure the greens are loosely packed to allow for effective spinning.

4.2. Spinning the Greens

1. Insert the colander basket with greens into the glass bowl.
2. Place the lid securely on the glass bowl. Ensure the pump is in the unlocked (up) position.
3. Press the large pump knob repeatedly to initiate the spinning action. The basket will rotate rapidly, using centrifugal force to remove excess water from your greens.



Figure 4.1: Operating the one-hand pump for efficient drying.

4. Continue pumping until the greens are dry to your desired crispness.

4.3. Stopping the Spinner

1. To stop the spinning action instantly, firmly press the patented brake button located on the lid.



Figure 4.2: Pressing the brake button to stop the spinning action immediately.

2. Once the basket has stopped, remove the lid and lift out the colander basket.

4.4. Serving and Storage

- The elegant borosilicate glass bowl can be used directly as a serving bowl for your freshly dried salad.



Figure 4.3: The glass bowl is suitable for serving salads directly.

- For compact storage, press the pump knob down and engage the storage lock (a small button or lever on the lid) to keep the pump flush with the lid.

5. Maintenance and Cleaning

- **Dishwasher Safe:** All components of the OXO Good Grips Glass Salad Spinner are dishwasher safe. For best results and to prolong the life of the lid mechanism, place the lid on the top rack of the dishwasher.
- **Hand Washing:** If hand washing, use warm, soapy water and a soft sponge or cloth. Rinse all parts thoroughly to remove any soap residue.
- **Drying:** Ensure all parts are completely dry before reassembling or storing to prevent water spots or mildew.
- **Lid Care:** Periodically check the lid mechanism for any food particles or debris that might impede its function. Clean gently with a small brush if necessary.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Salad greens are not drying effectively.	Basket is overloaded; insufficient pumping; lid not sealed properly.	Do not overload the basket; pump more vigorously or for a longer duration; ensure the lid is securely seated on the bowl.
Pump mechanism feels stiff or sticky.	Food residue or mineral buildup; pump in locked position.	Thoroughly clean the lid, especially around the pump mechanism. Ensure the storage lock is disengaged before use.
Spinner is unstable during use.	Uneven surface; non-slip base is wet or dirty.	Place the spinner on a flat, stable surface. Ensure the non-slip base on the bottom of the bowl is clean and dry.

7. Specifications

- **Brand:** OXO
- **Model Number:** 11262700
- **Color:** Glass
- **Material:** Borosilicate Glass (Bowl), Plastic (Lid, Basket)
- **Product Dimensions:** Approximately 18.59 x 30.61 x 31.19 cm (7.32 x 12.05 x 12.28 inches)
- **Item Weight:** Approximately 1.47 Kilograms (3.24 pounds)
- **Dishwasher Safe:** Yes
- **BPA-Free:** Yes

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official OXO website. You can also find more information and contact details through the OXO Brand Store on Amazon.

© 2025 OXO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question