**JVC SI50UR**

# JVC SI50UR 50-inch 4K LED Smart TV User Manual

Model: SI50UR

## 1. Introduction

This user manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your JVC SI50UR 50-inch 4K LED Smart TV. Please read this manual thoroughly before using your television to ensure proper functionality and safety. Keep this manual for future reference.

## 2. Product Overview

### 2.1 Key Features

- 50-inch 4K UHD (3840 x 2160) LED Display
- Roku Operating System for integrated smart TV functionality
- High Dynamic Range (HDR10) support for enhanced contrast and color
- Built-in Wi-Fi for seamless internet connectivity
- Multiple HDMI inputs for connecting external devices
- Easy setup and automatic software updates
- Private audio listening via the Roku mobile app

### 2.2 Package Contents

Upon unboxing, verify that all items listed below are present:

- JVC SI50UR 50-inch 4K LED Smart TV
- Remote Control with Batteries
- Tabletop Stand (2 pieces)
- Stand Screws
- Power Cord
- User Manual (this document)
- Quick Start Guide

- Warranty Card

## 3. Setup

### 3.1 Attaching the TV Stand

If you are not wall-mounting your TV, follow these steps to attach the tabletop stand:

1. Carefully place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align each stand leg with the corresponding slots on the bottom of the TV.
3. Secure each leg with the provided screws. Ensure they are tightened firmly.
4. Carefully lift the TV to an upright position on a stable, level surface.




**Image 3.1:** Front view of the JVC SI50UR 50-inch 4K LED Smart TV, displaying the Roku operating system home screen with various streaming applications and input options. This image illustrates the TV's appearance and initial interface.

### 3.2 Connecting External Devices

Your JVC Smart TV offers multiple ports for connecting various devices.

- **HDMI Ports:** Connect Blu-ray players, game consoles, cable/satellite boxes, or other HDMI-enabled devices.
- **USB Port:** For media playback from USB storage devices.
- **Antenna/Cable Input:** Connect an antenna for over-the-air broadcasts or a cable connection.
- **Optical Audio Output:** For connecting to a soundbar or home theater system.
- **Ethernet Port:** For a wired internet connection (optional, Wi-Fi is also available).

Ensure all connections are secure before powering on the TV.

### 3.3 Initial Power On and Roku Setup

1. Plug the power cord into the TV and then into a wall outlet.
2. Press the Power button on the remote control.
3. Follow the on-screen instructions to complete the initial Roku setup, which includes:
    - Selecting your language.
    - Connecting to your Wi-Fi network (or wired Ethernet).
    - Activating your Roku account (a free account is required).
    - Scanning for local channels (if an antenna is connected).




**Image 3.2:** A visual representation of the Roku TV interface, showcasing a variety of streaming applications for movies, series, news, and sports. This image demonstrates the diverse content options available through the integrated Roku OS.

## 4. Operating Instructions

## 4.1 Remote Control Functions

The included remote control allows you to navigate the Roku interface and control your TV.

- **Power Button:** Turns the TV on or off.
- **Directional Pad (D-Pad):** Navigates menus and selects items.
- **OK/Enter Button:** Confirms selections.
- **Home Button:** Returns to the Roku home screen.
- **Back Button:** Returns to the previous screen.
- **Volume Up/Down:** Adjusts the TV volume.
- **Mute Button:** Mutes or unmutes the sound.
- **Instant Replay:** Jumps back a few seconds in video playback.
- **Star Button (*):** Accesses options for the selected item.
- **Dedicated Channel Buttons:** Quick access to popular streaming services.

## 4.2 Navigating the Roku OS

The Roku OS provides a user-friendly interface for accessing streaming channels, inputs, and settings.

- From the Home screen, use the D-Pad to highlight desired channels or inputs.
- Press the OK button to launch a channel or switch to an input.
- Access the "Settings" menu for network configuration, display options, audio settings, and system updates.




**Image 4.1:** A smartphone screen displaying the Roku mobile application interface. This app allows users to control their Roku TV, browse channels, and utilize features like private listening, enhancing the overall user experience.

## 4.3 Connecting to Wi-Fi

1. From the Home screen, navigate to **Settings**.
2. Select **Network**.
3. Choose **Set up connection** and then **Wireless**.
4. Select your Wi-Fi network from the list and enter your password.
5. The TV will connect and confirm the network status.

## 4.4 Using Streaming Services

Once connected to the internet, you can access a wide range of streaming channels.

- From the Home screen, select a pre-installed channel (e.g., Netflix, Hulu, YouTube).
- To add new channels, navigate to **Streaming Channels** and browse the Roku Channel Store.
- You may need to sign in with existing accounts or create new ones for certain services.

# 5. Maintenance

## 5.1 Cleaning Your TV

- Always unplug the TV before cleaning.
- Use a soft, dry, lint-free cloth to gently wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner. Never spray cleaner directly onto the screen.
- Avoid using abrasive cleaners, waxes, or solvents.

## 5.2 Software Updates

Your JVC Roku TV automatically receives software updates to improve performance and add new features.

- Ensure your TV is connected to the internet for automatic updates.
- To manually check for updates, go to **Settings > System > Software update**.
- Do not unplug the TV during a software update.




**Image 5.1:** An infographic highlighting key benefits of the Smart TV experience, including automatic software updates, simplified setup processes, and the option for private audio listening through a mobile device. These features contribute to user convenience and an enhanced viewing experience.

## 6. Troubleshooting

Before contacting customer support, try these common troubleshooting steps.

### 6.1 No Power

- Ensure the power cord is securely plugged into both the TV and a working electrical outlet.
- Check if the outlet is receiving power by plugging in another device.
- Try pressing the power button on the TV itself, if available, instead of the remote.

### 6.2 No Picture, But Sound is Present

- Verify that the correct input source is selected (e.g., HDMI 1, Antenna).

- Check all cable connections to external devices.
- Restart the TV and any connected devices.

### 6.3 No Sound, But Picture is Present

- Check the volume level and ensure the TV is not muted.
- If using external audio equipment (soundbar, receiver), ensure it is powered on and correctly configured.
- Check audio output settings in the TV's menu (**Settings > Audio**).

### 6.4 Network Connection Issues

- Ensure your Wi-Fi router is powered on and functioning correctly.
- Restart your router and modem.
- Go to **Settings > Network > Check connection** to diagnose the issue.
- If using a wired connection, ensure the Ethernet cable is securely connected.

## 7. Specifications

| | |
|---|---|
| **Brand** | JVC |
| **Model Number** | SI50UR |
| **Screen Size** | 50 Inches (127 cm) |
| **Display Technology** | LED |
| **Resolution** | 4K UHD (3840 x 2160 pixels) |
| **Refresh Rate** | 60 Hz |
| **Operating System** | Roku OS |
| **Special Features** | Smart TV, HDR10 |
| **Connectivity** | HDMI, Wi-Fi, USB, Ethernet |
| **Aspect Ratio** | 16:9 |
| **Audio Output Mode** | Surround Sound |
| **Mounting Type** | Tabletop Stand |
| **Product Dimensions (W x D x H)** | 111 cm x 8 cm x 63 cm |
| **Product Weight** | 12 kg |
| **Model Year** | 2021 |




**Image 7.1:** A detailed diagram illustrating the physical dimensions of the JVC 50-inch Smart TV, including width, height, and depth, both with and without the stand. This provides essential information for placement and installation.

## 8. Warranty and Support

### 8.1 Warranty Information

Your JVC SI50UR 50-inch 4K LED Smart TV comes with a manufacturer's warranty. Please refer to the included warranty card for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.
Extended warranty options may be available from your retailer.

### 8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact JVC customer support.

- Refer to the warranty card or JVC's official website for contact details.
- Have your TV's model number (SI50UR) and serial number ready when contacting support.