Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

STJOYOPY B187

Battling Top Burst B-187 Savior Valkyrie.Sh-7 Gyro Toys Instruction Manual

Model: B187 | Brand: STJOYOPY

Introduction

This manual provides essential information for the safe and effective use of your STJOYOPY Battling Top B187 high performance gyro. Please read this manual thoroughly before use and retain it for future reference.
The B187 Battling Top is designed for competitive play, offering high performance for users aged 8 years and up. It is a reassemblable gyro, providing an engaging experience for family and friends.

Safety Information

- **Age Recommendation:** This product is suitable for children aged 8 years and up. Keep out of reach of younger children due to small parts.
- **Choking Hazard:** Contains small parts. Not for children under 3 years.
- **Eye Protection:** Always use eye protection when playing with battling tops to prevent injury from ricocheting parts.
- **Play Area:** Use in an open, clear area, preferably a designated battling arena, to prevent damage to property or injury to bystanders.
- **Launcher Safety:** Never aim the launcher at people or animals. Ensure the top is securely attached to the launcher before pulling the rip cord.
- **Modification Warning:** Do not modify the battling top or its components. Unauthorized modifications may lead to injury or product malfunction.

Parts List

The STJOYOPY B187 Battling Top typically includes the following components:

- Energy Layer (Top part with design)
- Forge Disc (Metal weight ring)
- Performance Tip (Bottom part for spinning)
- Sticker Sheet (For customization)

Note: Launchers are not included with this product and must be purchased separately.



Image showing the individual components of the B187 Battling Top, including the energy layer, forge disc, performance tip, and a sheet of stickers for customization.

Setup

Follow these steps to assemble your B187 Battling Top:

1. **Attach the Performance Tip:** Align the tabs on the Performance Tip with the slots on the Forge Disc. Push and twist until it clicks securely into place.
2. **Attach the Forge Disc:** Align the tabs on the assembled Performance Tip and Forge Disc with the slots on the Energy Layer. Push and twist until it clicks securely into place.
3. **Apply Stickers (Optional):** Refer to the included sticker sheet for placement instructions to customize your battling top.



Image displaying a side view of the fully assembled B187 Battling Top, ready for use.



Image showing four different perspectives of the assembled B187 Battling Top, highlighting its design from various angles.

Operating Instructions

Once your B187 Battling Top is assembled, follow these steps to engage in battling:

1. **Prepare the Launcher:** Attach your assembled battling top to a compatible launcher (not included). Ensure it is securely locked in place.
2. **Choose Your Arena:** Select a suitable battling arena for play.
3. **Launch:** Hold the launcher firmly, aim it into the arena, and pull the rip cord with a swift motion to launch the battling top.
4. **Battle:** The battling tops will spin and collide within the arena. The last top spinning or the one that knocks out its opponent wins the round.

Your browser does not support the video tag.

Video demonstrating the launching and battling action of two battling tops within an arena. This short clip shows the tops spinning and

interacting during play.

Maintenance

To ensure the longevity and performance of your B187 Battling Top, follow these maintenance guidelines:

- **Cleaning:** Wipe the battling top with a soft, dry cloth after use to remove dust and debris. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the battling top in a cool, dry place away from direct sunlight and extreme temperatures. Keep it in its original packaging or a dedicated storage case to prevent damage.
- **Inspection:** Regularly inspect all components for signs of wear or damage. Replace any broken or worn parts immediately to maintain optimal performance and safety.
- **Avoid Water:** Do not submerge the battling top in water, as this can damage its internal mechanisms and affect its balance.

Troubleshooting

Problem	Possible Cause	Solution
Top doesn't spin well or stops quickly.	Improper assembly; Worn-out performance tip; Damaged launcher.	Ensure all parts are securely clicked into place. Check the performance tip for wear and replace if necessary. Try a different launcher.
Top breaks easily during battle.	Excessive force during launch; Product defect; Normal wear and tear from intense battles.	Avoid over-launching. Ensure play is within recommended guidelines. If breakage is unusual, contact customer support.
Stickers peel off.	Improper application; Exposure to moisture or extreme temperatures.	Ensure surfaces are clean and dry before applying stickers. Avoid prolonged exposure to water or heat.

Specifications

- **Model Number:** B187
- **Brand:** STJOYOPY
- **Recommended Age:** 8 years and up
- **Package Dimensions:** 2.28 x 2.24 x 2.2 inches
- **Item Weight:** 2.89 ounces
- **ASIN:** B09KY6G1M7

Warranty and Support

STJOYOPY is committed to providing a comprehensive after-sales service to ensure a more enjoyable experience for our customers.
For any questions, concerns, or issues regarding your B187 Battling Top, please contact STJOYOPY customer support through the retailer where the product was purchased. Please have your purchase details and product model number (B187) ready when contacting support.
While specific warranty details are not provided in this manual, please refer to the product listing or contact the seller for information on return policies and potential manufacturer defects.

© 2024 STJOYOPY. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09KY6G1M7

More documents and user manuals: **https://manuals.plus/**