HADEN 75095

HADEN Heritage 1.7 Liter Stainless Steel Electric Kettle

Instruction Manual

Brand: HADEN | Model: 75095

Introduction

This manual provides essential information for the safe and efficient operation of your HADEN Heritage 1.7 Liter Stainless Steel Electric Kettle. Please read all instructions carefully before first use and retain for future reference.

Image: HADEN Heritage Electric Kettle in Black & Chrome, showcasing its classic design.

The HADEN Heritage Electric Kettle is designed to elevate your kitchen experience with its blend of classic style and modern engineering. Key features include:

- **1.7-Liter (7-Cup) Capacity:** Ample capacity for boiling water for tea, coffee, or general kitchen use.
- **Modern Engineering:** Features a simple design, easy to use controls, and a 360-degree base for stability.
- **Safety Features:** Equipped with auto-shut-off and boil-dry protection for peace of mind.

- **Premium Construction:** Crafted with premium coated stainless steel housing.
- **Removable Filter:** Facilitates convenient cleaning and maintenance.

Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Do not immerse the kettle, power base, cord, or plug in water or other liquids.
- Do not place the kettle in a dishwasher.
- Ensure the kettle is placed on a stable, flat, heat-resistant surface.
- Do not operate the kettle if the cord or plug is damaged, or if the kettle malfunctions or has been damaged in any manner.
- The kettle is equipped with boil-dry protection, which automatically turns off the heating element if the kettle is empty.
- While the handle is designed for safe pouring, the exterior surfaces of the kettle may become hot during operation. Exercise caution to avoid contact with hot surfaces.
- Keep the appliance out of reach of children.

Setup and First Use

1. **Unpacking:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future storage or disposal.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the MAX fill line. Boil the water, then discard it. Repeat this process two to three times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, and stable surface near a power outlet. The 360-degree base allows the kettle to be placed in any direction.
4. **Power Connection:** Plug the power cord into a standard electrical outlet.

Image: Detailed view of the HADEN Heritage Electric Kettle, highlighting its removable filter, automatic shut-off, and 360-degree base.

Operating Instructions

1. **Filling the Kettle:** Remove the lid by pulling the ring on top. Fill the kettle with the desired amount of water. Do not fill below the MIN mark or above the MAX (1.7L) mark. The water gauge on the side allows for easy monitoring of the water level.
2. **Placing on Base:** Place the kettle firmly onto the 360-degree power base.
3. **Starting the Boil:** Push the power lever down. The indicator light will illuminate, signaling that the kettle is heating.
4. **Auto Shut-off:** The kettle will automatically turn off once the water has reached its boiling point. The indicator light will extinguish, and the power lever will return to its original position.
5. **Pouring:** Carefully lift the kettle from the base and pour the hot water. Always pour slowly and steadily to avoid splashing.

Image: Overview of the HADEN Heritage Electric Kettle, illustrating its 1.7-liter capacity, water gauge, indicator light, and 1500W power.

Care and Maintenance

Proper care ensures the longevity and performance of your kettle.

- **Exterior Cleaning:** Wipe the exterior of the kettle and the power base with a damp cloth or sponge and dry thoroughly. Do not use abrasive cleaners or scouring pads.
- **Interior Cleaning:** Wash the inside of the kettle with hot, soapy water and rinse thoroughly.
- **Removable Filter:** The kettle includes a removable filter for easy cleaning. Regularly remove and rinse the filter under running water to prevent scale buildup.
- **Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale, fill the kettle with a mixture of equal parts white vinegar and water. Let it soak for at least 30 minutes, then boil. Discard the solution and rinse thoroughly. Repeat if necessary.

Image: A hand demonstrating the removal of the filter from the HADEN kettle for cleaning.

Troubleshooting

Problem	Possible Cause	Solution
Kettle does not turn on.	Not properly plugged in; power lever not fully engaged; no water in kettle (boil-dry protection activated).	Ensure the power cord is securely plugged into a working outlet. Push the power lever down completely. If boil-dry protection activated, allow kettle to cool before refilling with water.
Water is not boiling.	Insufficient water; kettle not properly seated on base.	Ensure water level is above MIN mark. Re-seat the kettle firmly on the power base.
Kettle turns off prematurely.	Limescale buildup; boil-dry protection activated.	Descale the kettle as per maintenance instructions. If boil-dry protection activated, allow kettle to cool before refilling.
Exterior of kettle feels hot.	Normal operation.	This is normal for electric kettles. Always use the handle for pouring and avoid touching hot surfaces.

Specifications

Feature	Detail

Feature	Detail
Brand	HADEN
Model Name	Heritage (Item model number: 75095)
Color	Black & Chrome
Capacity	1.7 Liters (7-cup)
Product Dimensions	7"L x 9.5"W x 11.75"H
Item Weight	3 Pounds
Material Feature	Boil dry cut-off protection
Included Components	Kettle, User Manual, Extra Replacement Filter
UPC	017342750951
Country/Region Of Origin	China

Image: Diagram showing the dimensions of the HADEN Heritage Electric Kettle.

Warranty and Support

For detailed warranty information, please refer to the official user guide included with your product or visit the HADEN website.

A digital version of the User Guide is available for download: HADEN Heritage Electric Kettle User Guide (PDF)

For further assistance or technical support, please contact HADEN customer service.

© 2024 HADEN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question