Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DOMO DO9249G

DOMO DO9249G Contact Grill - Grill Genius User Manual

Model: DO9249G

Important Safety Instructions

Please read these instructions carefully before using the appliance and keep them for future reference. Incorrect use can lead to injury or damage.

- Always ensure the appliance is placed on a stable, heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Keep out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for anything other than its intended use.
- The appliance is not intended to be operated by means of an external timer or separate remote-control system.
- The temperature of accessible surfaces may be high when the appliance is operating.

Product Overview

The DOMO DO9249G Contact Grill is a versatile kitchen appliance designed for grilling various foods such as paninis, toasts, meat, fish, and vegetables. It features a floating lid for even grilling, adjustable temperature control, and non-stick plates for easy cleaning.



Figure 1: Front view of the DOMO DO9249G Contact Grill in its closed position, highlighting the 'Grill Genius' branding and the intuitive control panel with various cooking indicators.



Figure 2: Close-up front view of the DOMO DO9249G Contact Grill, focusing on the digital display and control knob. Indicators for pre-heating, cooking stages (rare, medium, well done), and food types are visible.



Figure 3: The DOMO DO9249G Contact Grill with its approximate dimensions indicated: 43cm length, 39cm width, and 23cm height. This image provides a clear understanding of the appliance's physical size.

Setup

1. **Unpacking:** Carefully remove the grill from its packaging. Retain the packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wipe the grilling plates with a damp cloth or sponge. Ensure they are completely dry before plugging in the appliance.
3. **Placement:** Place the grill on a flat, stable, and heat-resistant surface. Ensure there is adequate ventilation around the appliance. Do not place it near flammable materials.
4. **Drip Tray Installation:** Insert the removable drip tray into its designated slot at the front or side of the grill to collect excess fat and juices during cooking.



Figure 4: A detailed view of the removable drip tray, designed to collect grease and liquids, making cleaning easier.

5. **Power Connection:** Plug the power cord into a grounded electrical outlet. The appliance is now ready for use.

Operating Instructions

Preheating the Grill

1. Close the grill lid.
2. Plug the appliance into a power outlet. The power indicator light will illuminate.
3. Select the desired cooking program or temperature using the control knob. The "PRE-HEATING" indicator will light up.
4. Wait for the grill to reach the set temperature. The "PRE-HEATING" indicator will turn off, and the "START TO COOK" indicator will illuminate, signaling that the grill is ready for use.

Grilling Food

1. Once preheated, carefully open the grill lid using the cool-touch handle.

2. Place the food evenly on the lower grilling plate. The floating lid will automatically adjust to the thickness of the food, ensuring even contact and cooking.



Figure 5: A piece of meat being grilled on the DOMO DO9249G Contact Grill, demonstrating the floating lid's ability to accommodate different food thicknesses.

3. Close the lid. The cooking process will begin.
4. Monitor the cooking progress using the doneness indicators (Rare, Medium, Well Done) on the control panel, if applicable to your selected program.
5. For foods like vegetables or open-face grilling, the grill can be opened flat to create a larger grilling surface.



Figure 6: The DOMO DO9249G Contact Grill fully opened, showcasing its ability to function as an open grill, ideal for cooking a larger quantity of vegetables or other items.

6. Once cooking is complete, carefully remove the food using heat-resistant utensils. Avoid using metal utensils that could scratch the non-stick coating.
7. Unplug the appliance from the power outlet after use.

Specific Food Programs (if applicable)

The DOMO DO9249G features pre-set programs for various food types, indicated by icons on the control panel. Use the 'SELECT' knob to cycle through these options:

- **Panini/Toast:** Ideal for sandwiches and paninis.
- **Fish:** Optimized for grilling fish fillets.
- **Meat:** Suitable for steaks, burgers, and other meats.
- **Poultry:** For chicken and other poultry.
- **Vegetables:** Perfect for grilling a variety of vegetables.
- **Manual Mode (M):** Allows for custom temperature setting via the thermostat.



Figure 7: The control panel of the DOMO DO9249G Contact Grill, displaying various food icons (e.g., fish, meat, vegetables) and doneness indicators (Rare, Medium, Well Done), which guide the user during the cooking process.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your grill.

1. **Cool Down:** Always allow the grill to cool completely before cleaning.
2. **Unplug:** Ensure the appliance is unplugged from the power outlet.
3. **Remove Drip Tray:** Carefully slide out the drip tray and empty any collected grease or liquids. Wash the drip tray with warm, soapy water and rinse thoroughly.



Figure 8: A detailed view of the removable drip tray, which slides out for easy disposal of collected grease and liquids.

4. **Clean Grilling Plates:** The non-stick grilling plates can be wiped clean with a damp cloth or sponge. For stubborn residue, use a plastic scraper or a soft brush. Do not use abrasive cleaners or metal scouring pads, as these can damage the non-stick coating.



Figure 9: The DOMO DO9249G Contact Grill with its grilling plates detached, illustrating the ease of removal for thorough cleaning. The drip tray is also visible.

5. **Exterior Cleaning:** Wipe the exterior of the grill with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
6. **Storage:** Once clean and dry, the grill can be stored vertically to save space.

Troubleshooting

Problem	Possible Cause	Solution
Grill does not heat up.	Not plugged in; power outlet malfunction; appliance malfunction.	Ensure the grill is properly plugged into a working outlet. Check the circuit breaker. If problem persists, contact customer support.
Food is not cooking evenly.	Grill not preheated; food placed unevenly; too much food.	Allow the grill to fully preheat until the "START TO COOK" indicator lights up. Distribute food evenly on the plates. Do not overload the grill.
Smoke coming from the grill.	Excess grease/food residue; high fat content food.	Ensure the drip tray is empty and clean. Clean grilling plates thoroughly after each use. For high-fat foods, trim excess fat before grilling.

Problem	Possible Cause	Solution
Non-stick coating is peeling.	Use of metal utensils; abrasive cleaning.	Always use wooden, plastic, or silicone utensils. Clean with soft cloths/sponges only. This may indicate wear and tear over time.

Specifications

Model: DO9249G

Brand: DOMO

Product Dimensions: 32.1D x 38.2W x 18H cm

Color: Stainless Steel / Black

Special Feature: Non-stick coating

Power Source: Electric

Voltage: 220-240V ~ 50/60Hz (Typical for EU)

Warranty and Support

DOMO products are designed and manufactured to the highest quality standards. In the unlikely event of a problem with your product, please refer to the warranty conditions provided with your purchase documentation.
For technical support, spare parts, or warranty claims, please contact your local DOMO service center or the retailer where you purchased the appliance. Please have your model number (DO9249G) and proof of purchase ready.
You can also visit the official DOMO website for more information and contact details:www.domo-elektro.be

© 2024 DOMO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09LQN9YSN

More documents and user manuals: **https://manuals.plus/**