**ALLIMITY NS-RCFNA-21**

# ALLIMITY NS-RCFNA-21 Replacement Voice Remote Control User Manual

## Introduction

This manual provides instructions for the ALLIMITY NS-RCFNA-21 Replacement Voice Remote Control, designed for use with various Insignia Smart TV models. This remote offers voice control capabilities and dedicated shortcut buttons for popular streaming services, enhancing your television viewing experience.

## Setup

### 1. Battery Installation

- The remote requires 2 AAA batteries (not included).
- Locate the battery compartment on the back of the remote.
- Open the compartment cover.
- Insert the batteries, ensuring correct polarity (+ and -).
- Close the battery compartment cover.

### 2. Initial Pairing with Your TV

For optimal functionality, the remote must be paired with your Insignia Smart TV. Follow these steps:

1. Ensure your TV is powered on.
2. Press and hold the **Home** button on the remote for approximately 30 seconds.
3. Release the **Home** button.
4. Wait for approximately 60 seconds. The remote will enter pairing mode.
5. Your TV should display a "Pairing success" message.
6. If pairing is unsuccessful, proceed to the Troubleshooting section.

## Operating Instructions

### Remote Control Layout

The ALLIMITY NS-RCFNA-21 remote features a standard layout with dedicated buttons for various functions.




*Image: Front view of the ALLIMITY NS-RCFNA-21 Replacement Voice Remote Control. It is a black remote with various buttons including power, voice control, navigation, playback controls, volume, mute, settings, and dedicated app buttons for Prime Video,*

*Netflix, IMDb TV, and Hulu.*

### Button Functions

| Button | Function |
|---|---|
| **Power** | Turns the TV on or off. |
| **Voice Control (Microphone icon)** | Activates voice commands for searching or controlling the TV. |
| **Navigation Pad (Circular)** | Used to navigate menus and select items. Press the center button to confirm selections. |
| **Back (Curved arrow)** | Returns to the previous screen or menu. |
| **Home (House icon)** | Returns to the TV's home screen. |
| **Menu (Three horizontal lines)** | Opens the TV's menu or options. |
| **Rewind, Play/Pause, Fast Forward** | Controls media playback. |
| **Volume Up (+)** | Increases the TV volume. |
| **Channel Up (Triangle pointing up)** | Changes to the next channel. |
| **Volume Down (-)** | Decreases the TV volume. |
| **Channel Down (Triangle pointing down)** | Changes to the previous channel. |
| **Mute (Speaker with X)** | Mutes or unmutes the TV audio. |
| **Settings (Gear icon)** | Accesses TV settings. |
| **Input (Rectangle with arrow)** | Changes the TV input source. |
| **Prime Video, Netflix, IMDb TV, Hulu** | Dedicated shortcut buttons to launch these streaming applications directly. |

## TROUBLESHOOTING

### Remote Not Pairing or Responding

If the remote does not pair successfully or stops responding, follow these steps:

1. **Power Cycle Devices:** Unplug the power cord from your Insignia Smart TV. Remove the batteries from the remote control. Wait for at least 30 seconds. Plug the TV power cord back in. Reinsert the batteries into the remote, ensuring correct polarity.
2. **Re-attempt Pairing:** Once the TV has fully restarted, press and hold the**Home** button on the remote for approximately 15 seconds. Release the **Home** button. Wait for approximately 60 seconds for the remote to enter pairing mode and attempt to connect.
3. **Check Battery Level:** Ensure the batteries are fresh and correctly inserted. Low batteries can cause intermittent functionality.
4. **Obstruction Check:** Ensure there are no obstructions between the remote and the TV.
5. **Contact Support:** If issues persist, refer to the Support section for further assistance.

## Specifications

- **Model:** NS-RCFNA-21
- **Brand:** ALLIMITY
- **Compatible Devices:** Insignia Smart TVs (F20, F30, F50 Series, and other compatible models)
- **Power Source:** 2 x AAA Batteries (not included)
- **Dimensions:** Approximately 6 x 2 x 0.6 inches
- **Item Weight:** Approximately 1.44 ounces
- **Special Feature:** Voice Control, Dedicated App Buttons

## Warranty and Support

For warranty information or technical support regarding your ALLIMITY NS-RCFNA-21 Replacement Voice Remote Control, please refer to the documentation provided with your purchase or contact the manufacturer directly. You may also visit the ALLIMITY support website for additional assistance.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question