GRIFEMA GA1002

GRIFEMA GA1002 4-Digit Long Shackle Combination Padlock User Manual

Model: GA1002

Introduction

Thank you for choosing the GRIFEMA GA1002 4-Digit Long Shackle Combination Padlock. This manual provides essential instructions for setting your personal combination, operating the padlock, and maintaining its performance. Please read these instructions carefully before first use and retain them for future reference.



Image: Two GRIFEMA GA1002 4-Digit Long Shackle Combination Padlocks, black in color, with their default combination visible on the dials.

Product Features

- **High Security:** 4-digit combination offers 10,000 unique combinations for enhanced security.
- **Robust Construction:** Made from durable zinc alloy body and hardened steel shackles, designed for weather resistance and anti-cut properties.
- **Easy Readability:** Features a side window design and large numbers for clear and easy reading of the combination.
- **Versatile Application:** Suitable for various indoor and outdoor uses, including gym lockers, school lockers, cabinets, toolboxes, gates, garages, sheds, fences, and suitcases.



Image: A detailed view of the GRIFEMA GA1002 padlock, illustrating its strong, chrome-plated steel shackle, high-quality zinc alloy body, and the convenient side window for reading the combination dials.

Setting Your Combination Code

Your GRIFEMA GA1002 padlock comes with a factory default combination of **0-0-0-0**. Follow these steps to set your personalized code:

1. Ensure the padlock is open and set to the default code **0-0-0-0**. Pull up the shackle.
2. Rotate the shackle 90 degrees counter-clockwise (or clockwise, depending on the model) until it aligns with the code setting gap on the padlock body.
3. Press the shackle down firmly until the tiny pin is fully inside the gap.
4. While holding the shackle down, rotate it another 90 degrees in the same direction. The shackle should now be in a horizontal position, locked down.
5. With the shackle held in this position, scroll the number dials to set your desired 4-digit combination. Choose a memorable code.

6. Once your new code is set, turn the shackle back 90 degrees to its original upright position. Release the shackle; it should pop up.
7. Scramble the dials to lock the padlock. Test your new combination to ensure it opens correctly before securing any valuables.

Important: Please remember your new combination. There is no master key or override function to reset the code if forgotten.



Image: Visual instructions detailing the six steps to set a new combination code on the GRIFEMA GA1002 padlock, showing shackle rotation and dial adjustment.

Operating the Padlock

- **To Open:** Align the dials to your set 4-digit combination. Pull up the shackle to open the padlock.
- **To Close:** With the shackle open, insert it into the padlock body. Scramble the dials to a random sequence to secure the padlock.



Image: Four examples demonstrating the versatile use of the GRIFEMA GA1002 padlock, securing items such as a gate chain, a fence, a gym locker, and a bicycle.

Maintenance

- **Cleaning:** Wipe the padlock with a soft, damp cloth to remove dirt and grime. Avoid harsh chemicals.
- **Lubrication:** For smooth operation, especially in outdoor environments, occasionally apply a small amount of graphite lubricant or silicone spray to the shackle mechanism and dials.
- **Storage:** Store the padlock in a dry place when not in use for extended periods to prevent corrosion.

Troubleshooting

- **Padlock will not open:**
  - Ensure the correct combination is entered. Double-check each digit.
  - Make sure the dials are perfectly aligned with the indicator marks.

- If the padlock feels stiff, apply a lubricant as described in the Maintenance section.

- **Cannot set a new combination:**
  - Verify that the shackle is fully pressed down and rotated correctly into the setting position.
  - Ensure the padlock was initially opened with the current (default or previous) combination.

- **Forgotten Combination:**
  - Unfortunately, without the correct combination, the padlock cannot be opened or reset. It is crucial to record your combination in a secure, memorable location.

Specifications

Brand	GRIFEMA
Model Name	GA1002
Lock Type	4-Digit Combination Lock
Material	Zinc Alloy Body, Hardened Steel Shackle
Color	Black
Special Feature	Passcode Unlock, Weatherproof
Item Weight	120 Grams (approx. 4.2 ounces)
Product Dimensions (Approx.)	Total Height: 116mm (4.57 in), Body Width: 44mm (1.73 in), Shackle Height: 61mm (2.4 in)



Image: Technical drawing showing key dimensions of the GRIFEMA GA1002 padlock, including total height (116mm / 4.57 inches), body width (44mm / 1.73 inches), and internal shackle height (61mm / 2.4 inches).

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact GRIFEMA customer service through their official website or the retailer from whom you purchased the product. Please have your model number (GA1002) and purchase details ready when contacting support.

© 2023 GRIFEMA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question