Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Balsam Hill 2809421

Balsam Hill 6.5ft Pre-Lit Classic Blue Spruce Artificial Christmas Tree Instruction Manual

Model: 2809421

Brand: Balsam Hill

Introduction

Thank you for choosing the Balsam Hill 6.5ft Pre-Lit Classic Blue Spruce Artificial Christmas Tree. This manual provides essential information for the safe and proper assembly, operation, maintenance, and storage of your new tree. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The Balsam Hill 6.5ft Pre-Lit Classic Blue Spruce Artificial Christmas Tree, fully assembled and lit.

Safety Information

- Always unplug the tree from the power outlet before assembly, disassembly, or maintenance.
- Do not overload electrical outlets. Ensure the tree is plugged into a suitable power source.
- Keep children and pets away from the tree during assembly and disassembly.
- Do not place the tree near heat sources or open flames.
- Use only the provided components and replacement parts.
- If any part of the tree or lighting system is damaged, discontinue use and contact customer support.

What's in the Box

Your Balsam Hill Christmas tree package includes the following items:

- Tree sections (typically 3 sections for a 6.5ft tree)
- Premium Christmas tree stand with scratch-proof feet
- Christmas tree storage bag
- Cotton fluffing gloves
- On/Off foot pedal (for pre-lit trees)
- Extra bulbs and fuses



Image: A close-up of the tree base and included accessories, illustrating the 'What's in the Box' contents.

Setup

Follow these steps for easy assembly of your Balsam Hill Christmas tree:

1. **Assemble the Stand:** Unfold the tree stand into an X shape and ensure it is stable. Insert the bottom tree section

(Section 1) into the stand. Tighten the screws on the stand to secure the tree section.

2. **Connect Sections:** Insert the middle tree section (Section 2) into the top of Section 1. The innovative Easy Plug Technology allows lights to seamlessly connect through the trunk, eliminating the need to manually connect light strands between sections.
3. **Add Top Section:** Place the top tree section (Section 3) onto Section 2.
4. **Fluff the Branches:** Starting from the bottom section and working your way up, gently spread and shape each branch. Wear the included protective gloves to protect your hands. Meticulous fluffing is crucial to achieve the tree's full and realistic appearance. This process may take over an hour for the first-time setup.
5. **Plug In:** Once all sections are assembled and fluffed, plug the tree's single cord into a wall outlet. Use the convenient foot pedal to control the lights.



Image: A person connecting tree sections, demonstrating the Easy Plug Technology for simplified setup.

Image: A visual guide detailing the steps for easy assembly and shaping of the tree branches.

Operating

Your Balsam Hill Pre-Lit Classic Blue Spruce tree features 700 clear incandescent lights, hand-strung for even coverage and a timeless warm glow. The Easy Plug Technology simplifies operation by requiring only one wall plug for the entire tree.

- **Power On/Off:** Use the included foot pedal to easily turn the tree lights on or off.
- **Light Type:** This model uses clear incandescent lights, designed to stay lit for up to 3,000 hours.



Image: A detailed view of the hand-strung clear incandescent lights integrated into the tree foliage.

Maintenance

- **Regular Fluffing:** Periodically adjust the branches to maintain the desired fullness and shape.
- **Light Replacement:** If a light bulb burns out, replace it with one of the included extra bulbs. Refer to the diagram on

the light strand for proper replacement.

- **Fuse Replacement:** If an entire section of lights goes out, check the fuses in the plug. Replace with the included spare fuses if necessary.
- **Storage:** At the end of the season, carefully compress the branches and disassemble the tree sections. Store the tree in the provided storage bag in a cool, dry location to protect it from dust and damage.

Troubleshooting

Lights Not Working

- **Check Power Connection:** Ensure the tree is securely plugged into a working electrical outlet and that the foot pedal is engaged.
- **Verify Section Connections:** For Easy Plug trees, ensure all tree sections are correctly seated, allowing the internal electrical connections to function.
- **Inspect Bulbs:** Check for any loose, broken, or missing bulbs. Replace any faulty bulbs with the spares provided. Even one faulty bulb can affect a section of lights.
- **Examine Fuses:** Locate the fuse compartment in the plug and check if any fuses are blown. Replace them with the extra fuses included in your package.
- **Contact Support:** If troubleshooting steps do not resolve the issue, contact Balsam Hill customer support for further assistance.

Specifications

Feature	Detail
Brand	Balsam Hill
Product Dimensions	53"D x 53"W x 78"H
Color	Clear Incandescent
Material	Metal, Polyvinyl Chloride
Item Weight	40 Pounds
Item Package Quantity	1
Recommended Uses	Christmas Tree
Special Feature	One Plug, Prelit Clear Incandescent
Tree Type	Spruce
Base Type	Stand
Built-in Light	Yes
Tip Count	2144
Light Color	Clear

Included Components	Christmas Tree Stand, Christmas Tree Storage Bag, Cotton Fluffing Gloves, On/Off Foot Pedal
UPC	196041205631
Item Model Number	2809421

Size Guide

Generally speaking, you want 6 inches between the ceiling and the top of your tree or tree topper, and your space should have 12 inches of clearance beyond the width of your tree.

Choosing the right height

All heights include tree stands.

UNDER 6'
For cozy rooms and secondary spaces (kitchens, dens).

6' - 6.5'
For homes with low to average ceiling height.

7' - 7.5'
For homes with 8' to 9' ceiling heights.

8' - 9'
For rooms with 10' to 11' ceiling heights.

10' - 14'
For 2-story living rooms and other rooms with very high ceiling heights, as well as commercial spaces.

15' - 30'
For churches, malls, office buildings, and other large public spaces.

Choosing the right shape and style

REGULAR (FULL)
Lush profiles and sturdy branches make these our most popular trees.

SLIM
Our most slender profile for tight spaces, corners, and foyers.

WIDE
Fill up a room and have plenty of space for ornaments and presents beneath.

SPARSE
Branches spaced so your ornaments become the star of the show.

FLATBACK
Space-savers that appear full from the front, but rest flat against a wall or corner.

6.5' CLASSIC BLUE SPRUCE® TREE: 78" X 54" (INCLUDES TREE STAND) | FULL

Image: A size guide illustrating various tree heights and shapes to help choose the right fit for your space.

Warranty & Support

Balsam Hill offers a 3-year warranty on its products. For warranty claims, technical support, or any questions regarding your tree, please contact Balsam Hill customer service directly. Keep your purchase receipt or Amazon invoice as proof of purchase.
For more information, visit the official Balsam Hill website or contact their customer support team.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09M28Q9W6

More documents and user manuals: **https://manuals.plus/**