MEIZE K110B

MEIZE 10.1-inch Android Tablet

User Manual

Introduction

This user manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your MEIZE 10.1-inch Android Tablet. Please read this manual carefully before using your device to ensure optimal performance and longevity.

Package Contents

Upon opening the package, verify that all items listed below are present:

- 1 x MEIZE 10.1 inch Tablet
- 1 x Keyboard
- 1 x Mouse
- 1 x Stylus
- 1 x Protective Case
- 1 x Protective Film (pre-applied or separate)
- 1 x USB Charger
- 1 x USB-C Cable
- 1 x OTG Cable
- 1 x User Manual (this document)



Figure 1: MEIZE Tablet and included accessories.

Setup Guide

1. Initial Charging

Before first use, fully charge your tablet using the provided USB charger and USB-C cable. Connect the USB-C end to the tablet's charging port and the USB charger to a power outlet. The charging indicator light will illuminate.

2. Power On/Off

- **To Power On:** Press and hold the Power button on the side of the tablet until the MEIZE logo appears.
- **To Power Off:** Press and hold the Power button, then select "Power off" from the options that appear on the screen.

3. Keyboard Connection (Bluetooth)

The included keyboard connects via Bluetooth. Ensure the keyboard is charged. Turn on the keyboard using its power switch. On your tablet, navigate to **Settings** > **Connected devices** > **Pair new device**. Select the keyboard (e.g., "Bluetooth 3.0 Keyboard") from the list of available devices and follow the on-screen prompts to complete pairing.



Figure 2: Bluetooth Keyboard Connection.

4. Mouse Connection (USB Dongle)

The included mouse connects via a USB dongle. Insert the USB dongle into the provided OTG cable, then connect the OTG cable's USB-C end to your tablet's USB-C port. The tablet will automatically recognize the mouse. Ensure the mouse has batteries installed (not included).

5. SIM Card and MicroSD Card Installation

Your tablet supports dual SIM cards for 4G network connectivity and a MicroSD card for expandable storage up to 1TB. Locate the card slot on the side of the tablet. Gently open the shell around the Type-C port. Insert the MicroSD card and/or SIM cards into their respective slots as indicated by the diagram, ensuring correct orientation. Close the shell securely. Restart your tablet after installation for changes to take effect.



Figure 3: SIM and MicroSD Card Installation.

Operating Your Tablet

1. Basic Navigation

The MEIZE tablet features a responsive 10.1-inch IPS HD touchscreen (1280x800 resolution). Navigate by tapping, swiping, pinching, and spreading fingers on the screen. The Android 10 operating system provides an intuitive user interface.



Figure 4: Android System Interface.

2. Connecting to Wi-Fi

To connect to a Wi-Fi network, go to**Settings** > **Network & internet** > **Wi-Fi**. Turn on Wi-Fi, then select your desired network from the list and enter the password if prompted.

3. Using the Cameras

The tablet is equipped with a 13MP rear camera and a 5MP front camera. Open the Camera app to capture photos and videos. Tap the screen to focus and press the shutter button to take a picture.



Figure 5: Tablet Camera Functionality.

4. Storage Management

The tablet comes with 64GB of internal storage (ROM) and supports expansion up to 1TB via a MicroSD card. To manage your storage, go to **Settings** > **Storage**. You can view used space and free up storage.

5. App Installation

As a GMS certified device, you can download and install applications from the Google Play Store. Tap the **Play Store** icon on your home screen or app drawer, search for your desired app, and tap **Install**.



Figure 6: App Ecosystem.

6. GPS Functionality

The tablet supports GPS, allowing for navigation and location-based services. Ensure location services are enabled in your tablet's settings to utilize GPS-enabled applications.



Figure 7: GPS Navigation.

Maintenance

1. Cleaning Your Tablet

Use a soft, lint-free cloth to clean the screen and body of your tablet. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaner. Avoid using harsh chemicals or abrasive materials.

2. Battery Care

The tablet is equipped with a 6000mAh battery. To prolong battery life, avoid extreme temperatures, do not let the battery fully drain frequently, and use the provided charger. Unplug the charger once the battery is full.

3. Software Updates

Periodically check for system updates to ensure your tablet has the latest features and security patches. Go to **Settings** >

System > **System update**.

Troubleshooting

Problem	Possible Cause / Solution
Tablet does not power on.	Battery may be depleted. Connect to charger and allow it to charge for at least 30 minutes before attempting to power on again.
Mouse is not working.	1. Ensure batteries are correctly installed in the mouse. 2. Verify the USB dongle is securely connected to the tablet via the provided OTG cable. The tablet's USB-C port requires the OTG cable to connect the USB-A mouse dongle. 3. Try restarting the tablet.
Keyboard is not connecting via Bluetooth.	1. Ensure the keyboard is charged and powered on. 2. Make sure Bluetooth is enabled on the tablet (**Settings** > **Connected devices** > **Bluetooth**). 3. Unpair and re-pair the keyboard if it was previously connected.
Wi-Fi connection issues.	1. Check if Wi-Fi is enabled on the tablet. 2. Verify the Wi-Fi password is correct. 3. Restart your Wi-Fi router. 4. Forget the network and reconnect.
Tablet is slow or unresponsive.	1. Close unnecessary background applications. 2. Clear cache of frequently used apps. 3. Restart the tablet. 4. If issues persist, consider a factory reset (backup data first).

Specifications

Feature	Detail
Brand	MEIZE
Model Name	K110B (Series k118)
Operating System	Android 10 (Some images suggest Android 11.0)
Screen Size	10.1 Inches
Screen Resolution	1280x800 IPS HD
Processor	Octa-Core (2.4 GHz)
RAM	4 GB
Internal Storage (ROM)	64 GB

Feature	Detail
Expandable Storage	Up to 1 TB (via MicroSD card)
Rear Camera	13 MP
Front Camera	5 MP
Wireless Type	802.11a/b/g/n/ac (2.4GHz Wi-Fi)
Bluetooth	BT5.0
Battery Capacity	6000mAh
Average Battery Life	13 Hours (usage dependent)
Charging Port	USB-C
Dimensions (LxWxH)	9.76 x 6.57 x 0.2 inches
Weight	0.106 ounces
Color	Black
GMS Certified	Yes



Figure 8: Key Features and Specifications.

Warranty and Support

MEIZE has over 10 years of experience in manufacturing and selling tablet PCs and maintains a professional after-sales service team. If you encounter any problems during use, please contact MEIZE customer support immediately for assistance. They are committed to resolving your issues as quickly as possible.
For support, please refer to the contact information provided on the MEIZE official website or your purchase documentation.

© 2025 MEIZE. All rights reserved.