LifePro LP-PWRNRN-BLU

LifePro PawRunner Dog Treadmill User Manual

Model: LP-PWRNRN-BLU

Introduction

The LifePro PawRunner Dog Treadmill is designed to provide a convenient and effective way for small and medium-sized dogs to exercise indoors. This compact and durable pacer treadmill helps improve your pet's fitness, circulation, and overall health, especially when outdoor conditions are not ideal.

Safety Information

Prioritizing your pet's safety is paramount. The PawRunner treadmill incorporates several features to ensure a secure exercise environment:

- **Safety Key:** A magnetic safety key is included. The treadmill will not operate without the safety key properly inserted. In case of an emergency, pulling the safety key will immediately stop the treadmill.
- **Emergency Stop Button:** An easily accessible emergency stop button provides an additional layer of safety, allowing for immediate cessation of the treadmill belt.
- **Weight Capacity:** This treadmill is designed for small and medium dogs only, with a maximum recommended pet weight of 130 lbs. Do not exceed this weight limit.
- **Quiet Operation:** The ultra-quiet motor is designed to minimize sounds and vibrations, creating a comfortable experience for your dog and reducing potential anxiety.

Setup and Assembly

The PawRunner treadmill is designed for quick and easy assembly, typically taking around 10 minutes. Refer to the included User Manual for detailed step-by-step instructions and diagrams.

Included Components:

- Power Cord
- Remote Control
- Safety Key

- Tool Kit
- Bottle of Maintenance Oil
- Treadmill Base Frame
- 2 x Base Frame End Caps
- Crossbar
- 10 x Velcro Strips
- Left Sidebar
- Right Sidebar
- 2 x Left Fabric Side Panel
- 2 x Right Fabric Side Panel
- Console & Adjustment Post
- T-Knob
- T-Knob Post
- 6 x Socket Head Screws, size M6×6mm
- User Manual (this document)



Image: The PawRunner Dog Treadmill with key dimensions: 48 inches deep, 22.8 inches wide, and 42 inches high. It also highlights the speed range (0.5-7.5 mph), 12 preset programs, 3 countdown modes, and 3 levels of manual incline control.

Operating Instructions

Control Console and Remote:

The treadmill features an adjustable control console and comes with a remote control for convenient operation.




Image: Close-up of the PawRunner treadmill's control panel, showing the digital display, speed adjustment buttons, power button, mode button, and magnetic safety key port. Numbered labels indicate: 1) 12 Preset Exercise Programs, 2) Active Mode Display Indication LED, 3) Adjustable Speeds, 4) Adjustable Control Console, 5) Power Button, 6) Mode Button, 7) Magnetic Safety Key Port.




Image: A collage showing various features of the PawRunner treadmill. Top left shows blue and black side panels. Top right shows the control panel with "No Beeping" text. Bottom left shows the remote control. Bottom right shows the wheels for easy transportation.

Starting an Exercise Session:

1. Ensure your pet is safely positioned on the treadmill belt and ready to begin.
2. For training or to keep your dog centered, attach their leash to the top bar of the treadmill.
3. Insert the magnetic safety key into its port on the console.
4. Press the Power Button to turn on the treadmill.
5. Use the speed adjustment controls on the console or remote to set the desired speed (ranging from 0.5 to 7.5 mph).
6. Select from 12 preset exercise programs or use the manual mode.
7. Monitor your pet throughout the session.

Adjusting Incline:

The PawRunner features manual incline control with 3 levels. To adjust the incline, you will need to manually set the incline level at the base of the treadmill before starting your pet's exercise session. Refer to the detailed instructions in the

main user manual for safe adjustment.



Image: A dog on the PawRunner treadmill with a person sitting nearby. Text overlays describe the usage: "Ensure your pet is on the treadmill & ready to go", "For training your dog, attach the leash to the top bar", and "Hit the power button & let your dog get fit & healthy".

Maintenance

Regular maintenance ensures the longevity and optimal performance of your PawRunner Dog Treadmill. A bottle of maintenance oil is included with your purchase.

- **Lubrication:** Periodically lubricate the running belt according to the instructions in the main user manual. This typically involves applying the provided maintenance oil under the belt to reduce friction.
- **Cleaning:** Keep the treadmill clean from pet hair, dust, and debris. Wipe down surfaces with a damp cloth.
- **Belt Adjustment:** Check the tension and alignment of the running belt regularly. Adjust as needed to prevent slipping or excessive wear.
- **Storage:** When not in use, store the treadmill in a dry, safe place. The integrated wheels allow for easy

transportation.

Troubleshooting

This section provides general guidance for common issues. For detailed troubleshooting steps, please refer to the comprehensive user manual provided with your product or contact LifePro customer support.

- **Treadmill Not Turning On:**
  - Ensure the power cord is securely plugged into a working outlet and the treadmill.
  - Verify the magnetic safety key is correctly inserted into its port on the console.
  - Check the main power switch on the treadmill (if applicable).
- **Belt Slipping or Sticking:**
  - The running belt may require lubrication. Apply maintenance oil as per the instructions in the main manual.
  - The belt tension might be too loose. Adjust the belt tension according to the main manual.
- **Unusual Noises:**
  - Ensure the treadmill is on a flat, stable surface.
  - Check for any loose components or debris under the belt.
  - If the noise persists, contact customer support.
- **Remote Control Not Responding:**
  - Check and replace the remote control batteries if necessary.
  - Ensure there are no obstructions between the remote and the treadmill's receiver.

Specifications

Feature	Detail
Brand	LifePro
Model Name	PawRunner
Product Dimensions (LxWxH)	48"D x 22.8"W x 42"H
Item Weight	47 Pounds
Material	Alloy Steel
Maximum Speed	7.5 Miles per Hour
Minimum Speed	0.5 Miles per Hour
Maximum Weight Recommendation	130 Pounds
Maximum Horsepower	0.5 Horsepower
Maximum Incline Percentage	10% (Manual Incline, 3 levels)
Number of Programs	12 Preset Programs
Display Type	LCD

Power Source	Corded Electric
Input Power	1000 Watts
Assembly Required	Yes
UPC	810090931425

Warranty and Support

LifePro offers **Lifetime Customer Support** for the PawRunner Dog Treadmill. If you encounter any issues, have questions, or require assistance, please contact LifePro customer service. Refer to the contact information provided in your product packaging or on the official LifePro website.

© 2024 LifePro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question