Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

STAKMANN 8054143010664

STAKMANN Ceramic Electric Wall-Mounted Fan Heater User Manual

Model: 8054143010664

1. Important Safety Instructions

Please read this manual carefully before using the appliance and keep it for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not cover the heater to avoid overheating.
- Do not use this heater in the immediate vicinity of a bath, shower, or swimming pool.
- Keep flammable materials (furniture, curtains, paper, clothing, etc.) at least 1 meter (3 feet) from the front, sides, and rear of the heater.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions, has been dropped or damaged in any manner.
- Ensure the voltage indicated on the rating label corresponds to the mains voltage in your home.
- The heater is equipped with an overheating protection device that automatically switches off the appliance in case of overheating.

2. Product Overview

The STAKMANN Ceramic Electric Wall-Mounted Fan Heater is designed to provide instant and efficient heating for indoor spaces. Its sleek design integrates seamlessly into various room aesthetics.



Figure 2.1: Front view of the STAKMANN Ceramic Electric Wall-Mounted Fan Heater.

Key Features:

- Wall-mounted design for space-saving installation.
- Ceramic heating elements for rapid and efficient heat.
- Two selectable power levels: 1000W and 2000W.
- Integrated LED display for easy monitoring.
- 24-hour timer function for automatic operation.
- Fan function with options for warm and hot air.
- Remote control for convenient operation.
- Overheating protection for enhanced safety.

3. Package Contents

Upon unpacking, please ensure all items are present and undamaged:

- STAKMANN Ceramic Electric Wall-Mounted Fan Heater
- Remote Control
- Mounting Hardware (screws, wall plugs)
- User Manual (this document)

4. Setup and Installation

This heater is designed for wall mounting. Choose a suitable location away from water sources, flammable materials, and direct sunlight. Ensure there is adequate clearance around the unit for proper air circulation.

4.1 Mounting the Heater

1. Select a sturdy wall surface capable of supporting the heater's weight.
2. Mark the desired mounting points on the wall using the provided template or by measuring the distance between the mounting holes on the back of the heater.
3. Drill holes at the marked points. Insert wall plugs if necessary.
4. Secure the mounting bracket (if separate) or the heater directly to the wall using the provided screws. Ensure it is level and firmly attached.
5. Once mounted, plug the heater into a suitable electrical outlet.



Figure 4.1: Example of the heater mounted on a wall.

5. Operating Instructions

The heater can be operated using the control panel on the unit or the included remote control.

5.1 Control Panel



Figure 5.1: Heater control panel.

- **Power Button ( ):** Turns the heater ON/OFF.
- **MODE Button:** Cycles through heating modes (e.g., Low Heat, High Heat, Fan Only).
- **TIMER Button:** Activates and adjusts the timer function.
- **RECEIVER Button:** For remote control pairing or specific functions (refer to remote section).
- **LED Display:** Shows current settings, temperature, or timer status.

5.2 Remote Control



Figure 5.2: Remote control.

- **Power Button ( ):** Turns the heater ON/OFF.
- **Mode:** Selects heating modes (1000W, 2000W, Fan).
- **AUTO:** Activates automatic temperature control (if available).
- **W-Timer:** Sets the timer for automatic shutdown (up to 7.5 hours).
- **+/- Buttons:** Adjusts temperature or timer settings.
- **Set:** Confirms settings.
- **24H:** Activates the 24-hour timer function.
- **LOCK:** Locks the control panel to prevent accidental changes.
- **Delay:** May refer to a delayed start function (consult specific model features).

5.3 Setting the Timer

The heater features a timer function for automatic shutdown up to 7.5 hours, and a 24-hour timer for scheduled operation.

1. Press the **TIMER** button on the control panel or the**W-Timer** / **24H** button on the remote control.
2. Use the **+/-** buttons to adjust the desired operating duration or scheduled time.
3. Press **Set** on the remote or wait a few seconds for the setting to be confirmed.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your heater. Always unplug the heater from the power outlet before cleaning.

- **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Air Inlet/Outlet:** Periodically clean the air inlet and outlet grilles with a vacuum cleaner or a soft brush to remove dust and debris.
- **Storage:** If storing the heater for an extended period, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging.

Do not immerse the heater in water or any other liquid.

7. Troubleshooting

If you encounter issues with your heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply, power switch off, overheating protection activated.	Check power cord connection and wall outlet. Ensure the main power switch is ON. Allow the unit to cool down if overheating protection was triggered.
No heat output.	Fan-only mode selected, low power setting, thermostat setting too low.	Select a heating mode (1000W or 2000W). Increase the thermostat setting if applicable.
Remote control not working.	Dead batteries, obstruction, out of range.	Replace batteries. Remove any obstructions between the remote and the heater. Ensure you are within effective range.
Unusual noise or smell.	Dust accumulation, foreign object inside.	Unplug immediately. Clean air inlets/outlets. If the problem persists, contact customer support.

If the problem persists after trying these solutions, please contact STAKMANN customer support.

8. Specifications

Feature	Detail
Brand	STAKMANN
Model Number	8054143010664
Type	Ceramic Electric Wall-Mounted Fan Heater
Color	White

Feature	Detail
Power Levels	1000W / 2000W
Voltage	240 Volt
Heating Method	Forced Air
Special Features	Remote Control, LED Display, 24H Timer, Fan Function, Overheating Protection
Dimensions (D x W x H)	11.5 cm x 19 cm x 50.5 cm (approx. 4.5 x 7.5 x 19.9 inches)
Item Weight	4 Kilograms (approx. 8.8 lbs)
Indoor/Outdoor Use	Indoor

9. Warranty and Support

This STAKMANN product is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact your retailer.

For technical support, troubleshooting assistance, or spare parts, please contact STAKMANN customer service through their official website or the contact information provided by your retailer.

Manufacturer: Stakmann

© 2023 STAKMANN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09M4D5K2F

More documents and user manuals: **https://manuals.plus/**