Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 9023

Ariete Polar 14 Portable Air Conditioner User Manual

Model: 9023

1. Introduction

Thank you for choosing the Ariete Polar 14 Portable Air Conditioner. This appliance is designed to provide efficient cooling, heating, and dehumidification for your indoor spaces. With its portable design and smart features, it offers comfort and convenience. Please read this manual thoroughly before operating the unit to ensure proper use, maintenance, and safety.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- This appliance is for indoor use only.
- Do not operate the unit with a damaged cord or plug.
- Ensure the power supply matches the voltage specified on the rating label.
- Keep the unit away from heat sources and direct sunlight.
- Do not block air inlets or outlets.
- Always unplug the unit before cleaning or servicing.
- Do not use the unit in wet or damp environments.
- Keep children and pets away from the unit during operation.

3. Product Overview



Figure 3.1: Front view of the Ariete Polar 14 Portable Air Conditioner with the exhaust hose visible.



Figure 3.2: Overview of the Ariete Polar 14, highlighting its key features: cooling, heating, dehumidifying, full control remote, and digital touch display.



Figure 3.3: Detailed view of the digital control panel on the top of the Ariete Polar 14, showing temperature display, mode indicators, and control buttons.



Figure 3.4: The remote control for the Ariete Polar 14, featuring buttons for power, mode selection, temperature adjustment, fan speed, and timer.

4. Setup

4.1 Unpacking

- Carefully remove the air conditioner from its packaging.
- Check for any shipping damage. If damaged, do not operate the unit and contact your retailer.
- Retain the original packaging for future storage or transport.

4.2 Positioning the Unit

- Place the unit on a firm, level surface in a room that requires cooling, heating, or dehumidification.
- Ensure there is at least 20 cm (8 inches) of space around the unit for proper airflow.
- Position the unit near a window or door for exhaust hose installation.



Figure 4.1: The Ariete Polar 14 Portable Air Conditioner positioned in a modern living room.

4.3 Exhaust Hose Installation

- Attach the exhaust hose connector to the back of the unit.
- Extend the exhaust hose and attach the window kit adapter to the other end.
- Install the window kit in a suitable window opening, ensuring a tight seal to prevent air leakage.
- Direct the exhaust hose through the window kit to vent hot air outside. Keep the hose as short and straight as possible for optimal performance.

4.4 Power Connection

- Plug the power cord into a grounded electrical outlet (220V).
- Ensure the outlet is suitable for the unit's power requirements.

5. Operating Instructions

5.1 Control Panel and Remote Control

The unit can be operated using the digital control panel on top of the unit or the provided remote control.

5.2 Turning On/Off

- Press the **ON/OFF** button on the control panel or remote control to turn the unit on or off.

5.3 Mode Selection

Press the **MODE** button to cycle through the available modes:

- **Cool Mode:** For cooling the room. Adjust temperature using the**UP/DOWN** arrows.
- **Heat Mode:** For heating the room. Adjust temperature using the**UP/DOWN** arrows.
- **Dry Mode (Dehumidify):** For removing moisture from the air. Fan speed is automatically set.
- **Fan Mode:** For air circulation without cooling or heating.

5.4 Fan Speed Adjustment

- In Cool, Heat, or Fan mode, press the**FAN SPEED** button to select between Low, Medium, High, or Auto fan speeds.

5.5 Timer Function

- Press the **TIMER** button to set a delay for turning the unit on or off. Use the**UP/DOWN** arrows to adjust the desired time (1-24 hours).

5.6 Sleep Function

- Press the **SLEEP** button to activate sleep mode, which adjusts the temperature gradually for comfortable sleep and reduces noise.

5.7 Wi-Fi Control

- The unit supports Wi-Fi control via a dedicated mobile application. Refer to the separate Wi-Fi setup guide for detailed instructions on connecting your unit to your home network and controlling it remotely.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your air conditioner.

6.1 Cleaning the Air Filter

- The air filter should be cleaned every two weeks or more frequently depending on usage.
- Turn off and unplug the unit.
- Remove the air filter from the back of the unit.
- Wash the filter with warm, soapy water. Rinse thoroughly and allow it to air dry completely before reinserting.

6.2 Draining Water

The unit has an internal water collection tank. When the tank is full, the unit will stop operating and display an error code (e.g., "FL").

- Turn off and unplug the unit.
- Place a shallow pan or tray under the drain outlet at the bottom rear of the unit.
- Remove the drain plug to allow water to flow out.
- Once drained, replace the drain plug securely.

6.3 Storage

- Before storing, drain all water from the unit.
- Clean the air filter and ensure it is dry.
- Unplug the power cord and coil it neatly.
- Store the unit in a cool, dry place, preferably in its original packaging.

7. Troubleshooting

If you encounter issues with your Ariete Polar 14, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Unit does not turn on	No power; Power cord unplugged; Full water tank	Check power outlet; Plug in power cord; Drain water tank
Unit not cooling/heating effectively	Air filter dirty; Exhaust hose not properly installed; Room too large; Doors/windows open	Clean air filter; Ensure hose is sealed; Use in appropriate room size; Close doors/windows
Unit is noisy	Unit not on a level surface; Air filter dirty; Obstruction in fan	Place on level surface; Clean air filter; Check for obstructions
Water leakage	Drain plug loose; Unit tilted	Secure drain plug; Ensure unit is level
Error code displayed	Specific internal issue (e.g., full tank, sensor error)	Refer to specific error code in the full manual (if available) or contact support. For 'FL' code, drain water.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Specification
Model Number	9023
Cooling/Heating Capacity	14000 BTU/h
Dimensions (L x W x H)	45 x 39.6 x 74.5 cm
Weight	33.7 kg

Feature	Specification
Voltage	220 Volts
Noise Level	65 dB
Refrigerant	R290 (Natural Gas)
Special Function	Heating function
Control Method	Application (Wi-Fi), Control Panel, Remote Control
Color	White

9. Warranty and Support

Your Ariete Polar 14 Portable Air Conditioner comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.
For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Ariete customer service. Contact information can typically be found on the manufacturer's website or on the product packaging.

© 2025 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09M71MY8C

More documents and user manuals: **https://manuals.plus/**