Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PINDOWS PDS-601G

PINDOWS Digital Sport Watch PDS-601G User Manual

Model: PDS-601G

1. Introduction

Thank you for choosing the PINDOWS Digital Sport Watch PDS-601G. This manual provides detailed instructions on how to set up, operate, and maintain your watch. Please read it carefully to ensure optimal performance and longevity of your device.





Image 1.1: Front view of the PINDOWS Digital Sport Watch PDS-601G.

2. Product Features

The PINDOWS PDS-601G Digital Sport Watch is equipped with a range of features designed for daily use and sports activities:

- **Multi-functional Display:** Time, Date, Day of the Week.
- **Alarm Function:** Three independent alarm groups.
- **LED Backlight:** High-brightness single-color backlight for visibility in low light.
- **Countdown Timer:** For various timing needs.
- **Stopwatch:** Precise timing for sports and activities.
- **Water Resistance:** Designed to resist water ingress (refer to specifications for depth).
- **Hourly Chime:** Optional audible alert every hour.
- **Durable Construction:** High-quality PU band, acrylic dial window, ABS plastic case, stainless steel back and buckle.

Image 2.1: Visual overview of the watch's main functions including LED light, water resistance, date/week display, 12/24-hour format, countdown, alarms, hourly chime, and stopwatch.

3. Watch Components and Button Functions

Familiarize yourself with the watch's buttons and their primary functions:



Image 3.1: Diagram illustrating the location and labels of the four control buttons on the watch.

- **Button A (LIGHT):** Activates the LED backlight.
- **Button B (MODE):** Cycles through different operational modes (Time, Stopwatch, Alarm, Countdown).
- **Button C (START/PAUSE):** Used to start/stop functions in Stopwatch and Countdown modes, and to adjust settings.
- **Button D (RESET/ADJUSTMENT):** Used to reset values in Stopwatch mode and to select items for adjustment in setting modes.

4. Operating Instructions

4.1. Time Setting

1. From the normal time display, press Button B (MODE) three times to enter Time Setting Mode. The seconds will flash.
2. Press Button D (RESET/ADJUSTMENT) to cycle through the settings: Seconds → Hours → Minutes → Month → Date → Day of Week.
3. While the desired value is flashing, press Button C (START/PAUSE) to adjust the value.
4. Press Button B (MODE) once to exit Time Setting Mode and return to normal time display.

4.2. 12/24-Hour Format

In Time Setting Mode (seconds flashing), press Button C (START/PAUSE) to toggle between 12-hour (with 'PM' indicator) and 24-hour formats.

4.3. Alarm Setting

1. From the normal time display, press Button B (MODE) twice to enter Alarm Mode. The hour digits will flash.
2. Press Button D (RESET/ADJUSTMENT) to select the alarm group (AL1, AL2, AL3).
3. Press Button C (START/PAUSE) to adjust the hour.
4. Press Button D (RESET/ADJUSTMENT) again to select the minute digits, then press Button C (START/PAUSE) to adjust the minutes.
5. Press Button B (MODE) to exit Alarm Setting Mode.
6. To activate/deactivate an alarm, in Alarm Mode, press Button C (START/PAUSE) to toggle the alarm ON/OFF. An alarm icon will appear/disappear on the display.

4.4. Hourly Chime

In Alarm Mode, press Button D (RESET/ADJUSTMENT) to select the hourly chime setting. Press Button C (START/PAUSE) to toggle the hourly chime ON/OFF. A chime icon will appear/disappear.

4.5. Stopwatch Function

1. From the normal time display, press Button B (MODE) once to enter Stopwatch Mode.
2. Press Button C (START/PAUSE) to start the stopwatch.
3. Press Button C (START/PAUSE) again to pause the stopwatch.
4. Press Button D (RESET/ADJUSTMENT) to reset the stopwatch to zero while it is paused.
5. Press Button B (MODE) to exit Stopwatch Mode.

4.6. Countdown Timer

1. From the normal time display, press Button B (MODE) four times to enter Countdown Mode.
2. Press Button D (RESET/ADJUSTMENT) to select the hour, minute, or second digits for adjustment.
3. Press Button C (START/PAUSE) to adjust the selected value.
4. Once the desired countdown time is set, press Button C (START/PAUSE) to start the countdown.
5. Press Button C (START/PAUSE) again to pause/resume the countdown.
6. Press Button D (RESET/ADJUSTMENT) to reset the countdown to its initial set time while it is paused.
7. Press Button B (MODE) to exit Countdown Mode.

4.7. LED Backlight

Press Button A (LIGHT) at any time to illuminate the display. The backlight will remain on for a few seconds.



Image 4.1: The watch display illuminated by its LED backlight, enhancing visibility in dark conditions.

5. Maintenance and Care

To ensure the longevity and proper functioning of your PINDOWS Digital Sport Watch, please follow these maintenance guidelines:

- **Water Resistance:** The watch is water-resistant. However, **do not press any buttons while the watch is submerged in water**. Avoid wearing the watch during hot showers or in saunas, as steam can penetrate the seals and cause internal fogging or damage.
- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- **Temperature:** Avoid exposing the watch to extreme temperatures (hot or cold) for extended periods.
- **Chemicals:** Keep the watch away from solvents, detergents, perfumes, and other chemical substances, as they can damage the band, case, or seals.
- **Impact:** Protect the watch from strong impacts or drops.



Image 5.1: The watch demonstrating its water resistance, suitable for splashes and brief immersion, but not for button operation underwater.

6. Troubleshooting

If you encounter any issues with your watch, please refer to the following common problems and solutions:

- **Display is blank or dim:** The battery may be low. Replace the CR2 battery.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model does not feature a lock). Try pressing Button B (MODE) to cycle through modes. If the issue persists, a battery replacement might be needed.
- **Water inside the display:** If condensation or water droplets appear inside the watch, stop using it immediately and seek professional service. This indicates a breach in the water resistance.
- **Time is inaccurate:** Re-set the time following the instructions in Section 4.1. If the time continues to be inaccurate, the battery may be weak or require replacement.

7. Specifications

Feature	Detail
Model Number	PDS-601G
Dimensions (L x W x H)	23 x 4.3 x 1.8 cm
Weight	50 grams
Case Material	ABS Plastic
Band Material	High-quality PU
Dial Window Material	Acrylic Mirror
Back Material	Stainless Steel
Water Resistance	30M (suitable for splashes, rain, hand washing; not for swimming or hot water)
Battery Type	1 x CR2 (requires 1 battery)

8. Warranty and Support

PINDOWS is committed to providing high-quality products and customer satisfaction. If you have any questions regarding the product's operation, settings, or encounter any issues, please contact our customer support. We are dedicated to assisting you and providing a satisfactory solution.

For further assistance, please refer to the contact information provided with your purchase or visit the official PINDOWS website.

© 2023 PINDOWS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MDM4FVR

More documents and user manuals: **https://manuals.plus/**