Manuals+

Q & A | Deep Search | Upload

manuals.plus /
› **AWOW** /
› **AWOW 14-inch Laptop User Manual - Intel Core i5, 8GB RAM, 256GB SSD, Windows 10 Home (Model 1418)**

AWOW 1418

AWOW 14-inch Laptop User Manual

Model: 1418 | Series: CreaBook i540

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your AWOW 14-inch laptop. Please read this guide thoroughly to ensure optimal performance and longevity of your device.

Image: The AWOW 14-inch laptop, showcasing its sleek design and display.

1. SETUP

1.1 Unpacking

Carefully remove all components from the packaging. Ensure the following items are present:

- AWOW 14-inch Laptop
- Power Adapter
- User Manual (this document)

1.2 Initial Charging

Before first use, connect the power adapter to the laptop's 19V DC input port and a power outlet. Allow the laptop to charge for at least 3 hours or until the battery indicator shows a full charge.

1.3 Power On and Windows Setup

Press the power button to turn on the laptop. Follow the on-screen instructions to complete the Windows 10 Home setup process. This includes selecting your language, region, creating a user account, and accepting the license agreement.

1.4 Connecting Peripherals

Your laptop features various ports for connecting external devices:

Image: Diagram illustrating the various ports on the AWOW laptop, including 19V DC in, HDMI, Type-C, USB, TF/SD card slot, and earphone jack.

- **HDMI Port:** Connect to an external monitor or TV.
- **USB Ports:** Connect USB devices such as mice, keyboards, or external storage.
- **Type-C Port:** For data transfer and connecting compatible Type-C devices.
- **TF/SD Card Slot:** Insert a Micro-SD card for additional storage.
- **Earphone Jack:** Connect headphones or external speakers.
- **Kensington Lock Slot:** For physical security.

2. OPERATING INSTRUCTIONS

2.1 Power On/Off and Sleep Mode

- **Power On:** Press the power button located on the keyboard.
- **Power Off:** Click the Windows Start button, then select Power > Shut down.
- **Sleep Mode:** Click the Windows Start button, then select Power > Sleep, or close the laptop lid.

2.2 Keyboard and Touchpad

The laptop features a full-size keyboard and a responsive touchpad. The touchpad supports multi-touch gestures for navigation.

Image: Close-up view of the AWOW laptop's keyboard and touchpad, highlighting their layout.

- **Single-finger tap:** Left-click.
- **Two-finger tap:** Right-click.
- **Two-finger scroll:** Scroll up or down.
- **Pinch-to-zoom:** Zoom in or out.

2.3 Webcam Usage

The integrated HD camera and microphone are suitable for video calls and online meetings. The laptop includes an anti-peep design for privacy.

Image: Detail of the laptop's webcam, featuring its anti-peep privacy design.

2.4 Battery Management

The laptop is equipped with a 7000 mAh, 7.6V battery designed for extended use. To maximize battery life:

Image: Graphic indicating the 7000mAh battery capacity of the AWOW laptop.

- Adjust screen brightness.
- Close unused applications.
- Enable battery saver mode in Windows settings.
- For optimal performance, keep the laptop plugged in during intensive tasks.

The battery provides approximately 8 hours of office use, 4.5 hours for web video, and 6.5 hours for downloaded video playback.

3. MAINTENANCE

3.1 Cleaning

- Use a soft, lint-free cloth to clean the screen and exterior.
- Avoid abrasive cleaners or solvents.
- Use compressed air to clear dust from keyboard keys and vents.

3.2 Software Updates

Regularly check for and install Windows updates to ensure system stability and security. Go to **Settings > Update & Security > Windows Update**.

3.3 Storage Management

To maintain optimal performance, periodically manage your 256GB SSD storage:

- Delete unnecessary files and applications.
- Utilize the Micro-SD card slot (up to 512GB) for additional storage of large files.
- Consider cloud storage for backups.

4. TROUBLESHOOTING

4.1 Common Issues and Solutions

- **Laptop does not power on:**
  Ensure the power adapter is securely connected and the battery is charged. Try a different power outlet.

- **Wi-Fi connection issues:**
  Check if Wi-Fi is enabled in Windows settings. Restart your router and the laptop. Ensure drivers are up to

date.

- **Slow performance:**
  Close unnecessary applications. Check for background processes consuming resources. Ensure sufficient free storage space on the SSD.

- **Screen is blank or flickering:**
  Restart the laptop. If connected to an external monitor, try disconnecting it. Adjust screen brightness.

For persistent issues, please refer to the Warranty and Support section for contact information.

5. SPECIFICATIONS

Feature	Detail
Brand	AWOW
Model Number	1418
Series	CreaBook i540
Operating System	Windows 10 Home
Processor	Intel Core i5-8279U (4 Cores, up to 4.1 GHz)
RAM	8 GB DDR4
Storage	256 GB SATA SSD, Micro-SD card slot (up to 512GB)
Display	14-inch Full HD (1920 x 1080) IPS LCD
Graphics	Integrated Intel Graphics
Connectivity	WiFi, Bluetooth 5.1
Ports	19V DC in, HDMI, Type-C, USB (multiple), TF/SD card slot, Earphone Jack, Kensington Lock Slot
Battery	7000 mAh, 7.6V Lithium-polymer
Dimensions (L x W x H)	32.3 x 21.8 x 1.8 cm
Weight	1.5 Kilograms

Image: Close-up of the Intel Core i5 processor, the core component of the laptop.

Image: The laptop's 14-inch Full HD IPS display, showing vibrant colors and clear resolution.

6. WARRANTY AND SUPPORT

AWOW provides comprehensive support for your laptop:

- **Warranty:** 12-month limited warranty from the date of purchase.
- **Customer Service:** 24-hour customer service availability.
- **Technical Support:** Lifetime technical support from experienced IT technicians.
- **Warranty Services:** During the warranty period, AWOW offers free authorized returns, exchanges, and genuine accessory parts for eligible issues.

For assistance, please contact AWOW customer support through their official channels.