Beurer MP 84

Beurer MP 84 Manicure/Pedicure Set User Manual

Model: MP 84 | Brand: Beurer

1. Safety Information

For external use only.
Always read and follow all instructions and warnings before using the device. Keep the device out of reach of children.

2. Product Overview

The Beurer MP 84 Manicure/Pedicure Set is a versatile electric nail file designed for comprehensive hand and foot care. It features a powerful rechargeable battery, allowing for cordless operation, and comes with a variety of high-quality attachments for filing, polishing, and callus removal.

2.1. What's in the Box

- Beurer MP 84 Manicure/Pedicure Device
- 10 High-Quality Sapphire and Felt Attachments
- Charging and Storage Case
- Protective Cap for Nail Dust
- Power Adapter (integrated into case)

2.2. Key Features

- Complete hand and foot care for shortening, filing, polishing nails, and removing calluses.
- Cordless operation with a high-quality battery providing up to 2 hours of use.
- Includes 10 high-quality sapphire and felt attachments.
- Charging and storage case for convenient organization and recharging.
- 3 speed levels with up to 4400 rpm.
- Integrated LED light for precise work.
- Adjustable rotation direction (clockwise/counter-clockwise).



Image: The Beurer MP 84 Manicure/Pedicure Set, showcasing the main device, the charging and storage case, and the full array of 10 interchangeable attachments.

3. Setup

3.1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that all listed items in the 'What's in the Box' section are present and undamaged. If any items are missing or damaged, contact customer support.

3.2. Charging the Device

1. Place the manicure/pedicure device into the provided charging and storage case.
2. Connect the charging case to a suitable power source using the integrated power adapter.
3. The LED indicators on the device will show the charging status. A full charge provides approximately 2 hours of

cordless operation.



Image: The Beurer MP 84 device securely placed within its open charging and storage case, illustrating how it is stored and charged.

3.3. Attaching Accessories

1. Select the desired attachment for your specific nail or skin care need.
2. Gently push the chosen attachment onto the spindle of the device until it clicks into place.
3. To remove an attachment, pull it firmly but gently off the spindle.



Image: The Beurer MP 84 device displayed alongside its ten high-quality sapphire and felt attachments, highlighting the variety available for different uses.

4. Operating Instructions

4.1. Power On/Off

Press and hold the power button on the device to turn it on or off.

4.2. Adjusting Speed and Rotation Direction

- Use the '+' and '-' buttons to cycle through the 3 available speed levels (3200, 3800, 4400 rpm).
- Press the rotation direction button to switch between clockwise and counter-clockwise rotation. This allows for comfortable use on both hands and feet.



Image: The Beurer MP 84 device, its attachments, and charging case, emphasizing the three adjustable speed levels and rotation direction.

4.3. Using the Attachments

Each of the 10 attachments is designed for a specific purpose. Refer to the following general guidelines:

- **Filing and Shaping:** Use the sapphire cone or disc attachments for shortening and shaping nails.
- **Polishing:** The felt cone is ideal for smoothing and polishing the nail surface to a high shine.
- **Callus and Hard Skin Removal:** Coarser sapphire attachments are effective for gently removing calluses and hard skin from feet.
- **Cuticle Care:** Specialized attachments can be used to carefully push back or remove excess cuticles.

Note: Do not pre-treat nails or skin with a foot bath before use, as the grinding attachments are less effective on wet or damp skin.

4.4. LED Light and Dust Protection Cap

- The integrated LED light illuminates the working area, ensuring precise application even in low light conditions.

- Attach the protective cap for nail dust to collect debris during use, maintaining hygiene and cleanliness.



Image: The Beurer MP 84 device shown with its transparent protective cap, highlighting key features such as battery life, accessories, LED screen, rotation, speeds, and the storage case.

5. Maintenance

5.1. Cleaning the Device and Attachments

1. Always disconnect the device from the power source before cleaning.
2. Wipe the device body with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
3. Clean the attachments after each use. Most attachments can be cleaned with a brush or a damp cloth. Ensure they are completely dry before storing.

5.2. Storage

Store the device and all attachments in the provided charging and storage case when not in use. This protects the components and keeps them organized. Store in a cool, dry place away from direct sunlight.

6. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the charging case.
Attachments are not effective.	Incorrect attachment used; attachments are worn; skin/nails are wet.	Ensure the correct attachment is selected for the task. Replace worn attachments. Ensure skin/nails are dry before use.
Device stops during use.	Battery is low; excessive pressure applied.	Recharge the device. Reduce pressure during use.

7. Specifications

Model: MP 84

Power Source: Battery-powered (Lithium-ion)

Battery Life: Up to 2 hours

Max Rotation Speed: 4400 rpm

Speed Levels: 3 (3200, 3800, 4400 rpm)

Input Power: 1.85 Watt

Voltage: 3.7 Volts

Dimensions (L x W x H): 6 x 21 x 2 cm

Weight: 135 Grams

Country of Origin: China

8. Warranty and Support

For detailed warranty information and customer support, please refer to the official Beurer website or the warranty card included with your product. You can also visit the official Beurer store for more information and product registration.

Official Beurer Store: Beurer Store on Amazon

9. Official Product Videos

No official product videos from the seller were found for embedding in this manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question