**ALLIMITY QYSY-RC-4848-QYSY**

# User Manual for ALLIMITY Replacement Remote Control

Model: QYSY-RC-4848-QYSY

## Introduction

This user manual provides comprehensive instructions for the ALLIMITY RC-4848 Replacement Remote Control. This remote is designed to function as a direct replacement for original remote controls of various Hitachi, Horizon, Luxor, Saba, and Lazer TV models. It covers all essential functions of your previous remote without requiring any complex programming.

## Setup

### Battery Installation

The ALLIMITY RC-4848 remote control operates on standard alkaline batteries. Batteries are not included with the remote and must be purchased separately.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new alkaline batteries (typically AAA or AA, refer to the remote's markings for exact type) ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

### Initial Use

This replacement remote control is designed for immediate use with compatible TV models. No programming or code entry is required. Once batteries are correctly installed, the remote is ready to operate your television.



Figure 1: Front view of the ALLIMITY RC-4848 Replacement Remote Control.

## Operating Instructions

The ALLIMITY RC-4848 remote control features a standard layout for easy navigation and control of your television.

Below is a general guide to the main functions:

- **Power Button (●):** Located at the top, this button turns the TV on or off.
- **Source Button ( ):** Selects the input source (e.g., HDMI 1, AV, TV).
- **Number Buttons (0-9):** Used for direct channel selection.
- **Volume Up/Down (V+/V-):** Adjusts the audio volume.
- **Channel Up/Down (P+/P-):** Changes the television channel.
- **Mute Button ( ):** Toggles sound on or off.
- **Menu Button:** Accesses the TV's main menu for settings and options.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate through menus and confirm selections.
- **Back Button:** Returns to the previous screen or menu.
- **Exit Button:** Exits the current menu or application.
- **Smart TV Buttons (e.g., Netflix):** Direct access buttons for popular streaming services or smart TV features, if supported by your TV model.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** Controls playback of media content.

Ensure there is a clear line of sight between the remote control and the TV's infrared receiver for optimal performance. The maximum effective range is approximately 10 meters (33 feet).

## Maintenance

### Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the remote's finish or internal components.

### Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries according to local regulations.

### Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage and potential damage.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote is not working. | • Dead or incorrectly inserted batteries.<br>• Obstruction between remote and TV.<br>• Remote is out of range. | • Replace batteries, ensuring correct polarity.<br>• Remove any objects blocking the signal path.<br>• Move closer to the TV (within 10 meters). |

| Problem | Possible Cause | Solution |
|---|---|---|
| Some buttons do not function. | • Remote not fully compatible with specific TV model features.<br>• Button stuck or damaged. | • Verify your TV model is listed as compatible.<br>• Gently press the button multiple times. If still unresponsive, the button may be faulty. |
| Remote works intermittently. | • Low battery power.<br>• Interference from other electronic devices. | • Replace batteries.<br>• Ensure no other devices are emitting strong infrared signals nearby. |

## Specifications

| | |
|---|---|
| **Brand** | ALLIMITY |
| **Model** | QYSY-RC-4848-QYSY |
| **Product Dimensions** | 4 x 12 x 0.3 cm (approximately 1.57 x 4.72 x 0.12 inches) |
| **Product Weight** | 50 g (approximately 1.76 ounces) |
| **Compatible Devices** | RC4848, 32HBT41, 40F501HB1T62, 40HB1C66I, 40HB6T62, 40HBT42, 40HK6W64, 42HZT66, 42HZT66K, 43HB6T62, 43HBT42, 43HG6W69I, 43HK6W64, 48HB6W62, 48HK6W64, 49HB1W62, 49HBT62A, 49HGW69, 50HZT66, 55HB6W62, 55HG2W69I, 55HGW69, 55HK6W64, 55HZ6C66I, 55HZT66K, 65HZT663DK, 32HL733H, 40HL733F, 43HL733F, 49HL733F, 55HL733, 24HL733H, LED42FSB, LED55FSB, LUX0132002, LUX01320021, LUX0132003/01, LUX013200301, LUX0132004/01, LUX0142001/02, LUX0150002/01, LUX015000201, LUX0155001, LUX0165001/01, LUX016500101, LZ55243, LD40VS249, S4927-SMART, 39800, 49800, 49HG6W69I, 55HK6W64 (V2), 40HBT42A, 65HZT663D, 49HK6W64 (V2), 43HGW69, 43HBT42A, 43HK6W64(V2), 49HBT62A, 49HK6T74U, 55HG2W691, V15L00202 |
| **Special Feature** | No programming required |
| **Battery Type** | Alkaline (not included) |
| **Connectivity Technology** | Infrared |
| **Number of Buttons** | 25 |
| **Maximum Range** | 10 Meters (33 feet) |

## Warranty and Support

For any issues, questions, or support regarding your ALLIMITY RC-4848 Replacement Remote Control, please contact the seller or manufacturer directly through the platform where the purchase was made. Please refer to your purchase documentation for specific warranty information, if applicable.

*Note: This manual is for informational purposes only. Product specifications and features are subject to change without notice.*

© 2024 ALLIMITY. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question