Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RM-C1245

ALLIMITY RM-C1245 Universal Remote Control User Manual

Model: RM-C1245

Brand: ALLIMITY

1. Introduction

This manual provides detailed instructions for the ALLIMITY RM-C1245 universal remote control. It is designed to replace your original remote and offers full functionality for a wide range of compatible TV models. Please read this manual carefully to ensure proper use and to maximize your remote control's performance.

2. Setup

2.1 Battery Installation

The ALLIMITY RM-C1245 remote control requires two AAA alkaline batteries (not included).

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
3. Close the battery compartment cover securely.

2.2 Compatibility

This remote control is compatible with various TV models from brands such as JVC, ORAVA, MYSTERY, MPMAN, CMX, HAIER, and HYUNDAI. No programming is required; simply insert batteries, and the remote is ready for use with the following models:

- LT-19HA52U, LT-24HD7WU, LT-24HA72U, LT-32HA72U, LT-28HA52U, LT-42HG82U, LT-28HA72U, LT-40HG72U
- LT19HA52U, LT24HD7WU, LT24HA72U, LT32HA72U, LT28HA52U, LT42HG82U, LT28HA72U, LT40HG72U
- LT-611-LED-M92B, LT611LEDM92B, LT-630-LED-M92B-VDO-RC, LT630LED-M92B
- LT-823-LED-M91B, LT823LEDM91B, LT-823-LED-M92B, LT823LEDM92B
- MTV-2428LT2, MTV2428LT2, MTV-3022LW, MTV3022LW, MTV-3220LT2, MTV3230LT2, MTV-3223LT2, MTV3223LT2, MTV-3228LT2, MTV3238LT2

3. Operating Instructions

The ALLIMITY RM-C1245 remote control is designed for intuitive use. Point the remote directly at your television's infrared

receiver for optimal performance.

3.1 Button Functions





Figure 1: Front view of the ALLIMITY RM-C1245 universal remote control, displaying all buttons and their layout.

- **Power (Red Button):** Turns the television on or off.
- **MUTE:** Mutes or unmutes the television sound.
- **Colored Buttons (Red, Green, Yellow, Blue):** These buttons typically correspond to specific functions within menus or teletext, as indicated on your TV screen.
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Stop, Record):** Used for controlling media playback on compatible devices or TV functions.
- **TEXT:** Accesses teletext services.
- **SUBTITLE:** Toggles subtitles on or off.
- **FREEZE:** Pauses the current image on screen.
- **INFO:** Displays program information.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections. The **OK** button confirms choices.
- **EPG (Electronic Program Guide):** Opens the electronic program guide.
- **EXIT:** Exits the current menu or function.
- **VOL +/-:** Increases or decreases the volume.
- **CH +/-:** Changes the channel up or down.
- **FAV (Favorite):** Accesses your list of favorite channels.
- **REC (Record):** Initiates recording on compatible devices.
- **Number Pad (0-9):** Directly enters channel numbers or other numerical inputs.
- **AUDIO:** Selects audio tracks or modes.
- **RECALL:** Switches between the current and previously viewed channel.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote.

5. Troubleshooting

5.1 Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity. Replace with fresh AAA alkaline batteries.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor. Point the remote directly at the TV.
- **Remote Control Distance:** Ensure you are within the effective operating range (up to 10 meters).
- **TV Power:** Confirm the TV is powered on and not in standby mode.

5.2 Specific Functions Not Working

- **Compatibility:** While the remote is universal for listed models, some advanced or brand-specific functions might not be fully supported. Refer to your TV's original manual for specific features.

6. Specifications

Feature	Detail
Brand	ALLIMITY
Model Name	RM-C1245
Color	Black
Connectivity Technology	Infrared
Special Feature	Universal
Compatible Devices	JVC, ORAVA, MYSTERY, MPMAN, CMX, HAIER, HYUNDAI TVs (specific models listed in Compatibility section)
Maximum Range	10 Meters
Number of Buttons	35
Controller Type	Remote Control
Power Source	2 x AAA Batteries (not included)

7. Warranty and Support

Information regarding product warranty and specific support contacts is not provided in the available product details. For any issues or further assistance, please refer to the retailer where you purchased the product or consult your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MZ6R68S

More documents and user manuals: **https://manuals.plus/**