Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-RC-4390

ALLIMITY Replacement Remote Control User Manual for Telefunken, ORAVA, OK. TV Models (QYSY-RC-4390)

1. Introduction

This user manual provides comprehensive instructions for the ALLIMITY QYSY-RC-4390 replacement remote control. This remote is designed to function as a direct replacement for original remote controls of various Telefunken, ORAVA, and OK. television models. It offers full functionality without requiring any complex programming.

2. Product Overview





Figure 1: ALLIMITY QYSY-RC-4390 Replacement Remote Control. This image displays the front view of the black remote control, highlighting its button layout including number keys, navigation pad, volume and channel controls, and dedicated Netflix and YouTube buttons.

The ALLIMITY QYSY-RC-4390 remote control is an infrared (IR) device featuring 40 buttons for comprehensive control over compatible televisions. Its universal design ensures compatibility with a wide range of specified TV models.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two new AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.

4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

Important: No programming or pairing is required. Once batteries are correctly installed, the remote control is ready for immediate use with compatible TV models.

4. Operating Instructions

Point the remote control directly at the television's infrared receiver. Ensure there are no obstructions between the remote and the TV.

- **Power Button ( ):** Turns the TV on or off.
- **Number Buttons (0-9):** Select channels directly.
- **Volume Up/Down (V+/V-):** Adjusts the audio volume.
- **Channel Up/Down (P+/P-):** Changes the TV channel sequentially.
- **Mute Button ( ):** Mutes or unmutes the TV audio.
- **Navigation Pad (Arrows & OK):** Navigates through menus and confirms selections.
- **Back Button:** Returns to the previous menu or screen.
- **Exit Button:** Exits the current menu or application.
- **Netflix Button:** Direct access to the Netflix application.
- **YouTube Button:** Direct access to the YouTube application.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.

5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new alkaline batteries.
  - Check for any obstructions between the remote control and the TV's IR sensor.
  - Ensure the remote is pointed directly at the TV.
- **Some functions not working:**
  - While this remote is designed for full functionality, some specific advanced features of your original TV remote might not be replicated if they are unique to that model.
  - Verify your TV model is listed as compatible.

6. Specifications

Brand	ALLIMITY
Model Name	QYSY-RC-4390
Connectivity Technology	Infrared (IR)
Special Feature	Universal Replacement
Color	Black

Number of Buttons	40
Maximum Range	10 Meters
Compatible Devices	Telefunken, ORAVA, OK. TV models including: ODL49650UV-TIB, D40U297M4CW, D50U293N4CWH, XU43E512, JT-55UBS300, D32H289N4CWD, D43U600M4CWII, D40U298N4CWH, SOMNIA24ESTV, 49DTU652, JT-65UBS300, D55U297N4CWH, D50U600M4CWII, L55U405N4CWH, SOMNIA40DSTV, 55DTU652, D32H287M4CWI, D43U700M4CWH, TFL32SWB17/2, D65U400N4CWH, 32DTH531, XU55E512, D32F289M4CWII, D49U700M4CWH, D43U297N4CWH, 40DTF531, L24H472F4CWV-WI, D32H289N4CWI, TE43292S31Y2P, ODL65650U-TIB, ODL43650UV-TIB, ODL40650UV-TIB, ODL65750UV-TI, ODL55750UV-TIB, ODL32750FV-TIB, ODL32653FV-TIW, ODL40650F, ODL32541H-DIB.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the remote becomes unresponsive or its range decreases, replace the batteries promptly. Remove batteries if the remote will not be used for an extended period to prevent leakage.

8. Warranty and Support

Information regarding specific warranty terms or dedicated support channels for this ALLIMITY replacement remote control is not available in the provided product details. For any issues, please refer to the retailer's return policy or contact the seller directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MZ7F8LF

More documents and user manuals: **https://manuals.plus/**