Silverlit 20634

Silverlit EXOST X-Crawler 2.4Ghz Remote-Controlled Car Instruction Manual

Model: 20634

Introduction

Welcome to the world of EXOST! This manual provides essential information for the safe and optimal operation of your Silverlit EXOST X-Crawler 2.4Ghz remote-controlled car. The X-Crawler is designed for all-terrain excursions with its robust front and rear suspensions and specially charted tires. Featuring 2.4Ghz technology, it supports indoor and outdoor play for up to 10 players simultaneously.
Please read this manual thoroughly before using the product and retain it for future reference.



Figure 1: Silverlit EXOST X-Crawler remote-controlled car.

Package Contents

- EXOST X-Crawler Remote-Controlled Car
- 2.4Ghz Remote Control
- USB Rechargeable Battery (for car)
- USB Charging Cable
- Instruction Manual (this document)



Figure 2: EXOST X-Crawler product packaging.

Setup

1. Car Battery Installation and Charging

1. Locate the battery compartment on the underside of the X-Crawler car.
2. Open the battery compartment cover.
3. Connect the included USB rechargeable battery to the car's battery connector.
4. Close the battery compartment cover securely.
5. To charge the car's battery, connect the USB charging cable to the car's charging port and then to a standard USB power source (e.g., computer USB port, USB wall adapter).
6. The charging indicator light will show the charging status (refer to car for specific light behavior). Charging typically takes approximately 60-90 minutes for a full charge.
7. Once fully charged, disconnect the USB charging cable.

2. Remote Control Battery Installation

The remote control requires 2 x AA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Open the battery compartment cover.
3. Insert 2 new AA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Figure 3: EXOST 2.4Ghz Remote Control.

3. Pairing the Car and Remote

The X-Crawler uses 2.4Ghz technology for automatic pairing.

1. Ensure both the car and the remote control have fresh or fully charged batteries.
2. Turn on the car using the ON/OFF switch located on its underside.
3. Turn on the remote control using its ON/OFF switch.
4. The car and remote will automatically pair. The indicator light on the remote (and possibly the car) will stop flashing and remain solid once paired.
5. If pairing fails, turn both devices off and repeat the steps.

Operating Instructions

Basic Controls

- **Steering Wheel:** Turn the steering wheel on the remote control left or right to steer the car.
- **Trigger:** Pull the trigger towards you to move the car forward. Push the trigger away from you to move the car

backward or to brake.

Driving Tips

- The X-Crawler is designed for all-terrain use, including rough surfaces, thanks to its front and rear suspensions and robust tires.
- Avoid driving in water or extremely wet conditions.
- The maximum control range is approximately 20 meters. Operating beyond this range may result in loss of control.
- The car can reach an actual speed of 7 km/h (scale speed: 168 km/h).
- Enjoy up to 25 minutes of play time on a full charge.
- Up to 10 X-Crawler cars can be operated simultaneously in the same area due to 2.4Ghz technology.



Figure 4: Operating the X-Crawler with the remote control.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the car and remote control. Do not use water or chemical cleaners, as this may damage electronic components.
- **Battery Care:**
  - Always turn off the car and remote control after use.
  - Remove AA batteries from the remote control if it will not be used for an extended period to prevent leakage.
  - Recharge the car's battery only when necessary and avoid overcharging.
  - Store batteries in a cool, dry place.
- **Storage:** Store the X-Crawler and its remote control in a cool, dry place away from direct sunlight and extreme temperatures.

- **Inspection:** Periodically check for loose screws, damaged parts, or worn tires. Replace any damaged parts as needed.

Troubleshooting

Problem	Possible Cause	Solution
Car does not respond to remote.	• Car or remote is off. • Low batteries in car or remote. • Not paired correctly. • Out of range.	• Ensure both are switched ON. • Charge car battery; replace remote batteries. • Turn both off, then on again to re-pair. • Move closer to the car.
Poor control range or intermittent signal.	• Low batteries. • Interference from other 2.4Ghz devices. • Obstacles between remote and car.	• Charge car battery; replace remote batteries. • Move to an area with less interference. • Ensure a clear line of sight.
Car moves slowly or not at all.	• Low car battery. • Obstruction in wheels or drivetrain.	• Recharge car battery. • Check and clear any debris from wheels and axles.

Specifications

Model Number	20634
Product Dimensions (L x W x H)	7.87 x 4.72 x 4.72 inches (20 x 12 x 12 cm)
Item Weight	1.21 pounds
Frequency	2.4 GHz
Control Range	Up to 20 meters
Actual Speed	7 km/h
Scale Speed	168 km/h
Play Time	Up to 25 minutes
Car Battery	USB Rechargeable (included)
Remote Control Batteries	2 x AA (not included)
Recommended Age	5 years and above
Manufacturer	Silverlit

Warranty Information

Specific warranty details for the Silverlit EXOST X-Crawler are typically provided with the product packaging or can be found on the official Silverlit website. Please refer to the documentation included in your product box for the most accurate and up-to-date warranty information.

Support

For further assistance, technical support, or inquiries regarding your Silverlit EXOST X-Crawler, please visit the official Silverlit website or contact their customer service department.

Manufacturer: Silverlit

Visit the Silverlit Store on Amazon

© 2023 Silverlit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question