Instant Pot 113-0058-01

Instant Pot Duo Plus 8-Quart Whisper Quiet 9-in-1 Electric Pressure Cooker

Model: 113-0058-01 | Brand: Instant Pot

Introduction and Overview

The Instant Pot Duo Plus 8-Quart is a versatile 9-in-1 electric pressure cooker designed for efficiency and convenience in the kitchen. It combines the functions of a pressure cooker, slow cooker, rice cooker, steamer, saut , yogurt maker, warmer, and sterilizer, all within a single appliance. Its intuitive dial control and smart programs simplify meal preparation, while the innovative WhisperQuiet technology ensures a peaceful cooking experience by minimizing steam release noise. This appliance is engineered for speed, cooking food up to 70% faster than traditional slow cooking methods, making it ideal for busy households. The durable stainless steel inner pot is designed to stay in place during saut , and both the lid and inner pot are dishwasher-safe for effortless cleanup.



Figure 1: The Instant Pot Duo Plus 8-Quart Electric Pressure Cooker, showcasing its sleek stainless steel exterior and intuitive control panel.

Key Features

- **9 Cooking Functions:** Pressure cook, slow cook, steam, saut , sous vide, make rice, yogurt, cake, or simply keep your meal warm all in one appliance with intuitive dial control.
- **Guided Cooking:** An angled control panel with a clear message display and cooking progress bar, paired with 25 recipe presets and step-by-step instructions, makes every meal foolproof.
- **Safe, Easy & Silent Steam Release:** WhisperQuiet technology minimizes noise for a peaceful kitchen, while the perfectly placed one-touch steam release button lets you release steam effortlessly and safely.
- **Good Food Done Faster:** Cook up to 70% faster compared to slow cooking methods.

- **Sturdy Anti-Spin Pot:** Stainless steel (18/8) pot with a tri-ply bottom that stays in place for seamless saut .
- **Family-Sized Capacity:** The 8-quart capacity is perfect for up to 8 servings ideal for larger families, gatherings, meal prep, and batch cooking.
- **Quick Cleanup:** The dishwasher-safe lid and inner pot make clean-up a breeze.
- **Proven Peace of Mind:** Features over 10 safety mechanisms, including overheat protection and an easy seal safety lid lock.
- **A Little Extra:** Includes a stainless-steel steam rack with handles and two extra sealing rings.



Figure 2: Visual representation of the nine distinct cooking programs available on the Instant Pot Duo Plus.

Setup

Before first use, ensure all components are clean. Wash the inner pot, lid, and silicone sealing rings with warm, soapy water. Rinse thoroughly and dry. Insert one of the silicone sealing rings firmly into the lid's sealing ring rack. The Instant Pot comes with two sealing rings; one is typically red and the other clear. It is recommended to use separate rings for savory and sweet dishes to prevent flavor transfer.



Figure 3: The dishwasher-safe lid and inner pot of the Instant Pot, highlighting ease of cleaning.

Place the stainless steel inner pot into the cooker base. Ensure it is properly seated. The inner pot is designed to remain stable during use, preventing spinning when stirring ingredients.



Figure 4: The sturdy stainless steel inner pot, designed for seamless saut without spinning.

Operating Instructions

Control Panel and Display

The Instant Pot Duo Plus features an angled control panel with a clear message display and a central dial for easy program selection and adjustment. The display provides real-time updates on the cooking process, including "Preheating," "Cooking," and "Keep Warm" statuses, eliminating guesswork.



Figure 5: The easy-to-read progress indicator and message display on the Instant Pot control panel.

Selecting a Cooking Program

To select a cooking program, simply turn the central dial to navigate through the available presets (e.g., Pressure Cook, Slow Cook, Rice, Steam, Saut , Yogurt, Sous Vide, Cake). Once a program is selected, you can further adjust parameters like cooking time and pressure level using the dial. After setting your desired parameters, press the "Start" button to begin the cooking cycle.

Steam Release (WhisperQuiet Technology)

The WhisperQuiet steam release feature is designed for safety and reduced noise. The steam release button is strategically placed away from the steam vent, allowing for effortless and safe pressure release. When the cooking cycle is complete and pressure needs to be released, simply press the steam release button. The display will indicate when it is safe to open the lid.



Figure 6: Demonstration of the WhisperQuiet steam release button, located safely away from the steam vent.

During the cooking process, the display may show "DO NOT OPEN LID," it indicates that the cooker is pressurized and opening it would be unsafe. Wait for the pressure to release naturally or manually release it using the WhisperQuiet steam release button as instructed in the Operating section.

Maintenance and Cleaning

The Instant Pot Duo Plus is designed for easy maintenance. The stainless steel inner pot and the entire lid assembly are dishwasher-safe, simplifying cleanup after cooking. For best results, remove the silicone sealing ring from the lid before washing and ensure it is properly reinserted before the next use.

Regularly inspect the silicone sealing rings for any signs of wear or damage. The product includes two sealing rings, allowing you to dedicate one for savory dishes and another for sweet dishes to prevent flavor transfer. This helps maintain the integrity of flavors in your meals.

Troubleshooting

The Instant Pot's digital display provides helpful messages during operation. If the display shows "DO NOT OPEN LID," it indicates that the cooker is pressurized and opening it would be unsafe. Wait for the pressure to release naturally or manually release it using the WhisperQuiet steam release button as instructed in the Operating section.
For other issues, refer to the comprehensive User Manual (PDF) available online for detailed troubleshooting steps and solutions. Ensure all components are correctly assembled and the sealing ring is properly seated for optimal performance.

Specifications

Attribute	Value
Brand	Instant Pot
Model Number	113-0058-01
Capacity	8 Quarts
Material	Stainless Steel
Color	Chrome
Product Dimensions	15"D x 15"W x 14"H
Item Weight	19.7 Pounds
Power Performance	1200 watts, 120 V 60 Hz
Safety Mechanisms	Over 10, including overheat protection, easy seal safety lid lock
UPC	810028585188
Country of Origin	China

Warranty and Support

For detailed warranty information and comprehensive support, please refer to the official User Manual (PDF) provided with your Instant Pot Duo Plus. You can also visit the Instant Pot Store on Amazon for additional product information and resources.

© 2024 Instant Pot. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question