Tefal FV5841U0

T-Fal Ultraglide Steam Iron FV5841U0 Instruction Manual

Model: FV5841U0 | Brand: Tefal

Introduction

The T-Fal Ultraglide Steam Iron FV5841U0 is designed to make ironing ultra-smooth and efficient. Featuring a patented Durilium AirGlide soleplate, this iron effortlessly glides across garments, offering superior scratch resistance and long-lasting performance. With 1800 watts of power, it ensures fast heat-up and powerful steam output for effective wrinkle removal.

This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your T-Fal Ultraglide Steam Iron.

Important Safety Instructions

When using your iron, basic safety precautions should always be followed:

- Read all instructions before using the iron.
- Use the iron only for its intended use.
- To protect against a risk of electric shock, do not immerse the iron in water or other liquids.
- Always turn the iron OFF before plugging or unplugging from the outlet. Never yank cord to disconnect from outlet; instead, grasp plug and pull to disconnect.
- Do not allow cord to touch hot surfaces. Let iron cool completely before putting away. Loop cord loosely around iron when storing.
- The iron should always be turned to "Min" before plugging or unplugging from outlet.
- Do not operate iron with a damaged cord or if the iron has been dropped or damaged. To avoid the risk of electric shock, do not disassemble the iron; take it to a qualified serviceman for examination and repair. Incorrect reassembly can cause a risk of electric shock when the iron is used.
- Close supervision is necessary for any appliance being used by or near children. Do not leave iron unattended while connected or on an ironing board.
- Burns can occur from touching hot metal parts, hot water, or steam. Use caution when you turn a steam iron upside down – there may be hot water in the reservoir.
- The iron must be used and rested on a stable surface.
- When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.

- The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.

Auto-Off Feature: For enhanced safety, the iron is equipped with an auto-off function:

- Shuts off in 30 seconds if left horizontally or on its side.
- Shuts off in 8 minutes if left upright.

Product Components



Overall View: The T-Fal Ultraglide Steam Iron FV5841U0 in Teal and Black.



*20% LESS ENERGY COMPARED WITH ENERGY CONSUMPTION AT MAXIMUM OUTPUT LEVEL

Key Features Diagram: Illustrates the iron's main features including Eco-friendly mode, 100g/min steam burst, cold spray control, steam control, built-in spray for deep creases, precision tip, and ultra scratch-resistant Durilium AirGlide soleplate.



Durilium AirGlide Soleplate: Patented soleplate providing the speed of nonstick with the durability of stainless steel, ensuring extremely scratch-resistant performance.



Anti-Drip System: Prevents water drips and white marks on your garments during ironing. Features a built-in cleaning system to capture mineral build-up.

WORRY FREE AUTO-OFF



Worry-Free Auto-Off: The iron automatically shuts off after 30 seconds horizontally or on its side, and after 8 minutes when left upright, enhancing safety.



Vertical Steaming: Allows for de-wrinkling garments and refreshing fabrics without the need for an ironing board.

Setup

Before First Use:

It is normal to find condensation or water droplets inside the water tank upon unboxing. This is due to the manufacturer's pre-testing process to ensure proper functionality.

Filling the Water Tank:

1. Ensure the iron is unplugged from the power outlet.
2. Set the steam control to the 'Dry Ironing' position (no steam).
3. Open the water filling inlet cover located on the top of the iron.
4. Fill the water tank with tap water up to the 'MAX' level indicator. Do not overfill.
5. Close the water filling inlet cover securely.

Note: Tap water is recommended for this iron. Distilled water is not necessary and may not provide optimal performance.

Operating Instructions

Powering On and Temperature Selection:

1. Plug the iron into a suitable power outlet. The indicator light will illuminate.
2. Turn the temperature dial to select the desired heat setting based on the fabric type. Settings include:
    - Delicate (low heat)
    - Wool
    - Cotton
    - Max (high heat)
    - Eco Mode (uses 20% less energy)
3. Allow the iron to heat up until the indicator light turns off, signaling that the selected temperature has been reached.

Steam Ironing:

- Ensure the water tank is filled.
- Set the temperature dial to a steam-compatible setting (typically Wool, Cotton, or Max).
- Adjust the steam control slider to the desired steam output (continuous steam up to 30 g/min).
- For stubborn creases, press the steam boost button to deliver an extra burst of steam (up to 100 g/min).

Vertical Steaming:

- Hang the garment on a hanger.
- Hold the iron in a vertical position, close to the fabric but not touching it.
- Press the steam boost button to release steam and remove wrinkles.

Spray Function:

- Press the spray button to lightly mist the fabric with water, which helps in smoothing out tough wrinkles.

Precision Tip:

- The pointed tip of the soleplate allows for easy access to difficult areas such as collars, cuffs, and around buttons.

Maintenance and Cleaning

Built-in Cleaning System (Anti-Calc):

The iron features a built-in cleaning system to prevent mineral build-up and prolong its lifespan. Refer to the full user manual for detailed calc cleaning instructions, typically recommended monthly.

Emptying the Water Tank:

- After each use, unplug the iron and allow it to cool completely.
- Open the water filling inlet cover and invert the iron over a sink to drain any remaining water.

- Close the cover and store the iron upright.

Soleplate Cleaning:

- To clean the soleplate, use a damp cloth and a non-abrasive cleaner.
- Do not use abrasive scouring pads or harsh chemicals, as these can damage the Durilium AirGlide coating.

Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet issue; auto-off activated.	Check power cord connection; test outlet with another appliance; move iron to reactivate.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam control set to 'Dry Ironing'.	Fill water tank; set temperature to steam-compatible range (Wool, Cotton, Max); adjust steam control.
Water leaking from soleplate.	Temperature too low for steam; iron overfilled; calc build-up.	Increase temperature; do not overfill; perform calc cleaning.
White marks on clothes.	Mineral deposits from water.	Perform calc cleaning regularly.

If the problem persists after attempting these solutions, please refer to the full user manual or contact customer support.

Specifications

- **Brand:** Tefal
- **Model Name:** Ultraglide
- **Item Model Number:** 83430
- **Power:** 1800 Watts
- **Soleplate Material:** Durilium AirGlide (Aluminum)
- **Special Features:** Steam Boost Function, Vertical Steaming, Anti-Drip, Auto-Off
- **Color:** Teal, Black
- **Product Dimensions:** 12"L x 6"W
- **Item Weight:** 3.63 pounds
- **UPC:** 023108834308
- **Country of Origin:** China

Warranty and Support

Warranty: This T-Fal Ultraglide Steam Iron FV5841U0 comes with a 1 Year Limited Warranty.

For detailed warranty terms, service, or additional support, please refer to the official T-Fal User Manual PDF available online or contact T-Fal customer service.

Official User Manual (PDF): Download Here