Mattel GWD70

Mattel Jurassic World Dominion Uncaged Ultimate Pyroraptor Dinosaur Toy Instruction Manual

Model: GWD70

1. Introduction

The Mattel Jurassic World Dominion Uncaged Ultimate Pyroraptor is an interactive action figure designed to bring the excitement of the Jurassic World Dominion movie to life. This electronic dinosaur toy features a wide attacking jaw, rotating body, raising and lowering tail, animated eyebrows, and feathers that stand at attention. With multiple touch sensors, it reacts to interaction in various play modes, offering a dynamic and engaging play experience.



Image: The Ultimate Pyroraptor toy, showcasing its detailed design and interactive features.

2. Safety Information

- **Age Recommendation:** This toy is suitable for children aged 5 years and older.
- **Battery Safety:** Use only the specified battery type and ensure correct polarity. Do not mix old and new batteries, or different types of batteries. Remove exhausted batteries promptly.
- **Choking Hazard:** This product may contain small parts. Not for children under 3 years.
- **Supervision:** Adult supervision is recommended during play.

3. Package Contents

Ensure all items are present upon unboxing:

- 1 x Ultimate Pyroraptor Dinosaur Toy
- Instruction Manual



Image: The Ultimate Pyroraptor in its retail packaging.

4. Setup

4.1. Battery Installation

The Ultimate Pyroraptor requires 3 AAA batteries (not included) for full functionality. To install the batteries:

1. Locate the battery compartment on the underside of the dinosaur's body.
2. Using a Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the cover and secure it with the screw.

Once batteries are installed, locate the ON/OFF switch, usually near the battery compartment, and slide it to the 'ON' position to activate the toy.

5. Operating Modes

The Ultimate Pyroraptor features multiple interactive modes, each indicated by a different eye color and unique behaviors.

The toy responds to touch sensors located on its head and body.

5.1. Wild Mode

In Wild Mode, the Pyroraptor's eyes glow**red**, and its hackles are raised. The dinosaur will not respond to direct commands and exhibits unpredictable, untamed behavior, roaring and moving independently. This mode simulates a wild, untamed dinosaur.



Image: The Pyroraptor in its aggressive Wild Mode, indicated by red eyes.

5.2. Training Mode

In Training Mode, you can attempt to tame the Pyroraptor. Its eyes glow**yellow**. Tap specific sensors on its head to give commands and teach it sequences of up to six movements. Refer to the included instruction sheet for precise touch points and command sequences. This mode helps develop skills in taming the dinosaur.



Image: The Pyroraptor in Training Mode, ready to learn commands with yellow eyes.

5.3. Play Mode (Challenge Mode)

Play Mode allows for interactive play where the Pyroraptor's eyes glow**blue**. This mode includes a challenge where you follow the dinosaur's movements and test your memory. It offers up to 30 movement combinations. Be careful, incorrect responses may trigger an attack from the dinosaur!



Image: The Pyroraptor in Play Mode, with blue eyes indicating readiness for interactive challenges.

5.4. Mode Demonstration Video

Watch this official demonstration video to see the different modes and interactive features of the Ultimate Pyroraptor in action:

Your browser does not support the video tag.

Video: Official Mattel demonstration of the Jurassic World Dominion Uncaged Ultimate Pyroraptor, showcasing its various interactive modes and movements.

6. Maintenance

6.1. Cleaning

To clean the Pyroraptor, gently wipe its surface with a damp cloth. Do not immerse the toy in water or use harsh chemicals, as this may damage the electronic components.

6.2. Storage

When not in use, store the toy in a cool, dry place away from direct sunlight. Remove batteries if the toy will not be used for an extended period to prevent battery leakage.

7. Troubleshooting

- **Toy not responding:** Ensure the batteries are correctly installed and not depleted. Check that the ON/OFF switch is in the 'ON' position.
- **Unexpected behavior:** The dinosaur's behavior is mode-dependent. If it's acting 'wild', it might be in Wild Mode. Refer to the operating modes section to understand expected behavior for each mode.
- **Sound issues:** Check battery levels. If sounds are distorted or absent, replace batteries.

8. Specifications

Feature	Detail
Brand	Mattel
Model Name	Jurassic World Uncaged Ultimate Fire Dino

Model Number	GWD70
Item Dimensions (L x W x H)	21.26" x 7.09" x 10.24"
Item Weight	1.2 Kilograms
Material Type	Plastic
Age Range	5 years and older
Battery Requirements	3 AAA batteries (not included)
Additional Features	Sound, Interactive Motion, Multiple Play Modes

9. Warranty and Support

Manufacturer Warranty: This product comes with no manufacturer warranty.
For further assistance or inquiries, please refer to the contact information provided on the product packaging or visit the official Mattel website.

© 2024 Mattel. All rights reserved. Jurassic World Dominion © Universal City Studios LLC and Amblin Entertainment, Inc. All Rights Reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question