Mattel HJM23

Mattel Marvel Groovin’ Groot Dancing & Talking Figure - Instruction Manual

Product Overview

The Mattel Marvel Groovin’ Groot Dancing & Talking Figure brings the beloved character from the Disney+ series *I Am Groot* to life. This 11-inch plush figure features movement and sound, allowing it to groove to music and speak its iconic phrase. Designed for fans and collectors aged 3 years and up, it offers interactive play and display.





Image: The Mattel Marvel Groovin’ Groot Dancing & Talking Figure, an 11-inch plush toy with a molded head and soft body, ready for play.

Key Features

- Groovin' Groot Plush figure comes to life with movement and sound inspired by the beloved Marvel character.
- Play music near Groot Plush to watch him groove to the beat with dance moves.
- Press the soft doll's chest to hear the iconic phrase, "I am Groot," in several different inflections.
- Approximately 11-inches tall, the character plush is perfect for cuddling or display.
- Inspired by the Disney+ series *I Am Groot*, the soft toy makes a great gift or collectible for fans of all ages.

Setup

Battery Installation

The Groovin' Groot figure requires 3 AAA batteries (not included). Follow these steps for proper installation:

1. Locate the battery compartment on the bottom of the figure's feet.
2. Use a small screwdriver to open the battery compartment cover.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Note: For optimal performance, use new alkaline batteries.



Image: The Groovin' Groot figure's feet, indicating the location of the battery compartments and the on/off switch.

Video: This video demonstrates the location of the battery compartments and the on/off switch on the Groovin' Groot

figure's feet, along with a brief demonstration of its talking feature.

Operating Instructions

Power On/Off

Locate the ON/OFF switch on the bottom of one of Groot's feet. Slide the switch to the 'ON' position to activate the figure. Slide to 'OFF' when not in use to conserve battery life.

Dancing to Music

Place the Groovin' Groot figure near a music source. The figure is sound-activated and will begin to groove and dance to the beat of the music. For best results, ensure the music is played at a moderate volume close to the figure.



Image: A young boy smiling and playing with the Groovin' Groot figure. The figure is designed to dance when music is played nearby, providing interactive fun.

Video: This video showcases the Groovin' Groot figure dancing to music, demonstrating its sound-activated movement feature.

Talking Feature

To hear Groot speak his iconic phrase, "I am Groot," press the button located on his chest. Each press will trigger a different inflection of the phrase.



Image: A hand pressing the chest of the Groovin' Groot figure. Pressing this area activates its talking feature, where it says 'I am Groot' in various tones.

Video: This video demonstrates the Groovin' Groot figure speaking its iconic phrase 'I am Groot' when its chest is pressed, and also shows its dancing motion.

Maintenance and Care

Cleaning

To clean the plush body of the Groovin' Groot figure, gently wipe with a damp cloth. Do not immerse the figure in water or use harsh cleaning agents, as this may damage the electronic components.

Storage

When not in use for extended periods, turn the figure off and remove the batteries to prevent leakage.

Store in a cool, dry place away from direct sunlight.

Troubleshooting

Figure Not Responding

- **Check Batteries**: Ensure batteries are correctly installed and not depleted. Replace with new AAA batteries if necessary.
- **Power Switch**: Verify the ON/OFF switch on the foot is in the 'ON' position.
- **Sound Activation**: If dancing to music, ensure the music source is close enough and at an adequate volume for the figure's sound sensor to detect it.
- **Chest Button**: If the talking feature is not working, ensure the chest button is being pressed firmly.

Movement or Sound is Weak

- **Low Batteries**: This is often an indication of low battery power. Replace all batteries with new ones.

Product Specifications

- **Model Number**: HJM23
- **Product Dimensions**: 5.91 x 7.48 x 11.02 inches
- **Item Weight**: 1.46 pounds
- **Recommended Age**: 3 years and up
- **Batteries Required**: 3 AAA batteries (not included)
- **Contents**: 1 11-inch plush figure
- **Manufacturer**: Mattel

Warranty Information

This product is covered by Mattel's standard limited warranty. For specific details regarding warranty coverage, duration, and claims process, please refer to the documentation included with your purchase or visit the official Mattel website.

Customer Support

For further assistance, product inquiries, or technical support, please contact Mattel Customer Service. Contact information can typically be found on the product packaging or on the official Mattel website.

© 2026 Mattel. All rights reserved.