AOOGITF M666

AOOGITF M666 MP3 Player User Manual

Model: M666 | Brand: AOOGITF

1. Product Overview

The AOOGITF M666 is a versatile 64GB MP3 player designed for high-fidelity audio playback. It features Bluetooth 5.2 connectivity, an integrated speaker, FM radio, and a voice recorder. Its compact metal body and 2.4-inch color display make it a portable and user-friendly device for enjoying music and other audio content.

2. Safety Information

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble or attempt to repair the device yourself. This may void the warranty and cause damage.
- Use only the provided or certified charging cables and adapters.
- Listen at moderate volume levels to prevent hearing damage.
- Keep out of reach of children.

3. Package Contents

Please check the package for the following items:

- AOOGITF M666 MP3 Player
- Wired Headphones
- USB Charging/Data Cable
- User Manual (this document)

4. Device Layout





Image: Front and back view of the AOOGITF M666 MP3 Player, showing the screen, control buttons, and rear speaker grille.

The AOOGITF M666 MP3 player features a sleek design with a 2.4-inch color display on the front. Below the screen are touch-sensitive control buttons for navigation and playback. The device has a metallic body, with a speaker grille visible on the back. On the sides, you will find physical buttons for power, volume control, and a slot for a micro SD card (if expandable storage is supported, though not explicitly stated for this model). A USB port is located at the bottom for charging and data transfer, alongside a 3.5mm headphone jack.

5. Setup

5.1 Charging the Device

Before first use, fully charge the MP3 player. Connect the provided USB cable to the device's USB port and the other end to a USB power adapter (not included) or a computer's USB port. The battery indicator on the screen will show charging status. A full charge typically takes a few hours.

5.2 Transferring Music and Files

1. Connect the MP3 player to your computer using the USB cable.
2. The device will appear as a removable disk drive on your computer.
3. Drag and drop your music files (MP3, FLAC, etc.) and other supported media into the appropriate folders on the device.
4. Once transfer is complete, safely eject the device from your computer before disconnecting the USB cable.

5.3 Initial Power On

Press and hold the Power button (usually on the side) for a few seconds until the screen lights up. Follow any on-screen prompts for initial setup, such as language selection.

6. Operating Instructions

6.1 Basic Navigation

Use the touch-sensitive buttons below the screen to navigate through menus. The central button typically acts as 'Enter' or 'Select', while the arrow buttons allow you to move up, down, left, and right. A 'Back' or 'Return' button is usually present to go back to the previous screen.

6.2 Music Playback

1. From the main menu, select 'Music'.
2. Browse by Artist, Album, Song, or Folder.
3. Select a song to begin playback.
4. Use the playback controls (Play/Pause, Next/Previous, Volume Up/Down) to manage your music.

6.3 Bluetooth Connection

1. Go to 'Settings' and then 'Bluetooth'.
2. Turn Bluetooth 'On'.
3. The player will search for nearby Bluetooth devices.
4. Select your desired Bluetooth headphones or speaker from the list to pair.
5. Once paired, audio will be routed through the Bluetooth device.

6.4 FM Radio

1. Plug in the wired headphones; they act as the antenna for the FM radio.
2. From the main menu, select 'FM Radio'.
3. Use the 'Auto Search' function to scan and save available radio stations.
4. Navigate between saved stations or manually tune to a frequency.

6.5 Voice Recorder

1. From the main menu, select 'Recorder' or 'Voice Record'.
2. Press the 'Record' button to start recording.
3. Press 'Stop' to end the recording.
4. Recordings are typically saved in a dedicated folder and can be played back from the 'Recordings' or 'Files' menu.

7. Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the device. Do not use liquid cleaners or aerosols.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device

regularly, even if not in use for extended periods.

8. Troubleshooting

Problem	Possible Cause	Solution
Device won't turn on	Low battery; System crash	Charge the device; Press and hold the power button for 10-15 seconds to force restart.
No sound	Volume too low; Headphones not connected properly; Corrupt audio file	Increase volume; Re-insert headphones; Try a different audio file.
Bluetooth won't connect	Bluetooth off; Device out of range; Pairing mode not active	Ensure Bluetooth is on for both devices; Move closer; Put the other device in pairing mode.
Files not playing	Unsupported format; Corrupt file	Ensure files are MP3 or FLAC; Re-transfer the file.
Device freezes	Software issue	Press and hold the power button for 10-15 seconds to force restart.

9. Specifications

- **Model:** M666
- **Brand:** AOOGITF
- **Storage Capacity:** 64 GB
- **Display:** 2.4-inch Color Screen
- **Connectivity:** Bluetooth 5.2, USB
- **Supported Audio Formats:** MP3, FLAC
- **Battery Type:** Lithium Polymer
- **Average Battery Life:** Up to 24 hours (playback dependent)
- **Dimensions:** 5 x 0.88 x 10.6 cm
- **Weight:** 98.5 g
- **Special Features:** Integrated Speaker, FM Radio, Voice Recorder

10. Warranty and Support

This product comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or contact AOOGITF customer support. If you encounter any issues not covered in this manual, please reach out to our support team for assistance.
For support inquiries, please visit the official AOOGITF website or contact the retailer where you purchased the product.

© 2023 AOOGITF. All rights reserved.