**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**MUMUWIND MMF-203B**

# MUMUWIND MMF-203B Portable Karaoke Machine User Manual

Model: MMF-203B

## 1. Introduction

Thank you for choosing the MUMUWIND MMF-203B Portable Karaoke Machine. This device is designed to provide a professional and enjoyable karaoke experience with its powerful sound, wireless microphones, and versatile connectivity options. It serves as a dynamic all-in-one PA system, music speaker, and karaoke machine, perfect for entertainment for all ages.




Image 1.1: The MUMUWIND MMF-203B Portable Karaoke Machine with its two wireless microphones.

## 2. Package Contents

Please check the package carefully to ensure all items are present:

- 1 x Portable Karaoke Speaker
- 2 x Wireless Handheld Microphones
- 1 x AUX Cable
- 1 x USB-C Charging Cable
- 1 x User Manual (English)




Image 2.1: Front view of the product packaging, showing the speaker and two microphones.

## 3. Product Features

The MUMUWIND MMF-203B offers a range of features for an enhanced karaoke experience:

- **Portable Design:** Compact size with powerful sound, easy to carry for any occasion.
- **Dual Wireless Microphones:** Includes two powerful microphones that can be used simultaneously for duets or singing competitions.
- **Bluetooth 5.0 Connectivity:** Seamlessly stream music wirelessly from smartphones, tablets, and other Bluetooth-enabled devices.
- **Multiple Audio Inputs:** Supports TF card, USB drive, and 3.5mm AUX input for versatile music playback options.
- **Voice Changing Modes:** Features 5 different voice changing effects (Original, Monster Sound, Male, Female, Baby) for added fun.
- **Vocal Cut Function:** One-click button to eliminate original vocals from songs, allowing users to sing along to instrumental tracks.

- **Long Battery Life:** Built-in rechargeable batteries provide extended playtime for both the speaker and microphones.




Image 3.1: The microphone features 5 voice changing modes: Original, Monster Sound, Male, Female, and Baby.




Image 3.2: The top panel of the speaker features AUX-IN, USB, TF card, and Charging ports for diverse connectivity.

## 4. Setup Guide

### 4.1 Charging the Device

Before first use, fully charge the speaker and both microphones.

- **Speaker:** Connect the USB-C charging cable to the speaker's charging port and a 5V/2.5A power adapter (not included). The speaker battery is 3000mAh, requiring 3-5 hours for a full charge.
- **Microphones:** Connect the USB-C charging cable to each microphone's charging port. Each microphone battery is 1500mAh, requiring 2-3 hours for a full charge.

### 4.2 Powering On/Off

- **Speaker:** Press and hold the power button on the speaker's control panel until the indicator light turns on.
- **Microphones:** Press and hold the power button on each microphone until the indicator light turns on.

### 4.3 Automatic Pairing

The speaker and microphones are designed to automatically pair with each other once both are turned on. No manual pairing is required.

### 4.4 Connecting to Audio Sources

The karaoke machine supports multiple connection methods:

- **Bluetooth Connection:**
    1. Turn on the speaker. It will automatically enter Bluetooth pairing mode.
    2. On your smartphone, tablet, or other Bluetooth device, go to Bluetooth settings and search for "YSD Speaker" or similar.
    3. Select the device to connect. A confirmation sound will indicate successful pairing.
- **AUX-IN Connection:**
    1. Use the provided AUX cable to connect the speaker's AUX-IN port to the audio output port of your external device (e.g., TV, computer).
    2. The speaker will automatically switch to AUX mode.
- **USB/TF Card Playback:**
    1. Insert a USB drive or TF (MicroSD) card containing MP3 audio files into the respective port on the speaker.
    2. The speaker will automatically detect and play the audio files.




Image 4.1: Connection methods for the karaoke machine, including Bluetooth for compatible TVs and AUX for TVs without Bluetooth.




Image 4.2: The speaker supports audio playback via Bluetooth from a smartphone and direct input from USB or TF cards.

## 5. Operating Instructions

### 5.1 Speaker Controls

The speaker's control panel features buttons for various functions:

- **Power Button:** Press and hold to turn on/off.
- **Volume Up/Down:** Adjust the overall speaker volume.
- **Echo Control:** Adjust the echo effect level for the microphones.
- **Vocal Cut:** Press this button to reduce or eliminate the original vocals from a song playing through the speaker.
- **Mode Button:** Switch between Bluetooth, AUX, USB, and TF card input modes.
- **Play/Pause:** Control music playback.
- **Previous/Next Track:** Navigate through songs.

### 5.2 Microphone Controls

Each wireless microphone has its own set of controls:

- **Power Button:** Press and hold to turn on/off.
- **Volume Up/Down:** Adjust the individual microphone volume.
- **EFF Button (Voice Changer):** Press to cycle through the 5 voice changing modes: Original, Monster Sound, Male, Female, and Baby.

### 5.3 Using the Vocal Cut Function

To use the vocal cut feature, ensure music is playing through the speaker. Press the "VOVAL CUT" button on the speaker's control panel. This function attempts to reduce or remove the lead vocals from the playing track, allowing you to sing along to the instrumental version.

## 6. Maintenance and Care

To ensure the longevity and optimal performance of your karaoke machine, follow these maintenance guidelines:

- **Cleaning:** Wipe the speaker and microphones with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the batteries frequently. Charge the device regularly, even if not in use for extended periods.
- **Avoid Water:** Keep the device away from water and moisture. Do not immerse it in any liquid.
- **Handle with Care:** Avoid dropping or subjecting the device to strong impacts.

## 7. Troubleshooting

If you encounter issues with your MUMUWIND MMF-203B, please refer to the following common problems and solutions:

- **No Sound from Speaker:**
  - Ensure the speaker is powered on and charged.
  - Check the volume level on both the speaker and the connected audio source.
  - Verify that the correct input mode (Bluetooth, AUX, USB, TF) is selected.
  - If using Bluetooth, ensure the device is properly paired and within range.
- **Microphones Not Working:**
  - Ensure both microphones are powered on and fully charged.
  - Confirm that the microphones have automatically paired with the speaker. If not, try turning both off and on again.
  - Check the microphone volume levels on the microphones themselves.
- **Vocal Cut Function Not Effective:**
  - The effectiveness of the vocal cut function can vary depending on the original song's mixing. It may not completely remove vocals from all tracks.
  - Ensure the music source is playing clearly.
- **Bluetooth Disconnection:**
  - Ensure the connected device is within the 10M transmission range.
  - Check for interference from other wireless devices.
  - Try unpairing and re-pairing the Bluetooth connection.

## 8. Specifications

| Feature | Specification |
|---|---|
| Brand | MUMUWIND |
| Model | MMF-203B |
| Bluetooth Version | V5.0 |
| Transmission Range | 10M |
| Speaker Battery | 3000mAh (Built-in Lithium Battery) |
| Speaker Charging Time | 3~5 Hours |
| Microphone Battery | 3.7V 1500mAh x 2pcs (Built-in Lithium Battery) |
| Microphone Charging Time | 2~3 Hours |
| Standby Time | 1.5 hours (Note: This might refer to microphone standby time, as speaker playtime is 3-5 hours) |
| Frequency Range | 20Hz-10KHz |
| Power Supply Voltage | DC 5V |
| Input Options | Bluetooth, TF card, USB hard drive, 3.5mm AUX |
| Speaker Max Output Power | 5 Watts |
| Product Dimensions | 16 x 16 x 17 cm |
| Item Weight | 1.25 kg |
| Material Type | Plastic |

## 9. Warranty and Support

The MUMUWIND MMF-203B Karaoke Machine comes with a **1-year warranty**. For any questions, concerns, or support needs regarding your product, please feel free to contact us via Amazon message. We are committed to providing assistance anything and anytime.

© 2024 MUMUWIND. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B09P1J5P7Q**

More documents and user manuals: **https://manuals.plus/**