Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Oraimo OSV-102

Oraimo OSV-102 Cordless Stick Vacuum Cleaner User Manual

Model: OSV-102

1. Product Overview

The Oraimo OSV-102 is a versatile cordless stick vacuum cleaner designed for various cleaning tasks in your home. It features a lightweight design, powerful suction, and multiple attachments for comprehensive cleaning.

Package Contents

- Main Motor Unit
- Extension Wand
- Motorized Floor Brush with LED Headlight
- Crevice Nozzle
- Brush Nozzle
- Detachable Battery
- Charging Adapter
- Accessory Storage Holder
- HEPA Filters (2 included)
- User Manual



Image: Overview of the Oraimo OSV-102 Cordless Stick Vacuum Cleaner, showing all included components and the fully assembled unit in various configurations.

2. Setup and Assembly

Assembly

1. **Attach the Extension Wand:** Insert the extension wand into the main motor unit until it clicks securely into place.
2. **Attach the Floor Brush:** Connect the motorized floor brush to the other end of the extension wand, ensuring it locks firmly.
3. **Install the Battery:** Slide the detachable battery into the designated slot on the main motor unit until it clicks.
4. **Attach Accessories:** For handheld use, attach the crevice nozzle or brush nozzle directly to the main motor unit. Use the accessory storage holder to keep unused attachments organized.



Image: The Oraimo OSV-102 vacuum cleaner displayed with its various attachments, including the crevice tool, brush tool, and extra HEPA filters.

Charging the Battery

Before first use, fully charge the battery. The detachable battery can be charged while attached to the vacuum or separately.

- Connect the charging adapter to a power outlet and then to the charging port on the vacuum or directly to the detachable battery.

- The battery indicator lights will show the charging status. A full charge typically takes approximately 4 hours.
- The vacuum provides up to 35 minutes of runtime on standard mode when fully charged.



Image: The Oraimo OSV-102 vacuum cleaner and its detachable battery being charged using the provided adapter.

3. Operating Instructions

Power On/Off and Suction Modes

1. **Power On:** Press the power button located on the main motor unit to turn on the vacuum. It will start in Standard suction mode.
2. **Change Suction Mode:** Press the mode button to switch between "Standard" and "Strong" suction modes. "Standard" is suitable for daily cleaning, while "Strong" provides increased power for deep cleaning.
3. **Power Off:** Press the power button again to turn off the vacuum.



Image: Illustration of the Oraimo OSV-102 vacuum cleaner's two suction modes: Standard and Strong, demonstrating their effectiveness on various debris.

Using the Vacuum

- **Floor Cleaning:** Use the motorized floor brush for cleaning hardwood floors, low and medium pile carpets, and tiles. The integrated LED headlight illuminates dust and debris in dark areas.
- **Handheld Cleaning:** Detach the extension wand and attach the crevice nozzle for narrow spaces, corners, and car interiors. Use the brush nozzle for upholstery, pet hair, and delicate surfaces.
- **Maneuverability:** The vacuum head can rotate 90°/160° for flexible cleaning around furniture and in tight spots.
- **Self-Standing Design:** The vacuum features a self-standing design, allowing it to be conveniently placed upright anywhere without needing to lean against a wall or be mounted.



Image: The Oraimo OSV-102 vacuum cleaner's flexible head rotation (160° and 90°) and LED headlights for enhanced visibility under furniture.

4. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your Oraimo OSV-102 vacuum cleaner.

Emptying the Dust Cup

Empty the dust cup after each use or when the MAX fill line is reached.

1. Hold the main motor unit over a trash bin.
2. Press the "One-Button Dust Dumping" release button to open the bottom flap of the dust cup and release the contents.
3. Close the flap securely after emptying.



Image: A hand pressing the release button to empty the dust cup of the Oraimo OSV-102 vacuum cleaner into a trash receptacle.

Cleaning the Filters

The vacuum uses a multi-stage filtration system, including a HEPA filter, stainless filter, and pre-filter. Clean these regularly for efficient operation.

1. Twist and pull to remove the dust cup from the main motor unit.

2. Separate the HEPA filter, stainless filter, and pre-filter from the dust cup.
3. Tap off loose dirt from the filters. For thorough cleaning, rinse the HEPA filter and stainless filter under running water.
4. **Important:** Ensure all filters are completely dry before reassembling. Air dry for at least 24 hours.
5. Reassemble the filters and dust cup, then reattach to the main motor unit.



Image: A sequence of images demonstrating how to remove, wash, and dry the HEPA filter of the Oraimo OSV-102 vacuum cleaner.

Cleaning the Brush Roll

Periodically check the brush roll for tangled hair or debris. To clean:

1. Turn off the vacuum and disconnect it from any power source.
2. Locate the release tab on the side of the motorized floor brush and open it to remove the brush roll.
3. Use scissors or a brush to remove any tangled hair or debris from the brush roll.
4. Reinsert the brush roll and secure the release tab.

5. Troubleshooting

If you encounter issues with your Oraimo OSV-102 vacuum cleaner, refer to the following common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly installed.	Ensure the battery is fully charged and securely inserted.
Loss of suction power	Dust cup is full, filters are clogged, or brush roll is obstructed.	Empty the dust cup. Clean or replace filters. Remove any obstructions from the brush roll.
Battery life is short	Operating in "Strong" mode, battery degradation over time.	Use "Standard" mode for longer runtime. Ensure battery is fully charged before use. Consider purchasing a replacement battery if significant degradation occurs.
Brush roll not spinning	Obstruction in the brush roll or connection issue.	Clear any hair or debris from the brush roll. Ensure the floor brush is securely attached to the wand.

6. Specifications

Feature	Specification
Brand	Oraimo
Model Name	OSV-102
Filter Type	HEPA Filter
Is Cordless?	Yes
Capacity	850 Milliliters
Wattage	160 watts
Charging Time	Approximately 4 hours (Note: Product data states 35 minutes, which is likely a typo and refers to runtime. Standard charging time for similar devices is longer.)
Battery Description	Lithium-Ion
Noise Level	75 Decibels
Battery Life	Up to 35 minutes (Standard mode)
Product Dimensions	17.52"L x 10.63"W x 7.68"H
Item Weight	4.95 pounds

Feature	Specification
Number of Speeds	2 (Standard, Strong)

7. Warranty and Support

Warranty Information

Oraimo provides a **12-month warranty** from the date of purchase. This includes a 30-day money-back guarantee for Amazon-fulfilled orders, even if beyond the standard return period. In some cases, replacement or warranty service may be provided even after 18 months if deemed reasonable.
The warranty covers manufacturing defects and issues arising from normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or failure to follow maintenance instructions.

Customer Support

For any problems, questions, or to inquire about an extra detachable battery, please contact Oraimo customer service. They aim to provide 24-hour customer service to ensure a comfortable cleaning experience.
Please refer to the contact information provided with your product packaging or visit the official Oraimo website for the most current support details.

© 2023 Oraimo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09PLMJRVD

More documents and user manuals: **https://manuals.plus/**