SOGO SS-14506

SOGO SS-14506 3-in-1 Stand Mixer User Manual

Introduction

Thank you for purchasing the SOGO SS-14506 3-in-1 Stand Mixer. This appliance is designed to assist you with various kitchen tasks, including mixing, blending, and kneading. To ensure safe and efficient operation, please read this manual thoroughly before first use and retain it for future reference.

Safety Information

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Keep hands, hair, clothing, and utensils away from moving parts during operation to prevent injury.
- Do not immerse the motor unit in water or any other liquid.
- This appliance is for household use only. Do not use outdoors.
- Supervise children closely when the appliance is in use.
- Do not operate the mixer with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Place the mixer on a stable, flat, and dry surface during operation.

Product Overview

The SOGO SS-14506 is a versatile kitchen appliance featuring a powerful 350W motor and a 3.2-liter stainless steel rotating bowl. It comes with two types of attachments: stainless steel beaters for mixing and blending, and stainless steel dough hooks for kneading. The mixer offers 5 speed settings for optimal control over various recipes.



Image 1: Front view of the SOGO SS-14506 Stand Mixer with its stainless steel mixing bowl.



Image 2: The SOGO SS-14506 Stand Mixer showcasing its included beaters and dough hooks, alongside examples of prepared food.

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Cleaning:** Before first use, wash the stainless steel bowl, beaters, and dough hooks in warm soapy water, then rinse and dry thoroughly. Wipe the motor unit with a damp cloth.
3. **Placement:** Place the mixer on a clean, dry, and stable countertop.
4. **Attaching the Bowl:** Place the 3.2L stainless steel bowl onto the base of the mixer. Ensure it is securely seated.
5. **Selecting Attachments:** Choose the appropriate attachments for your task:
    - **Beaters:** For mixing batters, creams, and light doughs.
    - **Dough Hooks:** For kneading heavy doughs like bread or pizza dough.
6. **Inserting Attachments:** Ensure the mixer head is in the raised position. Insert the chosen attachments into

the designated slots on the underside of the mixer head until they click into place. Make sure they are fully engaged.

7. **Lowering the Mixer Head:** Gently lower the mixer head until it locks into position over the bowl.



Image 3: The mixer head tilted upwards, illustrating how to insert or remove attachments.

Operating Instructions

1. **Add Ingredients:** Place your ingredients into the stainless steel mixing bowl.
2. **Plug In:** Connect the power cord to a suitable electrical outlet (220V).
3. **Select Speed:** Use the speed control dial (0-5) to select the desired mixing speed. Start with a lower speed to prevent splashing, then gradually increase as needed.
    - **Speed 1-2:** For gentle mixing, combining dry ingredients, or kneading light dough.
    - **Speed 3-4:** For mixing batters, creaming butter and sugar, or whipping eggs.

- **Speed 5:** For whipping cream, egg whites, or heavy mixing tasks.

4. **Mixing:** Allow the mixer to operate until ingredients are thoroughly combined or the desired consistency is achieved. The bowl rotates automatically to ensure even mixing.
5. **Stopping:** Turn the speed dial to '0' to stop the mixer. Unplug the appliance from the power outlet.
6. **Removing Ingredients:** Lift the mixer head to access the bowl. Scrape down the sides of the bowl with a spatula if necessary. Remove the attachments by pressing the release button (if applicable) and pulling them out.



Image 4: The SOGO SS-14506 Stand Mixer in operation, mixing ingredients with the beaters.

Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your SOGO SS-14506 Stand Mixer.

1. **Always Unplug:** Ensure the mixer is unplugged from the power outlet before cleaning.
2. **Attachments and Bowl:** The stainless steel bowl, beaters, and dough hooks are dishwasher safe. Alternatively, they can be washed by hand in warm soapy water, rinsed thoroughly, and dried immediately to prevent water spots.
3. **Motor Unit:** Wipe the exterior of the motor unit with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the motor unit in water or any other liquid.

4. **Storage:** Store the mixer and its accessories in a clean, dry place when not in use.

Troubleshooting

If you encounter any issues with your SOGO SS-14506 Stand Mixer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mixer does not turn on.	Not plugged in; power outlet not working; appliance fault.	Check if the power cord is securely plugged in. Test the outlet with another appliance. If still not working, contact customer support.
Attachments are difficult to insert or remove.	Mixer head not fully raised; attachments not aligned correctly.	Ensure the mixer head is fully tilted up. Align the attachments with the slots and push firmly until they click.
Ingredients are not mixing evenly.	Too much or too little liquid; bowl not rotating properly.	Adjust ingredient quantities. Ensure the bowl is correctly seated on the rotating base. Scrape down sides of the bowl periodically.
Motor sounds strained or overheats.	Overloading the mixer; continuous operation for too long.	Reduce the amount of ingredients. Allow the mixer to cool down for at least 15-20 minutes before resuming use. Do not exceed recommended operating times for heavy loads.

Specifications

Technical details for the SOGO SS-14506 3-in-1 Stand Mixer:

Feature	Specification
Model Number	SS-14506
Power	350 Watts
Voltage	220 Volts
Bowl Volume	3.2 Liters
Number of Speeds	5
Material	Stainless Steel (bowl, beaters, dough hooks)
Product Dimensions (L x W x H)	35 x 32 x 25 cm
Item Weight	1.73 Kilograms
Dishwasher Safe Parts	Bowl, Beaters, Dough Hooks



Image 5: Dimensional diagram of the SOGO SS-14506 Stand Mixer and its mixing bowl.

Warranty and Support

SOGO products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official SOGO website. If you require technical assistance, spare parts, or have any questions not covered in this manual, please contact SOGO customer support through their official channels.