PROGRACE K1

PROGRACE Kids Camera K1 User Manual

Model: K1

Introduction

This manual provides essential information for the safe and effective use of your PROGRACE Kids Camera K1. Please read it thoroughly before operating the device to ensure optimal performance and longevity.

The PROGRACE Kids Camera K1 is designed to be a fun and educational tool for children aged 3-12, allowing them to capture photos and videos, play built-in games, and explore their creativity. It features a durable design, an IPS HD screen for eye protection, and a dual-lens system for easy selfies.

Package Contents

- 1x PROGRACE Kids Camera K1
- 1x USB Cable
- 1x Lanyard
- 1x User Manual
- 1x 32GB Micro SD Card



Image: The PROGRACE Kids Camera K1 shown alongside its included 32GB Micro SD card, highlighting the storage solution.

Setup Guide

1. Charging the Camera

Before first use, fully charge the camera for approximately 3 hours. Use the provided USB cable to connect the camera to a power source (e.g., computer USB port or a USB wall adapter). The charging indicator light will typically show the charging status.



Image: The PROGRACE Kids Camera K1 with the USB charging cable connected to its port.

2. Inserting the Micro SD Card

The camera requires a Micro SD card to store photos and videos. A 32GB card is included. Locate the SD card slot on the side of the camera. Gently insert the Micro SD card with the gold contacts facing down until it clicks into place.

Your browser does not support the video tag.

Video: A demonstration of unboxing the PROGRACE Kids Camera K1, including how to insert the 32GB Micro SD card into the camera slot.

3. Attaching the Lanyard

Attach the included lanyard to the designated loop on the camera. This helps prevent accidental drops and makes the camera easy for children to carry.



Image: The PROGRACE Kids Camera K1 with its pink lanyard attached, ready for use.

4. Powering On/Off

Press and hold the power button (usually located on the top or side) for a few seconds to turn the camera on or off. The IPS HD screen will light up upon activation.

Operating the Camera

Basic Controls

The camera features intuitive buttons for navigation and function selection:

- **Power Button:** Turns the camera on/off.
- **Shutter/OK Button:** Takes photos, starts/stops video recording, confirms selections.
- **Navigation Buttons (Up/Down/Left/Right):** Navigates menus, zooms in/out, switches between modes.
- **Mode Button:** Switches between photo, video, playback, and game modes.



Image: The PROGRACE Kids Camera K1 displaying its main menu with icons for various functions like photo, video, and games.

Taking Photos

In photo mode, aim the camera at your subject and press the Shutter button. The camera supports 40-megapixel resolution and auto-focus for clear images. Experiment with the 28 fun frames and 6 filters available in the settings to customize your pictures.



Image: The PROGRACE Kids Camera K1 showcasing various creative frames and filters that can be applied to photos.

Recording Videos

Switch to video mode using the Mode button. Press the Shutter button once to start recording and again to stop. The camera records in 1080P HD, capturing clear and vibrant moments.

Using the Dual Lens for Selfies

The camera features a dual-lens design, allowing for easy selfies. Simply switch to the front-facing camera mode (usually indicated by an icon or a specific button press) and capture your self-portraits or group photos.

Your browser does not support the video tag.

Video: A demonstration of the PROGRACE Kids Camera K1's dual camera feature, showing how to switch to selfie mode.

Playback Mode

Enter playback mode to view your captured photos and videos. Use the navigation buttons to scroll through your media. Press the Shutter button to play videos.

Deleting Photos/Videos

To delete individual photos or videos, enter playback mode, navigate to the desired media, and follow the on-screen prompts for deletion. To delete all media, there is usually an option within the settings or by holding a specific button in playback mode.

Your browser does not support the video tag.

Video: Instructions on how to delete individual photos/videos and all media from the PROGRACE Kids Camera K1.

Playing Built-in Games

The camera includes built-in puzzle games for entertainment. Navigate to the game icon in the main menu and select a game to play using the navigation and Shutter buttons.

Accessing Settings

The settings menu allows you to adjust various camera parameters, including photo size, video resolution, time-lapse options, language, and auto-off duration. Navigate to the gear icon in the main menu to access these options.

Key Features

- **IPS HD Screen:** 2.0-inch display with high color accuracy and wide 178° viewing angle for better eye protection.
- **High Resolution:** 40-megapixel photos and 1080P HD video recording with auto-focus.
- **Creative Effects:** Includes 28 fun frames, 6 filters, and 10 creative effects for photo customization.
- **Multi-Functional:** Supports burst shooting, voice recording, time-lapse photography, and 4/16x digital zoom.
- **Dual Lens Design:** Front and rear lenses for easy selfies and versatile shooting.
- **Built-in Games:** Includes puzzle games for added entertainment.
- **Long Battery Life:** Built-in 1000mAh rechargeable battery provides 3-4 hours of use on a full charge.
- **Expandable Storage:** Comes with a 32GB Micro SD card for ample photo and video storage.



Image: The PROGRACE Kids Camera K1 illustrating its 4x zoom capability and time-lapse function with children at a party.

Care and Maintenance

- Keep the camera clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Protect the lens and screen from scratches.
- Avoid exposing the camera to extreme temperatures, direct sunlight for prolonged periods, or moisture.
- Store the camera in a cool, dry place when not in use.
- Ensure the Micro SD card is properly inserted and removed to prevent damage.

Troubleshooting

- **Camera not turning on:** Ensure the battery is charged. Connect the camera to a charger for at least 30 minutes.

- **"No Media" message:** Check if the Micro SD card is correctly inserted. If it is, try reformatting the card (this will erase all data).
- **Camera frozen or unresponsive:** Use a thin object (like a toothpick or needle) to press the reset button, usually located in a small pinhole on the camera body. This will restart the device without losing data.

Your browser does not support the video tag.

Video: A demonstration of how to reset the PROGRACE Kids Camera K1 using a small tool to press the reset button.

Technical Specifications

Feature	Detail
Brand	PROGRACE
Model Name	Digital Camera for Kids
Model Number	K1
Photo Sensor Resolution	40 MP
Video Resolution	FHD 1080p
Screen Size	2 Inches (IPS HD)
Optical Zoom	16x
Digital Zoom	16.0
Memory Storage Capacity	32 GB (Micro SD included)
Battery Capacity	1000mAh
Item Weight	3.84 Ounces
Connectivity Technology	USB

Warranty and Support

Your PROGRACE Kids Camera K1 comes with a **2-Year Limited Warranty**. For warranty claims, technical support, or any questions regarding your product, please contact PROGRACE customer service through the retailer where the product was purchased or visit the official PROGRACE website.

For additional information and support, you may visit the PROGRACE Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question