onn. 681131309189

onn. AC Powered Computer Speakers User Manual

Introduction

Thank you for choosing the onn. AC Powered Computer Speakers. This manual provides essential information for setting up, operating, and maintaining your new speakers. Please read this manual thoroughly before use to ensure proper functionality and to maximize your audio experience.



Image: A pair of onn. AC Powered Computer Speakers, showcasing their compact design and front-facing speaker cones.

Package Contents

Ensure all items are present in the package:

- 2 x onn. AC Powered Computer Speakers

Product Features

- Connects easily through your computer's 3.5 mm AUX input jack.
- Integrated volume and bass controls for personalized audio.
- 6W RMS output / 12W peak output for clear and powerful sound.

- Integrated volume on/off switch for convenient power control.
- LED power indicator to show operational status.
- Attached AC power cord (4.26 ft / 1.3 m) for direct power supply.
- Attached 3.5 mm AUX Connector cable (4.26 ft / 1.3 m) for audio input.

Setup

Follow these steps to set up your onn. AC Powered Computer Speakers:

1. **Connect the Audio Cable:** Locate the 3.5 mm AUX connector cable attached to one of the speakers. Plug this cable into the 3.5 mm audio output jack on your computer, laptop, or tablet.
2. **Connect Power:** Locate the AC power cord attached to the same speaker. Plug the AC power cord into a standard wall electrical outlet.
3. **Position Speakers:** Place the speakers on a flat, stable surface on either side of your computer monitor for optimal stereo sound.
4. **Power On:** Turn the volume knob on the speaker clockwise until you hear a click and the LED power indicator illuminates, indicating the speakers are powered on.



Image: The onn. speakers positioned next to a laptop, with the power cord plugged into a wall outlet, demonstrating a typical setup.

Operating Instructions

Once set up, operating your speakers is straightforward:

1. **Power On/Off:** The volume knob also functions as the power switch. Rotate it clockwise to turn the speakers on (LED illuminates) and counter-clockwise until it clicks to turn them off (LED extinguishes).
2. **Adjust Volume:** Rotate the larger knob (volume control) clockwise to increase the volume and counter-clockwise to decrease it.
3. **Adjust Bass:** Rotate the smaller knob (bass control) to adjust the bass level to your preference.



Image: A close-up, top-down view of the right speaker, clearly showing the volume and bass control knobs and the LED power indicator.

Maintenance

To ensure the longevity and optimal performance of your speakers:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speakers. Do not use liquid cleaners or abrasive materials.
- **Placement:** Avoid placing speakers in direct sunlight, near heat sources, or in areas with high humidity.
- **Storage:** When not in use for extended periods, store the speakers in a cool, dry place.

Troubleshooting

If you encounter issues with your speakers, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound	Speakers not powered on; Volume too low; Audio cable not connected; Incorrect audio output selected on computer.	Ensure speakers are powered on (LED illuminated); Increase volume using the knob; Verify 3.5 mm audio cable is securely plugged into both speakers and computer; Check computer's audio settings to ensure correct output device is selected.
Distorted sound	Volume too high; Audio source quality is poor; Bass level too high.	Decrease speaker volume; Try a different audio source; Adjust the bass control knob.
LED power indicator is off	Speakers are off; Power cord not connected; Power outlet not working.	Turn the volume knob clockwise to power on; Ensure AC power cord is securely plugged into both the speaker and a working wall outlet; Try a different power outlet.

Specifications

Feature	Detail
Model Name	681131309189
Speaker Type	Computer
Special Feature	Volume knob
Recommended Uses	For Computers
Compatible Devices	Desktop, Laptop, Tablet
Subwoofer Diameter	3 Inches
Controller Type	Corded Electric
Surround Sound Channel Configuration	2.0
Color	Berry
Included Components	2 x Speaker
Power Source	Corded Electric
Speaker Size	3 Inches
Connectivity Protocol	Auxiliary
Speaker Maximum Output Power	6 Watts
Connectivity Technology	Auxiliary
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount
Item Weight	1.46 pounds
Package Dimensions	8.62 x 7.83 x 4.33 inches

Warranty and Support

This product comes with a Limited Warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official onn. website. For technical support or customer service inquiries, please contact onn. customer support through their official channels.

© 2024 onn. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is there no sound from my onn. 681131309189 AC Powered Computer Speakers even though the auxiliary cable is connected, the power is plugged in, and the volume is turned up?

If your onn. AC Powered Computer Speakers (Model 681131309189) are not producing sound despite being plugged in and turned up, please check the following troubleshooting steps based on the user manual:Check the LED Power...

Read full answer