Fisher FAWMT-E12SB

Fisher 12 kg Top Load Washing Machine FAWMT-E12SB User Manual

Model: FAWMT-E12SB

Introduction

Thank you for choosing the Fisher 12 kg Top Load Washing Machine, model FAWMT-E12SB. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read it thoroughly before first use and keep it for future reference.

This washing machine features a 12 kg capacity stainless steel tub, resistant to rust and dust. It offers powerful, multi-directional water flow and multiple wash programs for various fabric types. Designed for convenience, it includes a transparent, durable, tight-closing lid and an electronic quick clean system. Operating at 220V/60Hz, it is built for ease of use and cleaning.





Figure 1: Top-down view of the Fisher 12 kg Top Load Washing Machine.

Setup and Installation

1. Unpacking

- Carefully remove all packaging materials, including the base packaging and any protective foam or tape.
- Inspect the washing machine for any damage incurred during transit. Contact your retailer immediately if any damage is found.

2. Placement

- Place the washing machine on a firm, level surface to prevent vibration and noise during operation.
- Ensure there is adequate space around the machine for ventilation and maintenance.

- Adjust the leveling legs (special feature: adjustable leveling legs) at the bottom of the machine to ensure it is perfectly stable.

3. Water Connection

- Connect the water inlet hose to a cold water tap and to the water inlet valve on the back of the washing machine. Ensure connections are tight to prevent leaks.
- Position the drain hose into a suitable drain pipe or sink, ensuring it is securely fastened to prevent dislodging during drainage.

4. Power Connection

- Plug the power cord into a grounded 220V/60Hz electrical outlet. Do not use extension cords or adapters.



Figure 2: Front view of the washing machine with the lid open, illustrating the top-load access.

Operating Instructions

1. Loading Laundry

- Open the transparent lid.
- Load clothes loosely into the tub, ensuring not to overload the machine (maximum 12 kg capacity). Distribute items evenly to maintain balance.
- Close the durable, tight-closing lid securely.

2. Adding Detergent

- Add the recommended amount of detergent to the dispenser drawer or directly into the tub, depending on the machine's design and detergent type.

3. Selecting a Wash Program

- The control panel features push buttons for various settings.
- Turn on the machine using the power button.
- Select the desired wash program (e.g., Normal, Quick Clean System) based on the fabric type and soil level. The machine offers multiple programs.
- Adjust water level, temperature, and spin speed (up to 1300 RPM) if options are available for the selected program.

4. Starting the Wash Cycle

- Press the Start/Pause button to begin the wash cycle.
- The machine will automatically proceed through the selected program, including powerful, multi-directional water flow for effective cleaning.



Figure 3: Angled view of the washing machine's control panel.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your Fisher washing machine. The machine is designed to be easy to clean.

1. Cleaning the Tub

- Utilize the electronic quick clean system periodically to remove detergent residue and odors from the stainless steel tub.
- For manual cleaning, wipe the interior of the tub with a soft cloth and a mild, non-abrasive cleaner.

2. Cleaning Filters

- Check and clean the lint filter (if applicable) regularly to prevent blockages and ensure efficient drainage. Refer to your machine's specific design for filter location and cleaning instructions.

3. Exterior Cleaning

- Wipe the exterior surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- Keep the control panel dry and clean.

4. Winterization (if applicable)

- If the machine is in an area prone to freezing temperatures, disconnect the water supply hoses and drain any remaining water from the hoses and pump to prevent damage.

Troubleshooting

Before contacting service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged; Lid not closed properly; Power outage.	Ensure power cord is securely plugged in; Close the lid completely; Check household circuit breaker.
No water filling	Water tap closed; Water inlet hose kinked or blocked.	Open the water tap; Straighten the water inlet hose; Clean the inlet filter if blocked.
Water not draining	Drain hose kinked or blocked; Drain pump filter blocked.	Straighten the drain hose; Clean the drain pump filter.
Excessive vibration/noise	Machine not level; Laundry unevenly distributed; Transit bolts not removed.	Adjust leveling legs; Redistribute laundry evenly; Ensure all transit bolts are removed during installation.
Detergent residue on clothes	Too much detergent used; Low water pressure.	Reduce detergent amount; Ensure adequate water pressure.

Specifications

Feature	Detail
Brand	Fisher
Model Number	FAWMT-E12SB
Product Type	Washing Machine
Capacity	12 kg
Access Location	Top Load
Operation Mode	Fully Automatic

Feature	Detail
Maximum Spin Speed	1300 RPM
Voltage	220 Volts
Frequency	60Hz
Product Dimensions (D x W x H)	60 cm x 63 cm x 100 cm
Item Weight	43 kg
Material	Aluminum (Tub: Stainless Steel)
Finish Type	Aluminum
Color	Multi-color (Silver/Grey)
Special Feature	Adjustable Leveling Legs
Control Type	Push Button
Installation Type	Freestanding
Cycle Options	Normal, Multi-program





Figure 4: Side view of the washing machine with energy label.

Warranty Information

The provided product data indicates that warranty information is 'N/A' (Not Available). For specific warranty details, please refer to the documentation included with your purchase or contact your retailer directly. Keep your proof of purchase for any warranty claims.

Customer Support

If you encounter any issues that cannot be resolved using the troubleshooting guide, or if you require further assistance, please contact your retailer or the Fisher customer service department. Have your model number (FAWMT-E12SB) and purchase date ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question