Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Disney 260027

Walt Disney World 50th Anniversary Castle PopSockets Adhesive PopGrip User Manual

Model: 260027

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Walt Disney World 50th Anniversary Castle PopSockets Adhesive PopGrip. This accessory is designed to enhance the grip and stand functionality of your smartphone or tablet.

The PopGrip features an iconic castle design celebrating the 50th Anniversary of Walt Disney World, offering both practical utility and a decorative element for your device.

Product Overview



Image: Front view of the Walt Disney World 50th Anniversary Castle PopSockets Adhesive PopGrip, showcasing the castle design.

The PopGrip is a versatile accessory that adheres to the back of your mobile device. It provides a secure grip for holding your phone or tablet, reducing the risk of accidental drops. When extended, it also functions as a convenient stand for hands-free viewing of videos or video calls.

Key features include:

- **Enhanced Grip:** Provides a more secure hold on your device.
- **Kickstand Functionality:** Allows for hands-free viewing in landscape or portrait mode.
- **Swappable Top:** The decorative top can be easily removed and replaced with other compatible PopGrip tops.
- **Adhesive Backing:** Securely attaches to most smooth, hard, plastic cases.

Setup and Installation

Follow these steps to properly attach your PopGrip to your device or case:

1. **Clean the Surface:** Ensure the back surface of your phone or tablet case is clean, dry, and free of dust or oils. The adhesive works best on smooth, hard, plastic surfaces. *Note: The adhesive will not stick to silicone, leather,*

waterproof, or highly textured cases.

2. **Peel the Backing:** Carefully peel off the protective film from the adhesive disc on the back of the PopGrip.
3. **Position the PopGrip:** Place the PopGrip in the desired location on the back of your device or case. Consider where it feels most comfortable for gripping and where it will provide stable support as a stand.
4. **Apply Pressure:** Once positioned, press firmly on the PopGrip for 10-15 seconds to ensure a strong bond. Allow the adhesive to cure for at least 1 hour before heavy use, ideally 24 hours for maximum adhesion.



Image: A four-panel illustration demonstrating the installation process: 1. Peeling the adhesive, 2. Positioning the PopGrip, 3. Pressing firmly, and 4. Swapping the top.

Operating Instructions

Using as a Grip

To use the PopGrip as a secure hold for your device, simply pull the top disc outwards until it clicks into its fully extended position. Slide your fingers between the extended base and the top disc for a comfortable and secure grip.



Image: A person holding a smartphone with the PopGrip extended, demonstrating its use as a secure grip.

Using as a Stand

Extend the PopGrip fully. You can then prop your device up on a flat surface in either portrait or landscape orientation. Adjust the angle by slightly collapsing the PopGrip until the desired viewing angle is achieved.



Image: A person using a tablet propped up by a PopGrip, illustrating its function as a hands-free stand.

Swapping the Top

The printed top of your PopGrip is swappable with other compatible PopGrip models. To remove the top, simply press the PopGrip flat (collapsed position), then turn the top 90 degrees until you hear a click. The top can then be lifted off. To attach a new top, align it with the base and turn 90 degrees until it clicks securely into place.

Maintenance and Care

- **Cleaning:** To clean the PopGrip, wipe it with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Adhesive Care:** If you need to re-position your PopGrip, gently peel it off and reapply. The adhesive is designed for multiple uses, but its effectiveness may decrease over time or with repeated re-positioning. If the adhesive loses its stickiness, rinse it with water and let it air dry completely. Do not wipe it.
- **Storage:** When not in use for extended periods, keep the PopGrip collapsed to protect the mechanism.

Troubleshooting

Problem	Solution
PopGrip does not stick to my device/case.	Ensure the surface is clean and dry. The adhesive works best on smooth, hard, plastic cases. It is not compatible with silicone, leather, waterproof, or highly textured surfaces. If the adhesive is dirty, rinse it with water and let it air dry.
PopGrip feels loose or wobbly.	Ensure the top is securely clicked into the base. If the entire PopGrip is loose, re-apply pressure to the adhesive or consider re-positioning it after cleaning the adhesive.
Cannot swap the top.	Make sure the PopGrip is fully collapsed (flat) before attempting to turn and remove the top. Turn 90 degrees until you hear a click.
Interferes with wireless charging.	The PopGrip is not compatible with wireless charging. It must be removed or repositioned if you wish to use a wireless charger.

Specifications

- **Model Number:** 260027
- **ASIN:** B09RCRZG4N
- **Brand:** Disney (Manufactured by PopSockets)
- **Grip Type:** Pop Grip
- **Material:** Silicone (for the grip mechanism, adhesive is acrylic-based)
- **Color:** Black (base), Multi-color (top design)
- **Item Weight:** 0.48 ounces
- **Package Dimensions:** 4.3 x 3.4 x 0.3 inches
- **Special Feature:** Expandable, Swappable Top
- **Compatibility:** Most smartphones and tablets. Best with smooth, hard, plastic cases.

© 2024 Disney / PopSockets. All rights reserved.
For further assistance, please refer to the official PopSockets support website or contact Disney customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09RCRZG4N

More documents and user manuals: **https://manuals.plus/**