Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Alien Pro ALCYCLONEII

Alien Pro ALCYCLONEII 12-inch Cyclone Dual Speaker User Manual

Model: ALCYCLONEII

Introduction Safety Information Product Overview Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Alien Pro ALCYCLONEII 12-inch Cyclone Dual Speaker. Please read this manual thoroughly before using the product to ensure proper function and to prevent damage. Keep this manual for future reference.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in fire, electric shock, or other injury or damage.

- Ensure all connections are secure and correctly polarized before powering on the speaker.
- Do not expose the speaker to extreme temperatures, humidity, or direct sunlight.
- Avoid placing the speaker near heat sources or in enclosed spaces without adequate ventilation.
- Do not attempt to open or repair the speaker yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from water and liquids. The product is not waterproof.
- Use only accessories specified by the manufacturer.

3. Product Overview

The Alien Pro ALCYCLONEII is a 12-inch dual speaker designed for high-quality audio output. It features a robust construction suitable for various audio setups.



Image showing the Alien Pro ALCYCLONEII 12-inch Cyclone Dual Speaker, highlighting its design and size.

Package Contents:

- Alien Pro ALCYCLONEII 12-inch Cyclone Dual Speaker (1 unit)
- User Manual (this document)
- *(Additional accessories may vary by package)*

4. Setup

4.1 Unpacking

Carefully remove the speaker from its packaging. Inspect the speaker for any signs of damage during transit. If any damage is found, do not proceed with installation and contact your retailer.

4.2 Placement

Position the speaker on a stable, flat surface. Ensure there is adequate space around the speaker for proper ventilation. Avoid placing it in direct sunlight or near heat sources.

4.3 Wiring Connections

1. Identify the audio input terminals on the back of the speaker.
2. Connect the audio cables from your amplifier or audio source to the speaker terminals. Ensure correct polarity (positive to positive, negative to negative) to avoid phase issues.
3. Secure all connections firmly to prevent loose contacts, which can cause signal loss or damage.

5. Operating Instructions

5.1 Powering On

Once all connections are made, power on your amplifier or audio source. The speaker itself does not have a separate power switch as it is a passive speaker.

5.2 Audio Playback

Begin playing audio from your connected source. Adjust the volume level on your amplifier or audio source. Start with a low volume and gradually increase it to a comfortable listening level.

5.3 Volume Control

Always control the volume from your audio source or amplifier. Avoid setting the volume too high, which can cause distortion and potentially damage the speaker or your hearing.

6. Maintenance

6.1 Cleaning

To clean the speaker, use a soft, dry cloth. Do not use liquid cleaners, aerosols, or solvents, as these may damage the finish or internal components. Gently wipe the surfaces to remove dust.

6.2 Storage

If storing the speaker for an extended period, ensure it is kept in a cool, dry place, away from direct sunlight and extreme temperatures. Cover the speaker to protect it from dust.

7. Troubleshooting

Problem	Possible Cause	Solution
No sound from speaker	• Loose or incorrect wiring connections. • Amplifier/audio source not powered on or set to incorrect input. • Volume too low.	• Check all audio cable connections for proper polarity and tightness. • Ensure amplifier/audio source is on and selected to the correct input. • Increase volume on amplifier/audio source.
Distorted sound	• Volume set too high. • Poor quality audio source. • Damaged speaker or wiring.	• Reduce volume on amplifier/audio source. • Test with a different audio source or cable. • If distortion persists, contact support.
Intermittent sound	• Loose connections. • Faulty audio cable.	• Check and secure all connections. • Replace audio cable if suspected faulty.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Detail
Brand	Alien Pro
Model Number	ALCYCLONEII
Speaker Size	12 inches

Feature	Detail
Woofer Diameter	12 inches
Mounting Type	Floor Standing
Waterproof	No
ASIN	B09RQ7Y2V
First Available Date	2023/05/25

9. Warranty and Support

9.1 Warranty Information

Alien Pro products are manufactured with high-quality materials and undergo strict quality control. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Alien Pro website.

9.2 Customer Support

If you encounter any issues or have questions regarding your Alien Pro ALCYCLONEII speaker, please contact Alien Pro customer support. Have your model number (ALCYCLONEII) and purchase details ready when contacting support. *Contact information can typically be found on the manufacturer's website or your purchase documentation.*

© 2023 Alien Pro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09RQ7Y24V

More documents and user manuals: **https://manuals.plus/**