Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Moultrie MCG-14074

Moultrie Micro-32i Trail Camera Kit - Double Pack User Manual

Model: MCG-14074

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Moultrie Micro-32i Trail Camera Kit. This kit includes two compact trail cameras designed for capturing high-resolution images and HD video in outdoor environments. The cameras feature invisible flash technology for discreet operation.



Image: The Moultrie Micro-32i Trail Camera Kit, showing two cameras and the included AA batteries.

Setup

1. Battery Installation

Each Moultrie Micro-32i camera requires 4 AA batteries for operation. The kit includes 8 AA batteries (4 per camera). Ensure batteries are inserted with correct polarity as indicated inside the battery compartment.



Image: A user inserting AA batteries into the camera's battery compartment while it is mounted on a tree.

2. SD Card Insertion

The camera requires an SD card (not included) to store images and videos. It is recommended to use an outdoor-rated SD card for optimal performance and durability in varying environmental conditions. Insert the SD card into the designated slot until it clicks into place.



Image: A detailed view of the camera's side, highlighting the SD card slot and control panel.

3. Mounting the Camera

The cameras come with heavy-duty installation straps for mounting. Securely attach the camera to a tree or post using the provided strap. Ensure the camera is stable and pointed towards the desired area for monitoring.



Image: Two Moultrie Micro-32i cameras securely mounted on a tree, demonstrating typical outdoor placement.

Operating Instructions

The Moultrie Micro-32i cameras are designed for ease of use with a simple ON/SETUP/OFF switch and intuitive control buttons.

Powering On and Setup Mode

To power on the camera, slide the switch to the "ON" position. To access setup options, slide the switch to "SETUP". The LCD screen will display menu options. Use the arrow buttons to navigate and the ENTER button to select.



Image: A close-up of the camera's internal control panel, showing the LCD screen, navigation buttons, and the ON/SETUP/OFF switch.

Capture Modes and Settings

- **Resolution:** Captures high-resolution 32 MP images.
- **Video Resolution:** Records HD video at 1280x720.

- **Trigger Speed:** Fast 0.5 second trigger speed to capture quick movements.
- **Detection Range:** Effective detection up to 70 feet.
- **Flash Range:** Invisible flash technology provides illumination up to 80 feet for night captures.
- **Motion Detect Delay:** Adjustable settings: 0 SEC./15 SEC./30 SEC./1 MIN./5 MIN.

Adjust these settings in the SETUP menu according to your monitoring needs. For detailed menu navigation, refer to the Quick Start Guide located inside the camera's door.

Official Product Video

Your browser does not support the video tag.

Video: An official Moultrie video demonstrating the "Hunt Smart" approach with various Moultrie products, including trail cameras and feeders, highlighting their integration for total game management.

Maintenance

Battery Life

The cameras are designed for extended battery life, capable of capturing approximately 13,000 images. Actual battery life may vary based on user settings (e.g., frequency of captures, video length) and environmental conditions (e.g., extreme temperatures). It is recommended to check battery levels periodically, especially before extended deployments.

SD Card Management

Regularly check and clear your SD card to ensure continuous recording. It is advisable to carry a backup SD card when checking cameras in the field. Always power off the camera before removing or inserting the SD card to prevent data corruption.

Troubleshooting

Poor Picture Quality / No Captures

- Ensure the lens is clean and free from obstructions (dirt, spiderwebs).
- Verify the camera is securely mounted and not swaying in the wind.
- Check the detection range and flash range settings to ensure they are appropriate for your desired monitoring area.
- Confirm the SD card is properly inserted and has sufficient free space. Format the SD card periodically.

Short Battery Life

- Reduce the frequency of captures or video length settings.
- Ensure you are using high-quality AA batteries.
- Extreme cold weather can significantly reduce battery performance. Consider using lithium batteries in such conditions.

Camera Not Powering On

- Check that batteries are inserted correctly with proper polarity.
- Replace all batteries with fresh ones.
- Ensure the ON/SETUP/OFF switch is fully in the "ON" or "SETUP" position.

Specifications

Feature	Specification
Camera Dimensions	3.25” W x 3.5” L x 2.625” D
Resolution	32 MP
Trigger Speed	0.5 SEC.
Detection Range	70 FT.
Flash Range	80 FT.
Flash Technology	Invisible Flash
Battery Life	13,000 Images (will vary depending on user settings and environmental conditions)
Power Source	4 x AA Batteries per camera (8 batteries included)
Video Resolution	1280x720
Motion Detect Delay	0 SEC./15 SEC./30 SEC./1 MIN./5 MIN.
Indoor/Outdoor Usage	Outdoor
Connectivity Protocol	Cellular
Wireless Communication Technology	Wi-Fi
Flash Memory Type	SD
International Protection Rating	IP65

Warranty and Support

Warranty Information

The Moultrie Micro-32i Trail Camera Kit comes with a warranty of up to 2 years. Please retain your proof of purchase for warranty claims.

Additional Support

For further assistance, detailed user guides, or frequently asked questions, please visit the official Moultrie website or refer to the User Manual (PDF).

© 2024 Moultrie. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09RQZLDHL

More documents and user manuals: **https://manuals.plus/**