Royalty Line RL-AF1700.882.1D

ROYALTY LINE Digital Air Fryer

Model: RL-AF1700.882.1D User Manual

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before operating the appliance.

- **DO NOT** touch hot surfaces. Use handles or knobs.
- To protect against electric shock, **DO NOT** immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- **DO NOT** operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- **DO NOT** use outdoors.
- **DO NOT** let cord hang over edge of table or counter, or touch hot surfaces.
- **DO NOT** place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- **DO NOT** use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Ensure adequate ventilation around the appliance during use.

2. Product Overview

The ROYALTY LINE Digital Air Fryer (Model: RL-AF1700.882.1D) allows you to enjoy your favorite fried snacks and foods with significantly less oil. This versatile appliance can fry, grill, roast, and even bake, offering a healthier alternative to traditional deep frying.

Key Features:

- **Power:** 1700 Watts
- **Capacity:** 6.5 Liters
- **Adjustable Cooking Time:** 0-60 minutes with acoustic signal
- **Adjustable Cooking Temperature:** 65°C - 200°C
- **Display:** High-quality LED display
- **Technology:** High-speed air circulation (Rapid Air Technology)
- **Basket & Pot:** Non-stick coating for easy cleaning
- **Safety:** Internal thermal fuse, cool-touch housing and handle, anti-skidding feet
- **Operation:** One-touch intelligent operation, intelligent micro-touch control



Image: The ROYALTY LINE Digital Air Fryer, Model RL-AF1700.882.1D, displayed on its packaging, highlighting key features like 1700W wattage, 80% less oil cooking, and rapid air technology. The image shows the appliance with a basket full of fries.

3. Setup and First Use

3.1 Unpacking

- Carefully remove the air fryer and all packaging materials from the box.
- Remove any stickers or labels from the appliance.

- Check that all parts are present and in good condition.

3.2 Initial Cleaning

- Wash the basket and the non-stick pot with hot water, a mild dishwashing liquid, and a non-abrasive sponge.
- Wipe the inside and outside of the appliance with a damp cloth.
- **DO NOT** immerse the main unit in water or any other liquid.
- Ensure all parts are thoroughly dry before use.

3.3 Placement

- Place the air fryer on a stable, horizontal, and heat-resistant surface.
- Ensure there is at least 10 cm (4 inches) of free space on the back and sides of the appliance, and 10 cm (4 inches) above it, to allow for proper air circulation.
- **DO NOT** place the appliance against a wall or other appliances.

---

4. Operating Instructions

4.1 Preparing for Cooking

1. Plug the main power cord into a grounded wall outlet.
2. Carefully pull the basket out of the air fryer.
3. Place the ingredients into the basket. **DO NOT** exceed the MAX fill line or the maximum weight indicated in the specifications.
4. Slide the basket back into the air fryer. Ensure it clicks securely into place.

4.2 Setting Time and Temperature

1. Once the basket is inserted, the LED display will illuminate.
2. Use the temperature control buttons to set the desired cooking temperature (65°C - 200°C).
3. Use the timer control buttons to set the desired cooking time (0-60 minutes).
4. Press the Start/Pause button to begin the cooking process. The fan and heating element will activate.

4.3 During Cooking

- Some recipes may require shaking or turning ingredients halfway through the cooking time. To do this, carefully pull out the basket using the cool-touch handle. The air fryer will automatically pause.
- Shake or turn the ingredients, then slide the basket back into the air fryer. The cooking will resume automatically.
- The air fryer will emit an acoustic signal when the set cooking time has elapsed.

4.4 Removing Cooked Food

1. When the cooking time is complete, carefully pull the basket out of the air fryer.
2. Empty the contents of the basket into a serving dish. Use tongs or other heat-resistant utensils to remove food, as the basket and food will be hot.
3. Allow the appliance to cool down completely before cleaning.

4.5 Cooking Tips

- For best results, preheat the air fryer for 3-5 minutes at the desired temperature before adding food.
- Smaller ingredients usually require a shorter cooking time than larger ingredients.
- A small amount of oil can be added to fresh potatoes for a crispier result.
- Foods that can be cooked in a conventional oven can also be cooked in the air fryer.
- For frozen foods, follow the package instructions, adjusting for air fryer use if necessary.

5. Maintenance and Cleaning

Clean the appliance after every use to ensure optimal performance and longevity.

1. **ALWAYS** unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Cleaning the Basket and Pot:**
    - Remove the basket and pot from the air fryer.
    - Wash them with hot water, a mild dishwashing liquid, and a non-abrasive sponge.
    - For stubborn food residues, soak the basket and pot in hot water with some dishwashing liquid for about 10 minutes.
    - The basket and pot are dishwasher safe, but hand washing is recommended to prolong the life of the non-stick coating.
3. **Cleaning the Interior:**
    - Wipe the interior of the appliance with a damp cloth.
    - If necessary, use a soft brush to remove any food residues from the heating element.
    - **DO NOT** use abrasive cleaning materials.
4. **Cleaning the Exterior:**
    - Wipe the exterior of the air fryer with a damp cloth.
    - **DO NOT** use harsh or abrasive cleaners.
5. **Storage:**
    - Ensure all parts are clean and dry before storing.
    - Store the air fryer in a cool, dry place.

6. Troubleshooting

Problem	Possible Cause	Solution
The air fryer does not turn on.	The appliance is not plugged in. The basket is not inserted correctly.	Plug the main plug into a grounded wall socket. Slide the basket into the appliance until it clicks into place.

Problem	Possible Cause	Solution
Food is not cooked evenly.	Too much food in the basket. Food was not shaken/turned.	Reduce the amount of food per batch. Shake or turn ingredients halfway through cooking.
White smoke comes out of the appliance.	Fat residues from previous use. Basket/pot not cleaned properly.	Clean the basket and pot thoroughly after each use. Ensure no oil or grease is left on the heating element.
Fresh fries are not crispy.	Not enough oil used. Incorrect potato type. Too much moisture.	Add a small amount of oil (1/2 tablespoon). Use fresh potatoes suitable for frying. Pat potatoes dry before adding oil.

7. Specifications

- **Model:** RL-AF1700.882.1D
- **Brand:** Royalty Line
- **Power:** 1700 Watts
- **Capacity:** 6.5 Liters
- **Color:** Black
- **Dimensions (Packaging):** 42 x 41 x 36.5 cm
- **Item Weight:** 7.8 Kilograms
- **Adjustable Temperature:** 65°C - 200°C
- **Adjustable Timer:** 0 - 60 minutes
- **Features:** Non-stick coating, Anti-skidding feet, LED display, Rapid Air Technology

8. Warranty and Support

ROYALTY LINE products are manufactured to the highest quality standards. For information regarding warranty coverage, product support, or service inquiries, please refer to the warranty card included with your purchase or visit the official ROYALTY LINE website.
Official Website: www.royaltyline.com