Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Restokki RDC-MB1

Restokki Muilti-Backlight Digital Alarm Clock User Manual

Model: RDC-MB1

Introduction

Thank you for purchasing the Restokki Muilti-Backlight Digital Alarm Clock. This manual provides detailed instructions for setting up, operating, and maintaining your new alarm clock. Please read this manual thoroughly before use to ensure proper functionality and longevity of the product.
This digital alarm clock features a large LCD display for easy reading, 12/24 hour conversion, and a color-changing backlight. It is designed for use in bedrooms, offices, and hotels, offering a simple yet stylish timekeeping solution.

Package Contents

Upon opening the package, please verify that all components are present and in good condition:

- 1 x Restokki Digital Alarm Clock
- 1 x User Manual

Note: 3 x AAA batteries are required for operation and are not included in the package.

Product Overview



Figure 1: Front view of the alarm clock, highlighting the large LCD display for clear time reading.



Figure 2: Rear view of the alarm clock, showing the battery compartment and control buttons (S, M, ON, NO, Reset).



Figure 3: The alarm clock showcasing its multi-color changing backlight feature and temperature display.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the alarm clock (refer to Figure 2).
2. Open the battery compartment cover.
3. Insert 3 new AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

The clock will power on automatically once batteries are installed. If the display does not appear, check battery orientation or replace with fresh batteries.

Operating Instructions

The alarm clock features several buttons on the back for configuration:

- **S (Set) Button:** Used to enter setting modes for time, date, and alarm.
- **M (Mode) Button:** Used to switch between display modes (e.g., Time, Alarm, Temperature).
- **Up/Down Buttons (▲/▼):** Used to adjust values during setting modes.
- **ON Button:** Used to activate the alarm.
- **NO Button:** Used to deactivate the alarm or activate the backlight/snooze.
- **RESET Button:** Resets the clock to factory defaults.

1. Setting Time and Date

1. Press the **S** button once to enter time setting mode. The hour digits will flash.
2. Use the ▲ and ▼ buttons to adjust the hour.
3. Press **S** again to move to minute setting. Adjust minutes using ▲ and ▼.
4. Continue pressing **S** to cycle through year, month, and day settings, adjusting each with ▲ and ▼.
5. After setting the day, press **S** one last time to exit setting mode.

2. 12/24 Hour Format Conversion

While in normal time display mode, press the ▲ button to toggle between 12-hour (with AM/PM indicator) and 24-hour formats.

3. Setting the Alarm

1. Press the **M** button until the alarm time is displayed (usually indicated by an alarm icon).
2. Press the **S** button to enter alarm setting mode. The alarm hour digits will flash.
3. Use the ▲ and ▼ buttons to adjust the alarm hour.
4. Press **S** again to move to alarm minute setting. Adjust minutes using ▲ and ▼.
5. Press **S** one last time to confirm and exit alarm setting mode.

4. Activating/Deactivating the Alarm

While in normal time display mode, press the **ON** button to activate the alarm. An alarm icon will appear on the display. Press the **NO** button to deactivate the alarm; the alarm icon will disappear.

5. Snooze Function

When the alarm sounds, press the **NO** button (or any other button except **RESET**) to activate the snooze function. The alarm will temporarily stop and sound again after approximately 5 minutes.

6. Backlight Activation

Press the **NO** button to momentarily activate the color-changing backlight for easy viewing in low light conditions. The backlight will automatically turn off after a few seconds to conserve battery life.

Maintenance

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the display or casing.
- **Battery Replacement:** Replace batteries when the display becomes dim or the clock stops functioning. Always use new AAA batteries and dispose of old batteries responsibly.
- **Storage:** If the clock will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead batteries; incorrect battery installation.	Replace batteries with new AAA batteries, ensuring correct polarity.
Alarm does not sound.	Alarm not activated; incorrect alarm time set.	Ensure alarm is activated (alarm icon visible). Verify alarm time is set correctly.
Time is incorrect.	Time not set correctly after battery installation or power interruption.	Follow "Setting Time and Date" instructions to reset the time.
Backlight not working.	Low batteries; backlight button not pressed.	Replace batteries. Press the **NO** button to activate the backlight.

Specifications

Item Type	Digital Alarm Clock
Brand	Restokki
Model	RDC-MB1
Material	ABS (Acrylonitrile Butadiene Styrene)
Display Type	Digital LCD
Power Source	Battery Powered (3 x AAA Batteries, not included)
Weight	Approx. 145g / 5.11oz (without batteries)
Special Features	Large LCD Screen, 12/24 Hour Conversion, Color Changing Backlight, Snooze Function

Warranty and Support

For any questions, technical support, or warranty inquiries regarding your Restokki Digital Alarm Clock, please contact our customer service team. Refer to the contact information provided on the product packaging or the official Restokki website.
Please retain your purchase receipt as proof of purchase for warranty claims.

© 2024 Restokki. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09RZXVJX4

More documents and user manuals: **https://manuals.plus/**