Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KidKraft 20237

KidKraft Windmill Elevator 2-in-1 Wooden Barn & Dollhouse Instruction Manual

Model: 20237

Introduction

This manual provides essential information for the assembly, operation, and maintenance of your KidKraft Windmill Elevator 2-in-1 Wooden Barn & Dollhouse. Designed for imaginative play, this three-story wooden dollhouse combines a farmhouse with a barn, featuring a working grain silo elevator and interactive elements like lights and sounds. Please read these instructions carefully to ensure safe and enjoyable use of the product.



Image: The fully assembled KidKraft Windmill Elevator 2-in-1 Wooden Barn & Dollhouse, showcasing its multi-level design and integrated barn area, with two children engaged in play.

Setup

The KidKraft Windmill Elevator 2-in-1 Wooden Barn & Dollhouse features EZ Kraft Assembly for a streamlined setup process. Follow the included assembly guide for detailed, step-by-step instructions. Ensure all components are present before beginning assembly. A flat, clear surface is recommended for construction.

- Unpack all parts and verify against the parts list in your separate assembly guide.
- Follow the numerical or alphabetical sequence provided in the assembly guide.
- Ensure all screws and fasteners are securely tightened, but do not overtighten.
- Place the assembled dollhouse on a stable, level surface.

Operating Instructions

This play set offers various interactive features for an engaging experience.

Windmill-Powered Elevator

The grain silo features a working elevator powered by a windmill. Rotate the windmill blades to raise and lower the elevator, transporting dolls or small accessories between levels.



Image: A child's hand rotating the pink windmill blades, demonstrating the operation of the integrated elevator system.

Lights and Sounds Features

The dollhouse includes two interactive lights and sounds features: a vintage-look wood-burning stove and a lamp.

- **Stove:** Press the button or interact with the stove accessory to activate realistic light and sound effects, simulating a warm, crackling fire.
- **Lamp:** Press the base of the lamp to turn its light on and off, illuminating the dollhouse interior.



Image: A close-up of a child's hand pressing a button on the miniature wood-burning stove, which emits a warm glow, indicating its light and sound function.



Image: A child's finger pressing the base of a miniature lamp, which is illuminated, demonstrating its functional light feature within the dollhouse bedroom.

Barn and Farm Features

The integrated barn area allows for farm-themed play with included accessories.

- **Chicken Coop:** Place the chicken and eggs in the coop for farm-to-table play scenarios.
- **Horse Stable:** Feed the included horse accessory with the hay bale in its stable.
- **Planter Box:** Plant the miniature carrots in the planter box for gardening role-play.



Image: A detailed view of the horse accessory standing in its stable, with a miniature hay bale placed in the feeder, ready for imaginative feeding play.



Image: Two children interacting with the horse accessory and miniature carrots, simulating feeding and care in the barn section of the play set.

Dollhouse Play Areas

The dollhouse features 3 levels and 9 distinct play areas, including a porch, covered balcony, and various rooms. Arrange the over 25 furniture and play pieces to create diverse living spaces for dolls up to 12 inches tall (dolls not included).



Image: A child arranging dolls and miniature furniture around a dining table in one of the dollhouse's interior rooms, demonstrating interactive play.

Your browser does not support the video tag.

Video: An overview of the KidKraft Windmill Elevator 2-in-1 Barn & Dollhouse, showcasing its various features, play areas, and interactive elements in action.

Maintenance

To ensure the longevity and cleanliness of your KidKraft Windmill Elevator 2-in-1 Wooden Barn & Dollhouse, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as they may damage the finish.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Storage:** Store the dollhouse in a dry environment away from direct sunlight or extreme temperatures to prevent

warping or fading of the wood.

Troubleshooting

If you encounter any issues with your dollhouse, refer to the following common troubleshooting tips:

- **Lights/Sounds Not Working:** Ensure batteries are correctly installed and are not depleted. Replace batteries if needed. Check for any loose connections if applicable.
- **Elevator Not Moving Smoothly:** Inspect the windmill mechanism for any obstructions. Ensure the elevator track is clear of debris.
- **Missing Parts:** If you believe parts are missing from your original package, refer to the parts list in your assembly guide and contact customer support.
- **Stability Issues:** Verify that all assembly steps were followed correctly and all fasteners are securely tightened. Ensure the dollhouse is placed on a flat, stable surface.

Specifications

Feature	Detail
Brand	KidKraft
Model Number	20237
GTIN (UPC)	706943204597
Material Type	Engineered Wood
Item Dimensions (L x W x H)	60.63 x 12.87 x 44.69 inches
Recommended Age	4 years and up
Number of Levels	3
Number of Play Areas	9
Included Components	Wood, accessories, hardware

Warranty Information

This KidKraft product is covered by a **90 Day Warranty Against Manufacturer Defects**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for any warranty claims. For specific details regarding warranty coverage and claims, refer to the documentation included with your product or contact KidKraft customer support.

Support

For further assistance, replacement parts, or any questions not covered in this manual, please contact KidKraft customer support. You can find contact information and additional resources on the official KidKraft website or by visiting the KidKraft Store on Amazon.

When contacting support, please have your model number (20237) and proof of purchase readily available.

© 2023 KidKraft. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09S1DDSVF

More documents and user manuals: **https://manuals.plus/**