Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced CSR722-C01

RemotesReplaced Remote Control for CONDOR CSR722-C01 User Manual

Introduction

This manual provides comprehensive instructions for the RemotesReplaced replacement remote control, specifically designed for compatibility with the CONDOR CSR722-C01 device. This remote offers all the functionalities of the original remote without requiring any complex setup or programming. It is a dedicated replacement, not a universal remote.

Product Overview

The RemotesReplaced remote control features a standard layout with 20 buttons, providing full control over your compatible device. It operates using infrared (IR) technology.



Figure 1: Front view of the RemotesReplaced remote control, showing all buttons and layout.



Figure 2: Top view of the remote control, highlighting the infrared (IR) emitter at the front.

Setup

This remote control requires two AAA batteries (not included). No programming or pairing is necessary. Simply insert the batteries correctly, and the remote will be ready for immediate use.

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align with the markings inside the compartment.
4. Replace the battery cover, sliding it back into place until it clicks securely.



Figure 3: Bottom view of the remote control, illustrating the battery compartment.

Operating Instructions

To operate your device, point the remote control directly at the infrared receiver on your television or compatible device. The maximum effective range is approximately 10 meters (33 feet).

Key Functions:

- **POWER:** Turns the device on or off.
- **MUTE:** Mutes or unmutes the audio.
- **TV/SAT/DVD/AUX:** Selects input sources.
- **MENU/EXIT:** Accesses and exits on-screen menus.
- **SHIFT:** Provides access to secondary functions of certain buttons.
- **Number Buttons (0-9):** Direct channel selection or data input.
- **SOURCE:** Cycles through available input sources.
- **+/- (Volume Up/Down):** Adjusts the volume level.

- **CH +/- (Channel Up/Down):** Changes channels.
- **GUIDE/INFO/EPG:** Displays program guide or information.
- **Navigation Pad (Up/Down/Left/Right/OK):** Navigates through menus and confirms selections.
- **BACK:** Returns to the previous screen or menu.
- **SLEEP:** Sets a sleep timer.
- **TV/DTV:** Switches between TV and Digital TV modes.
- **FAV:** Accesses favorite channels.
- **NET TV/SMART:** Accesses smart TV features or streaming apps.
- **Color Buttons (Red, Green, Yellow, Blue):** Functions vary depending on the on-screen menu or application.
- **Playback Controls (Rewind, Play/Pause, Fast Forward):** Controls media playback.

Maintenance

Battery Replacement:

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both AAA batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries.

Cleaning:

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

Disposal:

Dispose of used batteries according to local regulations. Do not dispose of batteries in household waste. The product packaging includes recycling information (see Figure 4).



Figure 4: Product packaging showing recycling instructions for paper and plastic components.

Troubleshooting

- **Remote not responding:**
  - Ensure fresh AAA batteries are correctly installed.
  - Verify there is a clear line of sight between the remote's IR emitter and the device's IR receiver.
  - Check if the device itself is powered on.
- **Limited range:**
  - Replace batteries with new ones.
  - Remove any obstructions between the remote and the device.
  - Ensure you are within the 10-meter operating range.

Specifications

Brand	RemotesReplaced
Model Number	CSR722-C01
Color	Black
Connectivity Technology	Infrared (IR)
Special Feature	No programming required
Compatible Devices	Television (specifically CONDOR CSR722-C01)
Number of Buttons	20
Maximum Range	10 Meters
Batteries Required	2 AAA batteries
Item Weight	120 Grams

Warranty and Support

This RemotesReplaced remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.
For technical support, warranty claims, or further assistance, please contact your retailer or the RemotesReplaced customer service. Refer to your purchase documentation for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09S3RXRTN

More documents and user manuals: **https://manuals.plus/**