Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schleich 42421

Schleich Farm World Chicken Coop Playset Instruction Manual

Model: 42421

Introduction

Welcome to the world of Schleich Farm World! This instruction manual provides essential information for the Schleich Farm World Chicken Coop Playset. This playset is designed to inspire imaginative play and learning about farm life and animals. Please read this manual carefully before use to ensure safe and enjoyable play.

Safety Information

Warning! Swallowable small parts. Choking hazard.
This product contains small parts which may pose a choking hazard for young children. Not suitable for children under 36 months (3 years) due to small parts. Adult supervision is recommended during play, especially with younger children.

Package Contents

Your Schleich Farm World Chicken Coop Playset includes the following components:

- 1 x Chicken Coop
- 1 x Enclosure
- 1 x Cockerel figurine
- 1 x Hen figurine
- 2 x Chick figurines
- 1 x Nest
- 1 x Eggs (set of eggs)



Image: All 8 pieces included in the Schleich Farm World Chicken Coop Playset, laid out on a green background. This includes the red and white chicken coop, a white fenced enclosure, a brown hen, a green and brown rooster, two yellow chicks, a brown nest, and a set of white eggs.

Setup Instructions

The Schleich Farm World Chicken Coop Playset is designed for easy assembly and immediate play. Follow these simple steps to set up your playset:

1. **Unpack all components:** Carefully remove all pieces from the packaging. Ensure all 8 components listed in the "Package Contents" section are present.
2. **Assemble the Chicken Coop:** The main chicken coop structure is largely pre-assembled. If any parts like the roof or ramp are detached, gently snap them into their designated slots.
3. **Attach the Enclosure:** The white fenced enclosure can be positioned next to the chicken coop. It is designed to connect or stand freely, allowing for flexible play configurations.
4. **Place the Figurines and Accessories:** Arrange the rooster, hen, and chicks within the coop and enclosure as

desired. Place the nest and eggs inside the coop for realistic farm scenarios.



Image: The fully assembled Schleich Farm World Chicken Coop Playset, showing the red and white coop with a ramp, and an attached white fenced enclosure. A rooster, hen, and two chicks are positioned around the coop, along with a nest containing eggs.



Image: An aerial view of the assembled chicken coop and enclosure, demonstrating how the animal figurines and nest can be placed inside the structure for play.

Operating and Play Instructions

The Schleich Farm World Chicken Coop Playset encourages open-ended, imaginative play. Here are some suggestions for engaging with your new playset:

- **Daily Farm Chores:** Pretend to be a farmer tending to the chickens. Move the hen to her nest to lay eggs, then collect the eggs. Guide the chicks as they explore the coop and enclosure.
- **Animal Interactions:** Use the rooster, hen, and chicks to act out various farm animal behaviors. The detailed figurines allow for realistic storytelling.
- **Expand Your Farm:** This playset is part of the larger Schleich Farm World collection. Combine it with other Schleich farm animals and playsets (sold separately) to create an expansive farm environment.

- **Educational Play:** Discuss the roles of different chickens (rooster, hen, chick) and the process of egg-laying with children during play.



Image: A detailed view of the rooster, hen, and two chick figurines, highlighting their realistic textures and colors, ready for imaginative play.

Care and Maintenance

To ensure the longevity and cleanliness of your Schleich Farm World Chicken Coop Playset, follow these simple care instructions:

- **Cleaning:** Wipe down the playset and figurines with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and air drying. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation and color fading.
- **Handling:** While durable, avoid excessive force or dropping the playset and figurines to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Small pieces (chicks, eggs) are easily lost.	The small size of these accessories makes them prone to misplacement during play.	Establish a designated storage container for all small components when not in use. Encourage children to return all pieces to this container after play.
Chicken coop roof/top does not stay attached securely.	Minor manufacturing variation or wear over time.	Ensure the roof is aligned correctly with its attachment points. If it consistently detaches, consider using a small amount of non-toxic, removable adhesive (e.g., poster putty) to secure it during play, if appropriate for the child's age and supervision level.

Product Specifications

Model Number: 42421

Product Dimensions: 7.28 x 6.69 x 4.13 inches (18.5 x 17 x 10.5 cm)

Item Weight: 12.3 ounces (348.7 grams)

Recommended Age: 36 months - 8 years

Brand: Schleich

Material: Durable, high-quality plastic

Number of Pieces: 8

Warranty and Customer Support

Schleich products are manufactured to high-quality standards. For specific warranty information, please refer to the packaging or contact Schleich customer service directly.
For further assistance, product inquiries, or to explore more Schleich products, please visit the officiaSchleich Store on Amazon.

© 2024 Schleich. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09S3XR256

More documents and user manuals: **https://manuals.plus/**