Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MSI Optix G321CQP

MSI G321CQP 32-inch Gaming Monitor User Manual

Model: Optix G321CQP | Brand: MSI

1. Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your MSI G321CQP 32-inch Gaming Monitor. Please read this manual thoroughly before using the product to ensure optimal performance and safety.



Figure 1.1: Front view of the MSI G321CQP monitor.

2. Package Contents

Verify that all items are present in the package. If any items are missing or damaged, contact your retailer.

- MSI G321CQP Monitor
- Monitor Stand (Base and Neck)
- Power Cable
- HDMI Cable
- DisplayPort Cable
- USB Upstream Cable
- Documentation (User Manual, Quick Start Guide, Warranty Card)

3. Setup

3.1 Assembling the Stand

1. Carefully place the monitor face down on a soft, clean surface to prevent scratches.
2. Attach the stand neck to the monitor's VESA mount area. Secure it with the provided screws.
3. Attach the stand base to the stand neck. Tighten the thumb screw or screws at the bottom of the base.



Figure 3.1: Rear view of the monitor with stand assembly.

3.2 Connecting the Monitor

Ensure the monitor and your computer are powered off before making any connections.

1. **Power Connection:** Connect the power cable to the monitor's power input and then to a power outlet.
2. **Video Connection:** Connect one end of the HDMI or DisplayPort cable to your computer's graphics card and the other end to the corresponding port on the monitor. For optimal performance (165Hz, FreeSync Premium), DisplayPort is recommended.
3. **USB Upstream Connection (Optional):** Connect the USB upstream cable from your computer to the monitor's USB upstream port to enable the monitor's USB downstream ports.
4. **Audio Connection (Optional):** If using external speakers or headphones, connect them to the monitor's audio output jack.



Figure 3.2: Monitor input ports.

3.3 Adjusting the Monitor

The MSI G321CQP monitor features an adjustable stand for ergonomic viewing comfort.

- **Height Adjustment:** Gently push or pull the monitor up or down to adjust its height.
- **Tilt Adjustment:** Hold both sides of the monitor and gently tilt it forwards or backwards.
- **Swivel Adjustment:** Rotate the monitor left or right on its stand.
- **Pivot Adjustment:** Rotate the monitor 90 degrees for portrait mode (ensure sufficient clearance).




Figure 3.3: Monitor adjustability features.

4. Operating the Monitor

4.1 Power On/Off

Press the power button located on the monitor to turn it on or off. The power indicator light will show the monitor's status.

4.2 On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various monitor settings. Use the joystick navigator button, typically located on the back or bottom of the monitor, to access and navigate the OSD.

- **Joystick Up/Down:** Navigate through menu options.
- **Joystick Left/Right:** Adjust values or enter sub-menus.
- **Joystick Press:** Select an option or confirm a setting.

4.3 Key Features and Settings

- **WQHD Resolution (2560 x 1440):** Provides a detailed and expansive viewing experience.
- **165Hz Refresh Rate:** Delivers smooth visual fluidity, reducing motion blur. Ensure your graphics card and connection type (DisplayPort recommended) support this refresh rate.



Figure 4.1: Visual comparison of 60Hz vs. 165Hz refresh rates.

- **1ms Response Time:** Minimizes ghosting and blurring for fast-paced content.




Figure 4.2: Illustration of 1ms response time.

- **AMD FreeSync Premium:** Synchronizes the monitor's refresh rate with your GPU's frame rate to eliminate screen tearing and stuttering. Enable this feature in both the monitor's OSD and your graphics card settings.




Figure 4.3: FreeSync Premium in action.

- **HDR Ready:** Supports High Dynamic Range content for enhanced contrast and color. Activate HDR in your operating system display settings.




Figure 4.4: HDR Ready feature comparison.

- **Wide Color Gamut:** Provides a broader range of colors for more vibrant and realistic visuals.




Figure 4.5: Wide Color Gamut illustration.

- **Console Mode:** Optimizes display settings for console gaming.



Figure 4.6: Console Mode for gaming.

- **Night Vision:** Enhances visibility in dark areas of games.




Figure 4.7: Night Vision feature comparison.

- **Less Blue Light PRO:** Reduces blue light emission to minimize eye strain during extended use.
- **PIP/PBP Mode:** Picture-in-Picture (PIP) and Picture-by-Picture (PBP) modes allow you to display content from multiple sources simultaneously.

5. Maintenance

5.1 Cleaning the Screen

To clean the monitor screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Do not spray cleaner directly onto the screen.

5.2 Cleaning the Casing

Use a soft, dry cloth to wipe the monitor casing. Avoid using strong detergents or abrasive cleaners, as they may damage the surface.

5.3 Storage

When storing the monitor for an extended period, power it off, disconnect all cables, and store it in a cool, dry place, preferably in its original packaging.

6. Troubleshooting

If you encounter issues with your monitor, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No image on screen	Monitor not powered on; Video cable loose or disconnected; Incorrect input source selected.	Ensure power cable is securely connected and monitor is on. Check video cable connections. Select correct input source via OSD.
Image is blurry or distorted	Incorrect resolution or refresh rate; Video cable quality.	Set display resolution to 2560x1440 and refresh rate to 165Hz in your operating system. Try a different, high-quality video cable.

Problem	Possible Cause	Solution
Screen tearing or stuttering	FreeSync Premium not enabled; Graphics card driver issues.	Enable FreeSync Premium in monitor OSD and graphics card control panel. Update graphics drivers.
No audio	External speakers/headphones not connected; Audio output not selected.	Ensure audio devices are properly connected. Select the monitor's audio output in your operating system's sound settings.
Monitor not detected by PC	Video cable issue; Graphics card issue.	Check video cable connection. Try a different video port on your graphics card or monitor. Ensure graphics card drivers are installed.

7. Specifications

Below are the technical specifications for the MSI G321CQP monitor.

Feature	Specification
Screen Size	32 Inches
Panel Type	VA
Resolution	2560 x 1440 (QHD)
Refresh Rate	165Hz
Response Time	1ms
Adaptive Sync Technology	FreeSync Premium
Curvature	1000R
Video Ports	HDMI, DisplayPort
USB Ports	1x USB 2.0 (Upstream), 2x USB 2.0 (Downstream)
Audio Ports	Headphone Out
Adjustability	Tilt, Swivel, Height, Pivot
Dimensions (LxWxH)	27.74 x 11.29 x 21.98 inches
Weight	21.1 pounds
Color	Black



Figure 7.1: Monitor dimensions.

8. Warranty and Support

For warranty information, please refer to the warranty card included in your product package or visit the official MSI website. For technical support, driver downloads, or further assistance, please visit the MSI support page or contact their customer service.

- **MSI Official Website:** www.msi.com
- **Support Page:** Refer to the official website for specific support contacts and resources.

© 2024 MSI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09S422R8B

More documents and user manuals: **https://manuals.plus/**