Calvin Klein 25200003

Calvin Klein Women's Quartz Analog Watch Model 25200003 Instruction Manual

Model: 25200003

Introduction

This manual provides essential instructions for the proper use, setup, and maintenance of your Calvin Klein Women's Quartz Analog Watch, Model 25200003. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

Product Overview

Your Calvin Klein watch is designed with a minimalist aesthetic and reliable quartz movement. It features a durable stainless steel case and a comfortable mesh bracelet.

Key Features:

- Quartz two-hand movement for accurate timekeeping.
- 38mm case diameter with a slim 7.5mm thickness.
- Elegant silver and white sunray dial.
- Yellow gold IP stainless steel mesh bracelet with a sliding fold-over clasp.
- Water resistance up to 3 ATM (30 meters), suitable for splashes and rain.

Watch Components:

Familiarize yourself with the main parts of your watch:

- **Crown:** Used for setting the time.
- **Dial:** The watch face displaying the time.
- **Hands:** Hour and minute hands.
- **Case:** The main body of the watch.
- **Bracelet:** The mesh band that secures the watch to your wrist.
- **Clasp:** The mechanism that fastens the bracelet.



Figure 1: Front view of the Calvin Klein Women's Quartz Analog Watch, Model 25200003. Shows the silver dial, gold-tone case, and mesh bracelet.

Setup

1. Setting the Time:

1. Gently pull the crown (located on the right side of the watch case) outwards to the time-setting position.
2. Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position against the watch case. This will start the watch movement.



Figure 2: Side view of the watch, highlighting the crown for time adjustment.

2. Adjusting the Mesh Bracelet:

The mesh bracelet features a sliding clasp for easy adjustment to fit your wrist size. No special tools are typically required.

1. Locate the small lever or tab on the clasp.
2. Using a small, flat tool (like a small screwdriver or a sturdy fingernail), lift the lever to unlock the clasp mechanism.
3. Slide the clasp along the mesh band to the desired position for a comfortable fit.
4. Press the lever back down firmly until it clicks into place, securing the clasp. Ensure it is fully closed to prevent accidental opening.



Figure 3: The watch worn on a wrist, demonstrating proper fit after bracelet adjustment.

Operating Your Watch

Once the time is set and the bracelet is adjusted, your watch will operate continuously. The quartz movement ensures accurate timekeeping with minimal intervention.

- **Daily Use:** Wear your watch as desired. Avoid exposing it to extreme temperatures, strong magnetic fields, or harsh chemicals.
- **Water Resistance:** This watch is water resistant to 3 ATM (30 meters). This means it can withstand splashes, rain,

and brief immersion in water (e.g., washing hands). It is **not** suitable for swimming, showering, diving, or any water sports. Ensure the crown is fully pushed in before any contact with water.

Maintenance

Cleaning Your Watch:

- Wipe the watch case and crystal with a soft, dry, lint-free cloth.
- For the mesh bracelet, a slightly damp cloth can be used, followed by immediate drying with a soft, dry cloth. Avoid using abrasive cleaners or chemicals.

Battery Replacement:

Your watch is powered by a lithium metal battery. When the watch stops running, the battery may need replacement. Battery replacement should be performed by a qualified watch technician to ensure the water resistance seal is maintained and to prevent damage to the movement.



Figure 4: Back view of the watch case, showing the sealed back where battery replacement would occur.

Troubleshooting

Problem	Possible Cause	Solution
Watch not running.	Battery depleted or crown pulled out.	Push the crown fully in. If still not running, the battery may need replacement by a professional.

Problem	Possible Cause	Solution
Time is inaccurate.	Time not set correctly or watch exposed to strong magnetic fields.	Reset the time as per "Setting the Time" instructions. Keep the watch away from magnets.
Moisture inside the watch.	Crown not fully pushed in or watch exposed to water beyond its resistance rating.	Immediately take the watch to a qualified watch technician for inspection and repair to prevent further damage.

Specifications

Feature	Detail
Model Number	25200003
Movement	Quartz (Analog)
Case Material	Stainless Steel
Case Diameter	38 mm
Case Thickness	7.5 mm
Band Material	Stainless Steel Mesh
Band Width	17 mm
Band Color	Gold (Yellow Gold IP)
Dial Color	Silver
Crystal Material	Mineral Glass
Water Resistance	3 ATM (30 meters) - Splash Resistant
Clasp Type	Sliding Fold-Over Clasp
Power Source	Battery Powered (1 Lithium Metal battery included)
Item Weight	54 grams

Warranty and Support

Your Calvin Klein watch is manufactured by Movado Group. For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Calvin Klein Watches website. Keep your proof of purchase for any warranty claims.



Figure 5: The watch packaging, typically containing the warranty card and additional documentation.

© 2024 Calvin Klein Watches. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question