Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced DPVR-7530D

RemotesReplaced Compatible Remote Control User Manual for FUNAI DPVR-7530D DVD Player

Model: DPVR-7530D

1. Introduction

This manual provides comprehensive instructions for the RemotesReplaced compatible remote control, specifically designed for use with the FUNAI DPVR-7530D DVD player. This remote offers all the essential functions required to operate your device effectively. Please read this manual thoroughly before use to ensure proper operation and to maximize your user experience.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off in the direction indicated by the arrow.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

No setup codes are required. Once batteries are installed, the remote is ready for use with your FUNAI DPVR-7530D DVD player.



Figure 2.1: Back view of the remote control, highlighting the battery compartment. This image shows the location for inserting two AAA batteries.

3. Operating Instructions

This section details the functions of the buttons on your RemotesReplaced compatible remote control.



Figure 3.1: Front view of the remote control, displaying the layout of all functional buttons.



Figure 3.2: Side view of the remote control, illustrating its profile and button placement.



Figure 3.3: Top view of the remote control, showing the infrared emitter at the front.

3.1 Basic Functions

- **POWER (Red Button):** Turns the FUNAI DPVR-7530D DVD player on or off.
- **MUTE:** Mutes or restores the audio output.
- **TV/SAT/DVD/AUX:** Selects the input source on your television or audio system. Use **DVD** for controlling the FUNAI DPVR-7530D.
- **Number Buttons (0-9):** Used for direct channel selection or inputting numerical values.
- **VOL +/-:** Adjusts the volume level.
- **CH +/- (P +/-):** Changes the channel or navigates through menus.
- **OK (Enter):** Confirms a selection or enters a menu option.
- **Directional Arrows (Up, Down, Left, Right):** Navigates through menus and options.

3.2 Playback and Menu Functions

- **MENU:** Accesses the main menu of the DVD player.
- **EXIT:** Exits the current menu or function.
- **GUIDE:** Displays the electronic program guide (if supported by the connected TV/system).
- **SETUP:** Accesses the system setup menu.
- **TEXT:** Toggles teletext display (if available).
- **BACK:** Returns to the previous screen or menu.
- **INFO:** Displays information about the current program or disc.
- **EPG:** Electronic Program Guide.
- **FAV:** Accesses favorite channels or settings.
- **SLEEP:** Sets a sleep timer.
- **TV/DTV:** Switches between TV and Digital TV modes.
- **NET TV / SMART:** Accesses network or smart features (if supported by the connected device).
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next):** Controls DVD playback.
- **Colored Buttons (Red, Green, Yellow, Blue):** These buttons typically correspond to on-screen prompts in menus or interactive features.

4. Maintenance

4.1 Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

4.2 Battery Replacement

Replace the batteries when the remote control's response becomes sluggish or stops functioning. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

5. Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote control does not work.	• Batteries are dead or incorrectly inserted. • Obstruction between remote and DVD player. • Remote control is too far from the DVD player.	• Replace batteries with new ones, ensuring correct polarity. • Remove any objects blocking the line of sight to the DVD player's IR sensor. • Move closer to the DVD player (within 10 meters).
Buttons are unresponsive or sticky.	• Dirt or debris under the buttons. • Worn-out internal contacts.	• Clean the remote control as described in Section 4.1. • If cleaning does not resolve the issue, the remote may need replacement.
Remote controls other devices unintentionally.	• Infrared signals interfering with other devices.	• Ensure the remote is pointed directly at the FUNAI DPVR-7530D DVD player. • Minimize other infrared devices in the immediate vicinity.

6. Specifications

Brand	RemotesReplaced
Model Number	DPVR-7530D
Compatible Device	FUNAI DPVR-7530D DVD Player
Power Source	2 x AAA Batteries
Maximum Range	10 Meters

Item Weight	120 Grams
Manufacturer	Linkwebb

7. Warranty and Support

7.1 Warranty Information

This RemotesReplaced compatible remote control comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote control functions as intended. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact your retailer or the RemotesReplaced customer service. Refer to the packaging or your purchase documentation for specific contact details.

© 2025 RemotesReplaced. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09S6MFGDZ

More documents and user manuals: **https://manuals.plus/**