Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced FIN22851DVD

RemotesReplaced Compatible Remote Control for FINLUX FIN22851DVD

Model: FIN22851DVD

Introduction

This manual provides instructions for the RemotesReplaced compatible remote control, specifically designed for the FINLUX FIN22851DVD model. This remote control offers identical electronic functionality to the original device, ensuring all features are accessible. It is a direct replacement and does not require any programming or setup codes.

Setup

Battery Installation

The remote control requires two (2) AAA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

No setup codes are required. Once batteries are installed, the remote is ready for immediate use with your FINLUX FIN22851DVD.



Image: Back view of the remote control, illustrating the location of the battery compartment for installation.

Operating Instructions

This replacement remote control is designed to function identically to your original FINLUX FIN22851DVD remote. All buttons correspond to the functions of the original device. Point the remote control directly at your FINLUX FIN22851DVD unit for optimal performance.



Image: Front view of the remote control, displaying all functional buttons including power, channel, volume, navigation, and playback controls.

Key Functions Overview:

- **POWER:** Turns the device on or off.
- **MUTE:** Mutes or unmutes the audio.
- **TV/SAT/DVD/AUX:** Selects the input source.
- **MENU/EXIT:** Accesses or exits the on-screen menu.
- **SHIFT:** Activates secondary functions of certain buttons.
- **Number Buttons (0-9):** For direct channel selection or data input.
- **SOURCE:** Cycles through available input sources.
- **-/--:** Toggles between single and double-digit channel input.
- **GUIDE:** Displays the electronic program guide.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the channel.
- **OK/Navigation Arrows:** Confirms selections and navigates through menus.
- **BACK:** Returns to the previous screen or menu.
- **SLEEP:** Sets a sleep timer for the device.
- **TV/DTV:** Switches between analog and digital television modes.
- **EPG:** Accesses the Electronic Program Guide.
- **FAV:** Accesses favorite channels list.
- **NET TV/SMART:** Accesses smart TV features or internet applications.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or inconsistent. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote's surface or internal components.

Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage.

Troubleshooting

- **Remote not responding:**
  - Ensure the batteries are correctly installed with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote control and the FINLUX FIN22851DVD unit.
  - Ensure you are within the effective operating range and pointing the remote directly at the device's IR receiver.
- **Specific buttons not working:**
  - Clean the remote control, especially around the problematic buttons, to remove any dirt or debris that might be interfering with their function.
  - If only a few buttons are unresponsive after checking batteries and cleaning, the remote may require

replacement.

Specifications

Brand	RemotesReplaced
Model Number	FIN22851DVD
Battery Type	2 x AAA batteries (not included)
Item Weight	120 Grams
Manufacturer	Linkwebb

Warranty and Support

Warranty Information

This RemotesReplaced compatible remote control comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact the retailer or manufacturer where the product was purchased. Refer to your purchase documentation for specific contact details.

© 2026 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09S6NV6V3

More documents and user manuals: **https://manuals.plus/**