Noma 272533

Noma LED Quick-Clip C9 Multicolor String Lights

INSTRUCTION MANUAL - MODEL 272533

1. Introduction

Thank you for choosing Noma LED Quick-Clip C9 Multicolor String Lights. This product is designed for both indoor and outdoor decorative lighting, featuring durable, energy-efficient LED bulbs. This manual provides essential information for safe installation, operation, and maintenance of your string lights. Please read these instructions carefully before use and retain them for future reference.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- **Read all instructions:** Before installing or using the string lights.
- **Indoor/Outdoor Use:** This product is rated for both indoor and outdoor use. Ensure all connections are secure and protected from moisture when used outdoors.
- **Electrical Rating:** Do not exceed the electrical rating of the string lights or any extension cords used. Refer to the product label for specific wattage information.
- **Connecting Multiple Sets:** Each 16' 7" strand has plug-ins at both ends. Do not connect more than the maximum number of sets specified on the product packaging or label. Overloading can cause fuses to blow or create a fire hazard.
- **Bulb Replacement:** Always unplug the string lights from the power source before replacing bulbs or fuses.
- **Secure Installation:** Ensure lights are securely fastened to prevent damage from wind or other environmental factors. Use the integrated quick-clips for easy and stable attachment.
- **Avoid Damage:** Do not pinch or cut the wire insulation. Do not mount the string lights in a manner that can cut or damage the wire insulation.
- **Supervision:** This is not a toy. Keep out of reach of children.

3. Package Contents

Your Noma LED Quick-Clip C9 Multicolor String Lights package includes:

- 1 x Noma LED Quick-Clip C9 Multicolor String Light Set (25 bulbs, 16' 7" length)
- 1 x Spare Fuse

- 2 x Spare C9 LED Bulbs
- Integrated Quick-Clips (attached to each bulb socket)

4. Setup and Installation

Follow these steps to set up your Noma LED Quick-Clip C9 String Lights:

1. **Unpack:** Carefully remove the string lights from the packaging. Untangle the strand gently to avoid damaging the wires or bulbs.
2. **Inspect:** Before plugging in, inspect the entire string for any signs of damage to the bulbs, wires, or plugs. Do not use if any damage is found.
3. **Placement:** Determine the desired location for your lights. Ensure the location is suitable for indoor or outdoor use as intended.
4. **Mounting:** Use the integrated quick-clips located at the base of each bulb socket to attach the lights to desired surfaces such as eaves, branches, railings, or other fixtures. The clips provide a secure and stable attachment point.
5. **Connecting Multiple Sets (Optional):** If connecting multiple sets, ensure the total wattage does not exceed the maximum allowed for the circuit. Connect the male plug of one set into the female receptacle at the end of another set. Secure all connections.
6. **Power Connection:** Once all lights are securely installed and connected, plug the main power cord into a standard electrical outlet.



Image: Noma C9 LED Multicolor Bulbs with Quick-Clips. This image displays five C9 LED bulbs in various colors (yellow, orange, blue, red, green), each attached to a white quick-clip at its base, illustrating the integrated clip design for easy installation.

5. Operating Instructions

Operating your Noma LED Quick-Clip C9 String Lights is straightforward:

- **Power On:** Plug the string lights into a live electrical outlet. The lights will illuminate.
- **Power Off:** Unplug the string lights from the electrical outlet to turn them off.
- **Continuous Operation:** These lights are designed for continuous illumination when powered. There are no built-in flashing or pattern modes.

6. Maintenance

Proper maintenance ensures the longevity and safe operation of your string lights.

Bulb Replacement

If a bulb burns out, it can be replaced. The set includes 2 spare bulbs.

1. **Unplug:** Always unplug the string lights from the power source before attempting any bulb replacement.
2. **Remove Old Bulb:** Gently twist the old bulb counter-clockwise to remove it from its socket.
3. **Insert New Bulb:** Insert a new C9 LED bulb into the socket and twist clockwise until secure.
4. **Test:** Plug the string lights back in to ensure the new bulb is working.

Fuse Replacement

If the entire string of lights does not illuminate, the fuse in the plug may need replacement. A spare fuse is included.

1. **Unplug:** Always unplug the string lights from the power source.
2. **Open Fuse Compartment:** Slide open the fuse access cover on the plug.
3. **Remove Old Fuse:** Carefully remove the old fuse.
4. **Insert New Fuse:** Insert the spare fuse into the compartment.
5. **Close Compartment:** Slide the fuse access cover back into place.
6. **Test:** Plug the string lights back in to check if they illuminate.

Cleaning and Storage

- **Cleaning:** Disconnect from power. Wipe bulbs and wires with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the string lights in a cool, dry place, away from direct sunlight and moisture. Coil the string neatly to prevent tangling and damage to wires.

7. Troubleshooting

If your Noma LED Quick-Clip C9 String Lights are not functioning as expected, refer to the following common issues and solutions:

- **Lights do not turn on:**
  - Ensure the plug is fully inserted into a working electrical outlet.
  - Check the fuse in the plug and replace if blown (refer to Fuse Replacement section).
  - Verify that no individual bulbs are loose or damaged. Replace any faulty bulbs.
- **Only part of the string is lit:**
  - Check for loose or burnt-out bulbs in the unlit section and replace them.
  - Inspect for any breaks or damage in the wiring of the unlit section. If damage is found, discontinue use.
- **Lights flicker:**
  - Ensure all bulbs are securely twisted into their sockets.
  - Check for loose connections at the plug or between connected sets.

If troubleshooting steps do not resolve the issue, please contact customer support.

8. Specifications

Feature	Detail
Brand	Noma
Model Number	272533
Indoor/Outdoor Usage	Indoor, Outdoor
Light Source Type	LED
Power Source	Corded Electric
Light Color	Multicolor

Number of Light Sources	25
Wattage	6E+1 (60W)
Material	Plastic
Item Weight	2.4 pounds
Included Components	Spare fuse, 2 spare bulbs, clips

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Noma customer service directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question