Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Microsoft Xbox 360 Slim 4GB Console

Microsoft Xbox 360 Slim 4GB Console with Kinect User Manual

Model: Xbox 360 Slim 4GB Console

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Microsoft Xbox 360 Slim 4GB Console with Kinect. Please read this manual thoroughly before using your console to ensure optimal performance and safety. Keep this manual for future reference.

1. Setup

1.1 Unpacking the Console

Carefully remove all components from the packaging. Ensure you have the Xbox 360 Slim console, Kinect sensor, power supply, AV cable (or HDMI cable), and any included accessories.



Image: The Xbox 360 Slim console shown alongside the Kinect sensor.

1.2 Connecting the Console to Power

1. Connect the power supply unit to the console's power input port.
2. Plug the power cord into the power supply unit.
3. Plug the other end of the power cord into a wall outlet.

1.3 Connecting to a Television

Use either an HDMI cable or the included AV cable to connect your Xbox 360 Slim to your television.

- **HDMI Connection (Recommended):** Connect one end of an HDMI cable to the HDMI port on the back of the console and the other end to an available HDMI input on your TV.
- **AV Connection:** Connect the multi-out connector of the AV cable to the AV port on the back of the console. Connect the yellow (video), red (audio right), and white (audio left) RCA connectors to the corresponding input ports on your TV.

1.4 Connecting the Kinect Sensor

1. Locate the dedicated Kinect port on the back of your Xbox 360 Slim console.
2. Plug the Kinect sensor cable into this port. The console will automatically detect the Kinect sensor.
3. Position the Kinect sensor horizontally, either above or below your TV, ensuring it has a clear view of the play area.



Image: The Kinect sensor, a horizontal bar with multiple cameras and microphones.

2. Operating Instructions

2.1 Turning On/Off the Console

- **To Turn On:** Press the power button on the front of the console or the Xbox Guide button on a connected controller.
- **To Turn Off:** Press and hold the power button on the console until it shuts down, or press and hold the Xbox Guide button on a controller, then select 'Turn Off Console'.

2.2 Using the Controller

The Xbox 360 controller allows you to navigate the dashboard, play games, and control media. Refer to the controller's specific manual for detailed button functions and pairing instructions.

2.3 Using the Kinect Sensor

The Kinect sensor allows for controller-free gameplay and navigation using body movements and voice commands.

- **Kinect Setup:** Follow the on-screen prompts after connecting the Kinect to calibrate it for your play space.
- **Gestures:** Use hand gestures to navigate the Xbox Dashboard. For example, wave your hand to select items or swipe to scroll.
- **Voice Commands:** Say "Xbox" to activate voice commands, then speak commands like "Xbox, play game" or "Xbox, pause."



Image: Two players engaging in a virtual rafting game using the Kinect sensor, demonstrating body-controlled gameplay.

2.4 Loading Games and Media

Insert a game disc or DVD/Blu-ray disc into the disc drive. The console will typically auto-launch the content. For digital games, navigate to your game library on the Xbox Dashboard and select the desired title.

3. Maintenance

3.1 Cleaning the Console and Kinect

- Use a soft, dry, lint-free cloth to clean the exterior of the console and Kinect sensor.
- Do not use abrasive cleaners, solvents, or chemical sprays.
- Keep vents clear of dust and obstructions to ensure proper airflow.

3.2 Storage

When not in use, store the console and Kinect in a cool, dry place away from direct sunlight and extreme temperatures. Disconnect the power supply if storing for an extended period.

4. Troubleshooting

If you encounter issues with your Xbox 360 Slim or Kinect, try the following solutions:

Problem	Solution
Console does not power on.	Ensure the power supply is securely connected to the console and a working wall outlet. Check the power brick indicator light.
No video or audio on TV.	Verify that the AV or HDMI cable is securely connected to both the console and the TV. Ensure the TV input is set to the correct source.
Kinect sensor not responding.	Check that the Kinect cable is firmly plugged into the console. Ensure the play area is well-lit and free of obstructions. Recalibrate the Kinect sensor through the console settings.
Disc drive not reading discs.	Ensure the disc is clean and free of scratches. Try a different disc. Restart the console.

For further assistance, refer to the official Microsoft Xbox support website.

5. Specifications

Feature	Detail
Model Number	Xbox 360 Slim 4GB Console
Internal Storage	4GB Flash Memory
Dimensions	30.5 x 33 x 18.4 cm
Weight	5.06 kg
Language	English (User Interface)
Included Accessory	Kinect Sensor

6. Warranty and Support

This product is a renewed item. Please refer to the specific warranty information provided by the seller or Amazon Renewed at the time of purchase. For technical support, visit the official Microsoft Xbox support website or contact the seller directly.

Online Resources:

- Microsoft Xbox Support: support.xbox.com
- Amazon Renewed Policy: Amazon Renewed

© 2026 Microsoft Corporation. All rights reserved. Xbox, Xbox 360, and Kinect are trademarks of the Microsoft group of companies.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09SBN9MVB

More documents and user manuals: **https://manuals.plus/**