Ariete 1380

Ariete 1380 Metal Slim Barista Espresso Coffee Maker User Manual

Model: 1380

Introduction

This manual provides detailed instructions for the safe and efficient operation of your Ariete 1380 Metal Slim Barista Espresso Coffee Maker. Please read all instructions carefully before first use and retain this manual for future reference. The Ariete 1380 is designed to deliver high-quality espresso and milk-based coffee beverages. Key features include:

- **Compact Design:** Slim profile for easy placement in any kitchen.
- **Versatile Coffee Options:** Compatible with both ground coffee and ESE pods.
- **15 Bar Pressure:** Ensures optimal extraction for rich espresso.
- **Maxi-Cappuccino Device:** Integrated milk frother for creamy cappuccinos and lattes.
- **Hot Water Dispenser:** For teas and other hot beverages.
- **Safety Features:** Automatic shut-off after 25 minutes and anti-drip system.

Safety Information

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons. This includes:

- Ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Unplug from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug.
- Use only manufacturer-recommended accessories.
- Avoid contact with hot surfaces.

Product Overview

Familiarize yourself with the components of your Ariete 1380 Espresso Coffee Maker.



Figure 1: Angled view of the Ariete 1380 Espresso Coffee Maker, showing the portafilter, steam wand, control panel, and water tank.



Figure 2: Front view of the Ariete 1380 Espresso Coffee Maker, highlighting the control buttons and portafilter.

Key Components:

1. **Water Tank:** Removable tank located at the back for easy refilling.
2. **Control Panel:** Buttons for single espresso, double espresso, and steam function.
3. **Portafilter:** Holds ground coffee or ESE pods.
4. **Steam Wand (Maxi-Cappuccino Device):** For frothing milk and dispensing hot water.
5. **Drip Tray:** Removable for easy cleaning, collects excess liquid.
6. **Cup Warmer:** Located on top of the machine to pre-heat cups.

Setup

Before using your coffee maker for the first time, follow these steps:

1. **Unpacking:** Carefully remove all packaging materials and ensure all parts are present.
2. **Cleaning:** Wash the water tank, portafilter, and drip tray with warm soapy water. Rinse thoroughly and dry.
3. **Positioning:** Place the machine on a stable, flat, heat-resistant surface, away from water sources and heat. Ensure adequate ventilation.
4. **Fill Water Tank:** Fill the removable water tank with fresh, cold water up to the MAX level. Ensure the tank is properly seated.
5. **First Use Rinse:**
    - Plug the appliance into a grounded power outlet.
    - Place a container under the portafilter and steam wand.
    - Turn on the machine. Allow it to heat up until the indicator light stops flashing (usually indicating it's ready).
    - Run a cycle of hot water through the portafilter without coffee.
    - Open the steam knob to dispense hot water through the steam wand for a few seconds. Close the knob.
    - Repeat this process 2-3 times to clean the internal circuits.

Operating Instructions

Making Espresso (Ground Coffee)

1. **Pre-heat:** Ensure the machine is on and heated. Place your espresso cup on the cup warmer.
2. **Prepare Portafilter:** Insert the appropriate filter basket for ground coffee into the portafilter.
3. **Add Coffee:** Add one or two scoops of finely ground espresso coffee into the filter basket. Distribute evenly.
4. **Tamp Coffee:** Use a tamper to press the coffee firmly. Wipe any excess coffee from the rim.
5. **Attach Portafilter:** Securely attach the portafilter to the brewing head by twisting it to the right until it locks.
6. **Brew Espresso:** Place your pre-heated cup(s) under the portafilter spouts. Press the single or double espresso button. The machine will automatically dispense the programmed amount of coffee.
7. **Remove Portafilter:** Once brewing is complete, carefully remove the portafilter by twisting it to the left. Discard the used coffee grounds.

Making Espresso (ESE Pods)

1. **Pre-heat:** Ensure the machine is on and heated.
2. **Prepare Portafilter:** Insert the filter basket designed for ESE pods into the portafilter.
3. **Insert Pod:** Place one ESE pod into the filter basket, ensuring it is centered.

4. **Attach Portafilter:** Securely attach the portafilter to the brewing head.
5. **Brew Espresso:** Place your cup under the portafilter spout. Press the single espresso button.
6. **Remove Pod:** After brewing, carefully remove the portafilter and discard the used pod.

Frothing Milk


MAX

Figure 3: Demonstrating the use of the steam wand to froth milk in a pitcher.

1. **Prepare Milk:** Fill a stainless steel milk pitcher with cold milk (dairy or non-dairy) to about one-third full.
2. **Activate Steam:** Press the steam button on the control panel. Wait for the indicator light to show the machine is ready for steaming.
3. **Position Wand:** Position the steam wand just below the surface of the milk in the pitcher.
4. **Froth Milk:** Slowly turn the steam knob to release steam. Move the pitcher up and down gently to incorporate air and create foam. Continue until the desired temperature and texture are achieved.
5. **Stop Steaming:** Turn off the steam knob, then press the steam button to deactivate the steam function.
6. **Clean Wand:** Immediately wipe the steam wand with a damp cloth to prevent milk residue from drying. Briefly open the steam knob again to purge any milk from inside the wand.

Hot Water Dispensing

To dispense hot water for tea or other beverages:

1. Ensure the machine is on and heated.
2. Place a cup under the steam wand.
3. Turn the steam knob to dispense hot water.
4. Close the steam knob when the desired amount of hot water is dispensed.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

- **Daily Cleaning:**
  - Empty and rinse the drip tray and water tank.
  - Clean the portafilter and filter basket after each use.
  - Wipe down the exterior of the machine with a damp cloth.
  - Clean the steam wand immediately after frothing milk.
- **Descaling:**
  - The machine has a cleaning indicator light. When this light illuminates, it indicates that descaling is required.
  - Use a commercial descaling solution suitable for espresso machines, following the manufacturer's instructions.
  - Typically, this involves running the descaling solution through the machine's water circuits, followed by several rinses with fresh water.

Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
No coffee dispenses.	Water tank empty, clogged filter, machine not heated.	Refill water tank, clean filter, allow machine to heat up.

Problem	Possible Cause	Solution
Coffee is too weak.	Coffee too coarse, not enough coffee, insufficient tamping.	Use finer grind, increase coffee amount, tamp more firmly.
No steam from wand.	Steam function not activated, wand clogged.	Activate steam function, clean steam wand.
Water leaking from machine.	Water tank not seated correctly, seals damaged.	Re-seat water tank, contact customer support if problem persists.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Feature	Detail
Brand	Ariete
Model Number	00M138010AR0
Color	Silver
Product Dimensions (D x W x H)	34 x 14 x 29 cm
Item Weight	4.1 Kilograms
Capacity (Water Tank)	1.1 Liters
Power / Wattage	1300 watts
Voltage	220 Volts
Material	Metal
Auto Shutoff	Yes (after 25 minutes)
Special Features	Removable Tank, 15 Bar Pressure, Milk Frother



Figure 4: Product dimensions, indicating a height of 11 inches (28 cm).

Warranty and Support

Your Ariete 1380 Espresso Coffee Maker comes with a**1-year warranty** from the date of purchase, covering manufacturing defects.
For warranty claims, technical support, or service inquiries, please refer to the contact information provided with your purchase documentation or visit the official Ariete website.
Please retain your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question