Hot Wheels FTB65

Hot Wheels Corkscrew Crash Track Set

Model: FTB65

1. Introduction

Welcome to the exciting world of Hot Wheels! The Corkscrew Crash Track Set is designed for high-speed action, featuring multiple motorized boosters, gravity-defying loops, and thrilling crash zones. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your track set to ensure a fun and safe play experience.



The complete Hot Wheels Corkscrew Crash Track Set, showcasing its multiple loops and crash zones.

2. Initial Setup

While the Hot Wheels Corkscrew Crash Track Set does not require complex assembly, some initial setup is necessary before play. Please follow these steps carefully.

2.1 Unpacking and Component Check

- Carefully remove all components from the packaging.
- Verify that all parts are present as listed on the product box. The set includes: 1 Hot Wheels Corkscrew Crash Track Set, 3 Motorized Boosters, 3 Epic Crash Zones, 3 Gravity Defying Loops, and 1 Hot Wheels Vehicle.
- Dispose of packaging materials responsibly.



The product packaging for the Hot Wheels Corkscrew Crash Track Set.

2.2 Battery Installation

The motorized boosters require batteries for operation. Batteries are**not** included with the set.

- Locate the battery compartments on each of the three motorized boosters.
- Using a screwdriver (not included), open the battery compartment covers.
- Insert the required 'D' size batteries (as specified on the compartment) ensuring correct polarity (+/-).
- Securely close the battery compartment covers.

3. Operating Instructions

Once the track set is assembled and batteries are installed, you are ready for high-octane racing action!

3.1 Launching Cars

Place a Hot Wheels car at the starting gate. Ensure the motorized boosters are switched on. Press the launch mechanism to send your car speeding into the track.



A Hot Wheels car being launched from the starting mechanism into the track.

3.2 Navigating the Corkscrew and Loops

The track features a unique corkscrew design and three gravity-defying loops. The motorized boosters will propel cars through these sections at high speeds. Observe how the cars gain momentum and navigate the challenging curves.



Multiple Hot Wheels cars racing simultaneously through the corkscrew loops of the track set.

3.3 Engaging the Crash Zones

The set includes three high-action crash zones. Cars will collide and potentially crash in these areas, adding an element of unpredictable excitement. Experiment with launching multiple cars to increase the chances of spectacular crashes.



Two Hot Wheels cars about to collide within one of the designated crash zones on the track.



Two children actively engaged in playing with the Hot Wheels Corkscrew Crash Track Set, demonstrating its interactive nature.

4. Maintenance

Proper care and maintenance will help extend the life of your Hot Wheels Corkscrew Crash Track Set.

- **Cleaning:** Wipe down track pieces and components with a dry or slightly damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the track set in a clean, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries from the motorized boosters if the set will not be used for an extended period to prevent leakage.
- **Inspection:** Periodically check all track connections and components for any signs of wear or damage. Replace any broken parts immediately.

5. Troubleshooting

If you encounter any issues with your Hot Wheels Corkscrew Crash Track Set, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Cars are not moving or moving slowly through boosters.	Low or dead batteries. Boosters are switched off. Obstruction in booster mechanism.	Replace batteries. Ensure booster switch is in the 'ON' position. Check for and remove any debris.
Cars are derailing frequently.	Loose track connections. Track not on a flat surface. Incorrect car type/weight.	Ensure all track pieces are securely connected. Place the set on a flat, stable surface. Use standard Hot Wheels cars designed for track play.
Boosters are making unusual noises.	Foreign object lodged in booster. Worn gears.	Turn off and inspect boosters for obstructions. If noise persists, contact customer support.

6. Specifications

Feature	Detail
Model Number	FTB65
Brand	Hot Wheels (MATTEL)
Recommended Age	5 - 9 years
Material	Plastic
Power Source	Battery Powered
Batteries Required	Yes (D size)
Batteries Included	No
Product Dimensions	0.99 x 0.99 x 0.99 cm; 840.01 g (approximate)
UPC	0887961639896

7. Warranty and Support

This product is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or visit the official Hot Wheels/Mattel website.
For technical support, replacement parts, or further assistance, please contact Mattel Customer Service. Contact information can typically be found on the product packaging or the official Mattel website.

© 2023 Mattel. All Rights Reserved. Hot Wheels and associated trademarks are owned by Mattel.